



Documentation

EL20xx, EL2124

Digital Output Terminals

Version: 5.4
Date: 2020-02-27

BECKHOFF

Table of contents

| | |
|---|-----------|
| 1 Foreword | 5 |
| 1.1 Product overview, digital output terminals | 5 |
| 1.2 Notes on the documentation..... | 5 |
| 1.3 Safety instructions | 7 |
| 1.4 Documentation issue status | 8 |
| 1.5 Version identification of EtherCAT devices | 10 |
| 1.5.1 Beckhoff Identification Code (BIC)..... | 12 |
| 1.6 Interference-free Bus Terminals | 13 |
| 2 Product overview, digital output terminals..... | 18 |
| 2.1 EL2002, EL2004, EL2008 - Introduction | 18 |
| 2.1.1 EL2002, EL2004, EL2008 - Technical data | 20 |
| 2.1.2 EL2002 - LEDs and connection | 21 |
| 2.1.3 EL2004 - LEDs and connection | 22 |
| 2.1.4 EL2008 - LEDs and connection | 23 |
| 2.2 EL2014 | 24 |
| 2.2.1 EL2014 - Introduction | 24 |
| 2.2.2 EL2014 - Technical data | 25 |
| 2.2.3 EL2014 - LEDs and pin assignment | 26 |
| 2.2.4 Overload protection | 27 |
| 2.2.5 Operating modes and settings | 29 |
| 2.2.6 Object description and parameterization | 35 |
| 2.3 EL2022, EL2024, EL2024-0010 - Introduction | 44 |
| 2.3.1 EL2022, EL2024, EL2024-0010 - Technical data | 45 |
| 2.3.2 EL2022 - LEDs and connection | 46 |
| 2.3.3 EL2024, EL2024-0010 - LEDs and connection | 47 |
| 2.3.4 EL2022, EL2024, EL2024-0010 - Switching off inductive loads | 48 |
| 2.4 EL2032, EL2034 - Introduction | 49 |
| 2.4.1 EL2032, EL2034 - Technical data | 50 |
| 2.4.2 EL2032 - LEDs and connection | 51 |
| 2.4.3 EL2034 - LEDs and connection | 52 |
| 2.4.4 EL2032, EL2034 - Switching off inductive loads | 53 |
| 2.5 EL2042 - Introduction | 54 |
| 2.5.1 EL2042 - Technical data | 55 |
| 2.5.2 EL2042 - LEDs and connection | 56 |
| 2.5.3 EL2042 - Switching off inductive loads | 57 |
| 2.6 EL2084, EL2088 - Introduction | 58 |
| 2.6.1 EL2084, EL2088 - Technical data | 59 |
| 2.6.2 EL2084 - LEDs and connection | 60 |
| 2.6.3 EL2088 - LEDs and connection | 61 |
| 2.7 EL2124 - Introduction | 62 |
| 2.7.1 EL2124 - Technical data | 63 |
| 2.7.2 EL2124 - LEDs and connection | 64 |
| 3 Basics communication | 65 |
| 3.1 EtherCAT basics..... | 65 |

| | | |
|----------|---|------------|
| 3.2 | EtherCAT cabling – wire-bound..... | 65 |
| 3.3 | General notes for setting the watchdog..... | 66 |
| 3.4 | EtherCAT State Machine | 68 |
| 3.5 | CoE Interface..... | 71 |
| 3.6 | Distributed Clock | 75 |
| 4 | Mounting and wiring..... | 76 |
| 4.1 | Installation on mounting rails | 76 |
| 4.2 | Installation instructions for enhanced mechanical load capacity | 78 |
| 4.3 | Positioning of passive Terminals | 79 |
| 4.4 | Installation positions | 80 |
| 4.5 | Connection | 82 |
| 4.5.1 | Connection system | 82 |
| 4.5.2 | Wiring..... | 84 |
| 4.5.3 | Shielding | 85 |
| 4.6 | ATEX - Special conditions (standard temperature range) | 85 |
| 4.7 | ATEX - Special conditions (extended temperature range) | 86 |
| 4.8 | ATEX Documentation | 87 |
| 5 | Commissioning..... | 88 |
| 5.1 | TwinCAT Quick Start | 88 |
| 5.1.1 | TwinCAT 2 | 91 |
| 5.1.2 | TwinCAT 3 | 101 |
| 5.2 | TwinCAT Development Environment | 113 |
| 5.2.1 | Installation of the TwinCAT real-time driver..... | 113 |
| 5.2.2 | Notes regarding ESI device description..... | 119 |
| 5.2.3 | TwinCAT ESI Updater | 123 |
| 5.2.4 | Distinction between Online and Offline..... | 123 |
| 5.2.5 | OFFLINE configuration creation | 124 |
| 5.2.6 | ONLINE configuration creation | 129 |
| 5.2.7 | EtherCAT subscriber configuration..... | 137 |
| 5.3 | General Notes - EtherCAT Slave Application | 146 |
| 6 | Appendix | 155 |
| 6.1 | EtherCAT AL Status Codes | 155 |
| 6.2 | UL notice | 155 |
| 6.3 | Firmware compatibility | 156 |
| 6.4 | Firmware Update EL/ES/EM/ELM/EPxxxx | 156 |
| 6.4.1 | Device description ESI file/XML..... | 157 |
| 6.4.2 | Firmware explanation | 160 |
| 6.4.3 | Updating controller firmware *.efw..... | 161 |
| 6.4.4 | FPGA firmware *.rbf..... | 163 |
| 6.4.5 | Simultaneous updating of several EtherCAT devices..... | 167 |
| 6.5 | Restoring the delivery state | 168 |
| 6.6 | Support and Service | 169 |

1 Foreword

1.1 Product overview, digital output terminals

| | |
|---|---|
| EL2002 [▶ 18] | 2 channels, 24 V _{DC} , 0.5 A |
| EL2004 [▶ 18] | 4 channels, 24 V _{DC} , 0.5 A |
| EL2008 [▶ 18] | 8 channels, 24 V _{DC} , 0.5 A |
| EL2014 [▶ 24] | 4 channels, 24 V _{DC} , 0.5 A, diagnostics |
| EL2022, EL2024 [▶ 44] | 2 and 4 channels, 24 V _{DC} , 2 A |
| EL2024-0010 [▶ 44] | 4 channels, 12 V _{DC} , 2 A |
| EL2032, EL2034 [▶ 49] | 2 and 4 channels, 24 V _{DC} , 2 A, diagnostics |
| EL2042 [▶ 54] | 2 channels, 24 V _{DC} ; 2 x 4 A/1 x 8 A |
| EL2084, EL2088 [▶ 58] | 4 and 8 channels, 24 V _{DC} , 0.5 A |
| EL2124 [▶ 62] | 4 channels, 5 V _{DC} , CMOS-outputs |

1.2 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.3 Safety instructions

Safety regulations

Please note the following safety instructions and explanations!

Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

Description of instructions

In this documentation the following instructions are used.

These instructions must be read carefully and followed without fail!

DANGER

Serious risk of injury!

Failure to follow this safety instruction directly endangers the life and health of persons.

WARNING

Risk of injury!

Failure to follow this safety instruction endangers the life and health of persons.

CAUTION

Personal injuries!

Failure to follow this safety instruction can lead to injuries to persons.

NOTE

Damage to environment/equipment or data loss

Failure to follow this instruction can lead to environmental damage, equipment damage or data loss.



Tip or pointer

This symbol indicates information that contributes to better understanding.

1.4 Documentation issue status

| Version | Comment |
|---------|---|
| 5.4 | - Update chapter "Introduction" - Update chapter "Technical data" - Update structure - Update revision status |
| 5.3 | - Update chapter "Technical data" - Update structure - Chapter "Non-reactive Bus Terminals" updated |
| 5.2 | - Update structure - Chapter "Non-reactive Bus Terminals" updated |
| 5.1 | - Update structure - Chapter "Non-reactive Bus Terminals" updated |
| 5.0 | - Update structure - Chapter "Technical data" updated |
| 4.9 | - Chapter "Non-reactive Bus Terminals" updated |
| 4.8 | - Chapter "Introduction" updated - Chapter "LEDs and connection" updated - Update structure |
| 4.7 | - Chapter "Non-reactive Bus Terminals" updated - Update structure |
| 4.6 | - Chapter "Non-reactive Bus Terminals" updated - Chapter "Technical data" updated |
| 4.5 | - Chapter "Introduction" Notes updated - Chapter "Technical data" updated |
| 4.4 | - Chapter "Foreword" – "Notes on the documentation" updated - Technical data corrected - Chapter "TwinCAT Quickstart" added - Chapter "EtherCAT slave process data settings" removed |
| 4.3 | - Chapter "Technical data" updated - Chapter "Connection" updated |
| 4.2 | - Chapter "Non-reactive Bus Terminals" added |
| 4.1 | - Terminal EL2014 added |
| 4.0 | - First publication in PDF format - Structural update - Correction: EL2032 pin assignment, EL2042 pin assignment, EL2088 pin assignment |
| 3.5 | - "Technical data" section updated - "Assembly instructions with increased mechanical load capacity" section supplemented - Structural update |
| 3.4 | - *"Technical data" section updated |
| 3.3 | - Sections "EtherCAT state machine" and "Watchdog" updated |
| 3.2 | - Connection diagrams updated |
| 3.1 | - Firmware compatibility note amended |
| 3.0 | - UL note added |
| 2.9 | - EL2084, EL2088 added |
| 2.8 | - "Device description update" amended |
| 2.7 | - Trademark notes added |
| 2.6 | - Technical description amended, EL2042 amended |
| 2.5 | - Technical description amended, EL2024-0010 amended |
| 2.4 | - Technical description amended, EL2124 amended |
| 2.3 | - Technical description amended |
| 2.2 | - Technical data amended, watchdog documentation amended |
| 2.1 | - Terminals EL2022, EL2024, EL2034 added |
| 2.0 | - Terminals EL2002, EL2008 added, technical data amended |
| 1.0 | - Technical data amended |

| Version | Comment |
|---------|--|
| 0.1 | - Provisional documentation for EL20xx |

1.5 Version identification of EtherCAT devices

Designation

A Beckhoff EtherCAT device has a 14-digit designation, made up of

- family key
- type
- version
- revision

| Example | Family | Type | Version | Revision |
|------------------|--|--|-------------------------------|----------|
| EL3314-0000-0016 | EL terminal (12 mm, non-pluggable connection level) | 3314 (4-channel thermocouple terminal) | 0000 (basic type) | 0016 |
| ES3602-0010-0017 | ES terminal (12 mm, pluggable connection level) | 3602 (2-channel voltage measurement) | 0010 (high-precision version) | 0017 |
| CU2008-0000-0000 | CU device | 2008 (8-port fast ethernet switch) | 0000 (basic type) | 0000 |

Notes

- The elements mentioned above result in the **technical designation**. EL3314-0000-0016 is used in the example below.
- EL3314-0000 is the order identifier, in the case of “-0000” usually abbreviated to EL3314. “-0016” is the EtherCAT revision.
- The **order identifier** is made up of
 - family key (EL, EP, CU, ES, KL, CX, etc.)
 - type (3314)
 - version (-0000)
- The **revision** -0016 shows the technical progress, such as the extension of features with regard to the EtherCAT communication, and is managed by Beckhoff.
In principle, a device with a higher revision can replace a device with a lower revision, unless specified otherwise, e.g. in the documentation.
Associated and synonymous with each revision there is usually a description (ESI, EtherCAT Slave Information) in the form of an XML file, which is available for download from the Beckhoff web site.
From 2014/01 the revision is shown on the outside of the IP20 terminals, see Fig. “EL5021 EL terminal, standard IP20 IO device with batch number and revision ID (since 2014/01)”.
- The type, version and revision are read as decimal numbers, even if they are technically saved in hexadecimal.

Identification number

Beckhoff EtherCAT devices from the different lines have different kinds of identification numbers:

Production lot/batch number/serial number/date code/D number

The serial number for Beckhoff IO devices is usually the 8-digit number printed on the device or on a sticker. The serial number indicates the configuration in delivery state and therefore refers to a whole production batch, without distinguishing the individual modules of a batch.

Structure of the serial number: **KK YY FF HH**

KK - week of production (CW, calendar week)
YY - year of production
FF - firmware version
HH - hardware version

Example with

Ser. no.: 12063A02: 12 - production week 12 06 - production year 2006 3A - firmware version 3A 02 - hardware version 02

Examples of markings



Fig. 1: EL5021 EL terminal, standard IP20 IO device with serial/ batch number and revision ID (since 2014/01)



Fig. 2: EK1100 EtherCAT coupler, standard IP20 IO device with serial/ batch number



Fig. 3: EL3202-0020 with serial/ batch number 26131006 and unique ID-number 204418

1.5.1 Beckhoff Identification Code (BIC)

The Beckhoff Identification Code (BIC) is increasingly being applied to Beckhoff products to uniquely identify the product. The BIC is represented as a Data Matrix Code (DMC, code scheme ECC200), the content is based on the ANSI standard MH10.8.2-2016.




Fig. 4: BIC as data matrix code (DMC, code scheme ECC200)

The BIC will be introduced step by step across all product groups.

Depending on the product, it can be found in the following places:

- on the packaging unit
- directly on the product (if space suffices)
- on the packaging unit and the product

The BIC is machine-readable and contains information that can also be used by the customer for handling and product management.

Each piece of information can be uniquely identified using the so-called data identifier (ANSI MH10.8.2-2016). The data identifier is followed by a character string. Both together have a maximum length according to the table below. If the information is shorter, spaces are added to it. The data under positions 1 to 4 are always available.

The following information is contained:

| Item no. | Type of information | Explanation | Data identifier | Number of digits incl. data identifier | Example |
|----------|------------------------------------|---|-----------------|--|-------------------------|
| 1 | Beckhoff order number | Beckhoff order number | 1P | 8 | 1P 072222 |
| 2 | Beckhoff Traceability Number (BTN) | Unique serial number, see note below | S | 12 | S BTNk4p562d7 |
| 3 | Article description | Beckhoff article description, e.g. EL1008 | 1K | 32 | 1K EL1809 |
| 4 | Quantity | Quantity in packaging unit, e.g. 1, 10, etc. | Q | 6 | Q 1 |
| 5 | Batch number | Optional: Year and week of production | 2P | 14 | 2P 401503180016 |
| 6 | ID/serial number | Optional: Present-day serial number system, e.g. with safety products | 51S | 12 | 51S 678294104 |
| 7 | Variant number | Optional: Product variant number on the basis of standard products | 30P | 32 | 30P F971, 2*K183 |
| ... | | | | | |

Further types of information and data identifiers are used by Beckhoff and serve internal processes.

Structure of the BIC

Example of composite information from item 1 to 4 and 6. The data identifiers are marked in red for better display:

BTN

An important component of the BIC is the Beckhoff Traceability Number (BTN, item no. 2). The BTN is a unique serial number consisting of eight characters that will replace all other serial number systems at Beckhoff in the long term (e.g. batch designations on IO components, previous serial number range for safety products, etc.). The BTN will also be introduced step by step, so it may happen that the BTN is not yet coded in the BIC.

NOTE

This information has been carefully prepared. However, the procedure described is constantly being further developed. We reserve the right to revise and change procedures and documentation at any time and without prior notice. No claims for changes can be made from the information, illustrations and descriptions in this information.

1.6 Interference-free Bus Terminals



Use of interference-free Bus or EtherCAT Terminals in safety applications

If a Bus or EtherCAT Terminal is described as interference-free, this means that the consecutive terminal behaves passively in a safety application (e.g. in the case of the all-pole switch-off of a potential group).

In this case the terminals do not represent an active part of the safety controller and do not affect the Safety Integrity Level (SIL) or Performance Level (PL) attained in the safety application.

For details, please refer to chapter 2.17f in the [TwinSAFE application manual](#).

NOTE**Pay attention to the hardware version**

Please pay attention to the information about the hardware version and non-reactivity of the respective Bus Terminal in the chapters "Technical Data" or "Firmware Compatibility"!

Only terminals with the appropriate hardware version may be used without the attained SIL/PL being affected!

The Bus or EtherCAT Terminals regarded as interference-free at the time of preparing this document are listed in the following tables together with their respective hardware versions.

| Terminal name Bus Terminal | from hardware version |
|-------------------------------|-----------------------|
| KL2408 | 05 |
| KL2809 | 02 |
| KL2134 | 09 |
| KL2424 | 05 |
| KL9110 | 07 |

| Terminal name EtherCAT terminal | from hardware version |
|------------------------------------|-----------------------|
| EL2004 | 15 |
| EL2008 | 07 |
| EL2022 | 09 |
| EL2024 | 06 |
| EL2034 | 06 |
| EL2809 | 01 |
| EL2872 | 01 |
| EL2878-0005 | 00 |
| EL9110 | 13 |
| EL9410 | 16 |

External wiring

The following requirements are to be ensured *by the system manufacturer* and must be incorporated into the user documentation.

- **Protection class IP54**

The terminals must be installed in IP54 control cabinets to ensure the necessary protection class IP54.

- **Power supply unit**

The standard terminals must be supplied with 24 V by an SELV/PELV power supply unit with an output voltage limit U_{\max} of 60 V in the event of a fault.

- **Prevention of feedback**

Feedback can be prevented through different measures. These are described below. In addition to mandatory requirements there are also optional requirements, of which only one needs to be selected.

- **No switching of loads with a separate power supply**

Loads that have their own power supply must not be switched by standard terminals, since in this case feedback via the load cannot be ruled out.




Fig. 5: Negative example – active load

- The control of an STO input of a frequency converter could serve here as a **negative example**. **Exceptions** to the general requirement are allowed only if the manufacturer of the connected load guarantees that feedback to the control input cannot occur. This can be achieved, for example, through adherence to load-specific standards.
- **Option 1: Ground feedback and all-pole disconnection**
The ground connection of the connected load must be fed back to the safely switched ground of the respective output terminal.




Fig. 6: Ground connection of the load: correct (K1) and incorrect (K2)

- If either
 - a) the ground of the load is not fed back to the terminal or
 - b) the ground is not safely switched but connected permanently

then fault exclusions are necessary with regard to a short-circuit with external potential in order to be able to achieve Cat. 4 PLe according to EN ISO 13849-1:2007 or SIL3 according to IEC 61508:2010 (refer here to the overview in the chapter "Effect of options on the safety level").

- **Option 2: Cable short-circuit fault exclusion**

If solution option 1 is not feasible, the ground feedback and all-pole disconnection can be dispensed with if the danger of feedback due to a cable short-circuit can be excluded by other measures. These measures, which can be implemented alternatively, are described in the following sections.




Fig. 7: Short circuit fault exclusion through protected cable laying

- **a) Possibility 1: Load connection via separate sheathed cables**
The non-safely switched potential of the standard terminal may not be conducted together with other potential-conducting cores inside the same sheathed cable. (Fault exclusion, see EN ISO 13849-2:2013, Table D.4)
- **b) Possibility 2: Wiring only inside the control cabinet**
All loads connected to the non-safe standard terminals must be located in the same control cabinet as the terminals. The cables are routed entirely inside the control cabinet. (Fault exclusion, see EN ISO 13849-2:2013, Table D.4)
- **c) Possibility 3: Dedicated earth connection per conductor**
All conductors connected to the non-safe standard terminals are protected by their own earth connection. (Fault exclusion, see EN ISO 13849-2:2013, Table D.4)
- **d) Possibility 4: Cable permanently (fixed) installed and protected against external damage**
All conductors connected to the non-safe standard terminals are permanently fixed and, e.g. protected against external damage by a cable duct or armored pipe.
- **Effect of the options on the safety level**
In principle, standard terminals in safely switched potential groups are not an active part of the safety controller. Accordingly, **the safety level attained is defined only by the higher-level safety controller**, i.e. the standard terminals are not included in the calculation! However, the wiring of the standard terminals can lead to limitations in the maximum attainable safety level. Depending on the solution selected for the avoidance of feedback and the safety standard considered (see Option 1 and Option 2), different maximum attainable safety levels result, which are summarized in the following table:

Summary of safety classifications

| Feedback avoidance measures | DIN EN ISO 13849-1 | IEC 61508 | EN 62061 |
|--|--------------------|-----------|-------------|
| Fault exclusion | max. | max. SIL3 | max. SIL2 * |
| Cable short-circuit | Cat. 4 | | |
| Ground feedback and all-pole disconnection | PLe | | max. SIL3 |

2 Product overview, digital output terminals

2.1 EL2002, EL2004, EL2008 - Introduction




Fig. 8: EL2002, EL2004




Fig. 9: EL2008

Two-, four-, and eight-channel digital output terminals 24 V_{DC}, 0.5 A

The EL200x digital output terminals relay binary control signals of the automation device in an electrically isolated manner to the actuators of the process level. They are protected against reverse polarity at the power contacts. The digital output terminals of the EL200x series indicate their signal state through an LED for each channel.

⚠ CAUTION**Watchdog settings**

Please refer to section "[Notes for setting the watchdog \[► 66\]](#)".

2.1.1 EL2002, EL2004, EL2008 - Technical data

| Technical data | EL2002 | EL2004 | EL2008 |
|--|--|----------------------------|--|
| Number of outputs | 2 | 4 | 8 |
| Non-reactive outputs | - | yes (see notice [► 13]) | yes (see notice [► 13]) |
| Load type | ohmic, inductive, lamp load | | |
| Nominal output voltage | 24 V _{DC} (-15% / +20%) | | |
| Switching times | T _{ON} : 60 µs typ.; T _{OFF} : 300 µs typ. | | |
| Output current per channel | maximum 0.5 A (short-circuit proof) | | |
| Switch-off energy (inductive) | max. 150 mJ/channel | | |
| Current consumption from load voltage (power contacts) | typ. 15 mA | | |
| Supply voltage for electronic | via the E-Bus | | |
| Current consumption via E-bus | typ. 100 mA | typ. 100 mA | typ. 110 mA |
| Electrical isolation | 500 V (E-bus/field voltage) | | |
| Bit width in the process image | 2 output bits | 4 output bits | 8 output bits |
| Configuration | no address setting, configuration via TwinCAT System Manager | | |
| Weight | approx. 55 g | | |
| Permissible ambient temperature range during operation | -25°C ... +60°C (extended temperature range) | | Aligned in horizontal installation position: -25°C ... +60°C (extended temperature range) All other <u>installation positions</u> , see note [► 80]: -25°C ... +45°C |
| Permissible ambient temperature range during storage | -40°C ... +85°C | | |
| Permissible relative humidity | 95%, no condensation | | |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) | | |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 | | |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also <u>Installation instructions for terminals with increased mechanical load capacity</u> [► 78] | | |
| EMC resistance burst/ESD | conforms to EN 61000-6-2 / EN 61000-6-4 | | |
| Protection class | IP20 | | |
| Installation position | variable | variable | see note [► 80] |
| Approval | CE cULus [► 155] ATEX [► 86] | | |

2.1.2 EL2002 - LEDs and connection




Fig. 10: EL2002

EL2002 - LEDs

| LED | Color | Meaning |
|----------|-------|---|
| OUTPUT 1 | green | off |
| OUTPUT 2 | | on |
| | | No output signal |
| | | 24 V _{DC} output signal at the respective output |

EL2002 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| +24 V | 2 | +24 V (internally connected to terminal point 6 and positive power contact) |
| 0 V | 3 | Ground for output 1 (internally connected to terminal point 7 and negative power contact) |
| PE | 4 | PE (internally connected to terminal point 8) |
| Output 2 | 5 | Output 2 |
| +24 V | 6 | +24 V (internally connected to terminal point 2 and positive power contact) |
| 0 V | 7 | Ground for output 2 (internally connected to terminal point 3 and negative power contact) |
| PE | 8 | PE (internally connected to terminal point 4) |

2.1.3 EL2004 - LEDs and connection




Fig. 11: EL2004

EL2004 - LEDs

| LED | Color | Meaning | |
|-------------|-------|---------|---|
| OUTPUT 1- 4 | green | off | No output signal |
| | | on | 24 V _{DC} output signal at the respective output |

EL2004 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| 0 V | 2 | Ground for output 1 (internally connected to terminal point 3, 6, 7 and negative power contact) |
| 0 V | 3 | Ground for output 3 (internally connected to terminal point 2, 6, 7 and negative power contact) |
| Output 3 | 4 | Output 3 |
| Output 2 | 5 | Output 2 |
| 0 V | 6 | Ground for output 2 (internally connected to terminal point 2, 3, 7 and negative power contact) |
| 0 V | 7 | Ground for output 4 (internally connected to terminal point 2, 3, 6 and negative power contact) |
| Output 4 | 8 | Output 4 |

2.1.4 EL2008 - LEDs and connection




Fig. 12: EL2008

EL2008 - LEDs

| LED | Color | Meaning | |
|-------------|-------|---------|---|
| OUTPUT 1- 8 | green | off | No output signal |
| | | on | 24 V _{DC} output signal at the respective output |

EL2008 - Connection

| Terminal point | | Description |
|----------------|-----|-------------|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| Output 3 | 2 | Output 3 |
| Output 5 | 3 | Output 5 |
| Output 7 | 4 | Output 7 |
| Output 2 | 5 | Output 2 |
| Output 4 | 6 | Output 4 |
| Output 6 | 7 | Output 6 |
| Output 8 | 8 | Output 8 |

2.2 EL2014

2.2.1 EL2014 - Introduction




Fig. 13: EL2014

Four-channel digital output terminal, 24 V_{DC}, 0.5A, with diagnostics

The EL2014 digital output terminal connects the binary control signals from the automation device on to the actuators at the process level with electrical isolation. The EL2014 is protected against polarity reversal and processes load currents with outputs protected against overload and short-circuit. The integrated diagnosis can be evaluated in the controller and is indicated by the LEDs. Overtemperature and the lack of a voltage supply to the terminal are supplied as diagnostic information. Beyond that each channel can among other things signal a short circuit individually. The output behavior of the channels in the case of a bus error can be parameterized. The switching state and any error of the output are indicated by the LED. Maintenance of the application is simplified by the diagnosis. The power contacts are continuous; reference potential of the outputs is the 0 V power contact.

The outputs are fed via the 24 V power contact in the EL2014.

NOTE

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.2.2 EL2014 - Technical data

| Technical data | EL2014 |
|--|---|
| Connection technology | 1-wire |
| digital outputs | 4 |
| Rated load voltage | 24 V _{DC} (-15% / +20%) |
| Load type | ohmic, inductive, lamp load |
| Distributed clocks | No |
| Max. output current | 0.5 A (short-circuit-proof) per channel |
| Short circuit current | < 1 A typ. |
| Switch-off energy (inductive) | < 150 mJ/channel |
| Output stage | push (high-side switch) |
| Reverse voltage protection | Yes |
| Switching times | T _{ON} : 50 µs typ., T _{OFF} : 100 µs typ. |
| Supply voltage for electronic | Via the power contacts |
| Current consumption via E-bus | typ. 60 mA |
| Recommended cycle time | ≥ 200 µs; with cycle times < 200 µs the process data is not updated in each cycle. |
| Current consumption of power contacts | typ. 15 mA + load |
| Electrical isolation | 500 V (E-bus/field voltage) |
| Bit width in process image | 4-bit output and 20-bit diagnostics |
| Supports NoCoeStorage [► 72] function | Yes |
| Configuration | via System Manager |
| Conductor types | solid wire, stranded wire and ferrule |
| Special features | diagnostics via process data and LED: overtemperature, PowerFail, short circuit (per channel) |
| Weight | approx. 70 g |
| Permissible ambient temperature range during operation | 0 °C ... +55 °C |
| Permissible ambient temperature range during storage | -25 °C ... +85 °C |
| Permissible relative humidity | 95%, no condensation |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 |
| Vibration/shock resistance | conforms to EN 60068-2-6 / EN 60068-2-27 |
| EMC immunity/emission | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP20 |
| Installation position | variable |
| Approval | CE, IECEx |

2.2.3 EL2014 - LEDs and pin assignment




Fig. 14: EL2014

EL2014 - LEDs

| LED | Color | Meaning |
|-------------|-------------------------|---|
| OUTPUT 1- 4 | green | off No output signal |
| | | on Output signal 24 V |
| OUTPUT 1- 4 | red | on ERROR: Overcurrent / Overtemperature |
| | Flashing red | ERROR: Short circuit to 24V |
| OUTPUT 1- 4 | red / green alternating | ERROR: Open Load |

EL2014 - Pin assignment

| Terminal point | | Description |
|----------------|-----|---|
| Designation | No. | |
| Output 1 | 1 | Output 1 |
| 0 V | 2 | Ground for output 1 (internally connected to terminal point 3, 6, 7 and negative power contact) |
| 0 V | 3 | Ground for output 3 (internally connected to terminal point 2, 6, 7 and negative power contact) |
| Output 3 | 4 | Output 3 |
| Output 2 | 5 | Output 2 |
| 0 V | 6 | Ground for output 2 (internally connected to terminal point 2, 3, 7 and negative power contact) |
| 0 V | 7 | Ground for output 4 (internally connected to terminal point 2, 3, 6 and negative power contact) |
| Output 4 | 8 | Output 4 |

2.2.4 Overload protection



Technical data

Please note the information in the technical data regarding load type, max. output current and short circuit current.

When switching on lamp loads, high starting currents occur that are limited by the output circuit of the terminals (see fig. *Overload current limitation*).




Fig. 15: Overload current limitation




Fig. 16: Schematic illustration of the thermal switch-off in case of overload

In case of a long-term overload and/or short-circuit, the output is protected by the thermal switch-off of the channel.

The output circuit of the terminal limits the current. The terminal maintains this current until important self-heating of the channel occurs.

On exceeding the upper temperature limit, the terminal switches the channel off.

The channel is switched on again after it has cooled down to below the lower temperature limit.

The output signal is clocked until the output is switched off by the controller or the short-circuit is eliminated (see fig. *Schematic illustration of the thermal switch-off in case of overload*). The clock frequency depends on the ambient temperature and the load of the other terminal channels.

Short-circuit or prolonged overload on a channel leads to an increase in the device temperature. If several channels are overloaded, this leads to a rapid increase in the device temperature. The overloaded channels are switched off when the upper limit for the device temperature is exceeded. The channels are only switched on again if the temperature falls below the lower limit values for both the device and the channel. The non-overloaded channels continue operating properly.

When switching off inductive loads, high induction voltages result from interrupting the current too quickly. These are limited by an integrated free-wheeling diode (switch-off energy [inductive] see Technical data). Since the current reduces only slowly, a delayed switch-off can occur in many control applications. For example, a valve remains open for many milliseconds. Switch-off times are realized that correspond, for instance, to the switch-on time of the coil.

● Protection against high induction voltages

i To protect against voltage peaks such as can occur when switching inductive loads, we recommend to provide suitable protective circuits (e.g. with the free-wheeling diode, RC combination or varistor) directly at the actuator.




Fig. 17: Switch-off of inductive loads

2.2.5 Operating modes and settings

2.2.5.1 Process data

Parameterization

An EL2014 is parameterized via 2 tabs in the TwinCAT System Manager: the Process Data tab (A) for the communication-specific settings and the CoE directory (B) for the settings in the slave.




Fig. 18: EL2014 “Process Data” tab

- Changes to the process data-specific settings are generally only effective after a restart of the EtherCAT master:
Restart TwinCAT in RUN or CONFIG mode; RELOAD in CONFIG mode
- Changes to the online CoE directory
 - are in general immediately effective
 - are generally stored in non-volatile memory in the terminal/slave. They should be entered in the CoE StartUp list so that the settings are accepted after a replacement of the terminal. The CoE StartUp list is processed at each EtherCAT start and the settings are loaded into the slave.

Illustration of the process data and structural contents

The EL2014 provides three different process data for transmission:

- the diagnostics per channel “DIG Diag Inputs” (16-bit),
- the device diagnostics “DIG Inputs Device” (4-bit),
- The switching state of the outputs “DIG output” (4-bit)




Fig. 19: EL2014 Online illustration of the process data and structural contents in the System Manager

The plain text display of the bit meanings is particularly helpful not only in commissioning but also for linking to the PLC program.

By right-clicking on the Status variable in the configuration tree (A), the structure can be opened for linking (B).

Activation of the “Show Sub Variables” button (C) displays all subvariables and links to the PLC (D) in the online view.

“Predefined PDO Assignment” selection dialog (from TwinCAT 2.11 build 1544 onwards)

The process data to be transmitted (PDO, ProcessDataObjects) can be selected by the user

- for all TwinCAT versions via the “Predefined PDO Assignment” selection dialog (see fig. “EL2014 Process Data tab” A) or
- selectively for individual PDOs (see fig. “EL2014 Process Data tab” B)

. These changes become effective after activation and an EtherCAT restart or a reload.




Fig. 20: EL2014 “Process Data” tab

- A Selection of the diagnostic scope via the selection dialog “Predefined PDO Assignment”
- B Display of (optional) PDOs (process data objects)
- C Selection of the required Sync Manager
- D Display of the PDOs available for selection

Three pre-defined PDO assignments can be selected:

- **Full Diagnostics:**
Inputs: Selection of the PDOs 0x1A00 (diagnostics per channel) and 0x1A02 (device diagnostics). Both the diagnostic data for each channel and the data for the device diagnostics are displayed and transmitted.
Outputs: PDO 0x1600 (switching state of the outputs) is displayed and transmitted.
- **Compact Diagnostics:**
Inputs: Selection of the PDO 0x1A02 (device diagnostics). Only the diagnostic data for the device are displayed in the System Manager and transmitted to the control system.
Outputs: PDO 0x1600 (switching state of the outputs) is displayed and transmitted.
- **No Diagnostics:** Neither 0x1A00 nor 0x1A02 is selected. No diagnostic data are displayed in the System Manager and none are transmitted to the control system.
Outputs: PDO 0x1600 (switching state of the outputs) is displayed and transmitted.

● Compact Diagnostics, No Diagnostics

I When converting from “Full Diagnostics” to “Compact Diagnostics” or “No Diagnostics”, or when deactivating the PDO 0x1600, links already established to the deactivated objects are deleted.

2.2.5.2 Diagnostics per channel

Open Load (Index 0x60n1:02 [[▶ 37](#)])

The open load detection shows that no load is connected when the output is switched on.

The “open load” bit (index 0x60n1:02) is set to TRUE if the output is TRUE and the output current is less than typ. 0.2 mA.

Short Circuit to 24V (Index 0x60n1:04 [[▶ 37](#)])

A short circuit to 24 V is detected if the output is FALSE, but nevertheless a voltage of more than typ. 10 V is present. The “Short Circuit to 24V” bit (index 0x60n1:04) is set to TRUE. The corresponding LED flashes red.

Overtemperature (index: 0x60n1:01 [[▶ 37](#)]) – overcurrent (index: 0x60n1:03 [[▶ 37](#)])

The “Overcurrent” bit (index: 0x60n1:03) is set in case of an overload. The LED lights up red. The channel heats up, so that the “Overtemperature” bit (index: 0x60n1:01) is set on reaching an upper limit temperature (see fig. [Overload current limitation](#) [[▶ 28](#)]).

In the case of a short-circuit the channel overheats very quickly, leading to it being switched off. Once the temperature has cooled down to below a lower limit value following the switch-off, the output is switched on again. The temperature, however, is then still so high that the “Overtemperature” bit (index: 0x60n1:01) remains set. Thus the LED remains red as long as the short-circuit is present.

Overcurrent diagnostics is no longer possible once the output is switched off. The “Overcurrent” bit (index: 0x60n1:03) is only set to TRUE when the output is switched on again (see fig. [Schematic illustration of the thermal switch-off in case of overload](#) [[▶ 28](#)]).

2.2.5.3 Device diagnostics

General error (index 0xF600:11 [[▶ 37](#)])

If the “Common Fault” bit (index 0xF600:11) is set, there is an error on one or more channels.

It is thus possible in the “Compact Diagnostics” process mode to determine that errors have occurred on one or more channels.

Device overtemperature (index 0xF600:12 [[▶ 37](#)])

The device temperature rises due to an overload, a short-circuit or excessively high ambient temperature. If the device temperature exceeds the upper limit value, the overloaded channels are switched off. The “Overtemperature Device” bit (index 0xF600:12) is set. All other channels continue to operate properly.

If the device temperature falls below the lower limit value the “Overtemperature Device” bit (index 0xF600:12) is reset. If the channel temperature also falls below the lower limit value, the respective channels are switched on again.

Undervoltage (index 0xF600:13 [[▶ 37](#)])

If the “Undervoltage” bit (index 0xF600:13) is set, the supply voltage of the terminal has fallen below typically 17 V.

Voltage loss (index 0xF600:14 [[▶ 37](#)])

If the error bit in “Missing Voltage” (index 0xF600:14) is set, the supply voltage of the terminal has fallen below typically 14 V.

2.2.5.4 Settings via the CoE directory

CoE online directory

| Index | Name | Flags | Value |
|---------|-----------------------------|-------|--------|
| 100A | Software version | RO | |
| 1011:0 | Restore default parameters | RO | > 1 < |
| 1018:0 | Identity | RO | > 4 < |
| 10F0:0 | Backup parameter handling | RO | > 1 < |
| 1600:0 | DIG RxPDO-Map Outputs | RO | > 5 < |
| 1A00:0 | DIG TxPDO-Map Diag Inputs | RO | > 16 < |
| 1A02:0 | DIG TxPDO-Map Inputs Device | RO | > 5 < |
| 1C00:0 | Sync manager type | RO | > 4 < |
| 1C12:0 | RxPDO assign | RW | > 1 < |
| 1C13:0 | TxPDO assign | RW | > 2 < |
| 1C32:0 | SM output parameter | RO | > 32 < |
| 1C33:0 | SM input parameter | RO | > 32 < |
| 6001:0 | DIG Diag Inputs Ch.1 | RO | > 4 < |
| 6001:01 | Overtemperature | RO P | FALSE |
| 6001:02 | Open Load | RO P | FALSE |
| 6001:03 | Overcurrent | RO P | FALSE |
| 6001:04 | Short Circuit to 24V | RO P | FALSE |
| 6011:0 | DIG Diag Inputs Ch.2 | RO | > 4 < |
| 6021:0 | DIG Diag Inputs Ch.3 | RO | > 4 < |
| 6031:0 | DIG Diag Inputs Ch.4 | RO | > 4 < |
| 7000:0 | DIG Outputs Ch.1 | RO | > 1 < |
| 7000:01 | Output | RO P | FALSE |
| 7010:0 | DIG Outputs Ch.2 | RO | > 1 < |
| 7020:0 | DIG Outputs Ch.3 | RO | > 1 < |
| 7030:0 | DIG Outputs Ch.4 | RO | > 1 < |
| 8000:0 | DIG Safe State Active Ch.1 | RW | > 1 < |
| 8000:01 | Active | RW | TRUE |
| 8001:0 | DIG Safe State Value Ch.1 | RW | > 1 < |
| 8001:01 | Value | RW | FALSE |
| 8010:0 | DIG Safe State Active Ch.2 | RW | > 1 < |
| 8011:0 | DIG Safe State Value Ch.2 | RW | > 1 < |

Fig. 21: EL2014 CoE directory

The online data are accessible (A) if the terminal is online, i.e. connected to the EtherCAT Master TwinCAT and in an error-free RUN state (WorkingCounter = 0). The entries "DIG Safe State Active Ch.n" (index 0x80n0) (D) and "DIG Safe State Value Ch.n" (index 0x80n1) (E) can be changed online; please also observe the [Notes on the CoE interface](#) [► 71] and on the [StartUp-List](#) [► 72].

The diagnostic data of the channels can be read under "DIG Diag Inputs Ch.n" (index 0x60n1) (B).

The diagnostic data of the terminal can be read under "DIG Inputs Device" (index 0xF600).

The state of the outputs can be read under "DIG Outputs Ch.n" (index 0x70n0) (C).

The display in TwinCAT is continuously updated if (F) has been activated.

DIG Safe State Active (index 0x80n0:01 [► 36]) / DIG Safe State Value (index 0x80n1:01 [► 36])

The setting in “DIG Safe State Active” (index 0x80n0:01) defines whether the outputs should assume a safe state in the case of a bus error. The safe state of the output in the case of a bus error is defined with “DIG Safe State Value” (index 0x80n1:01).

1. **“DIG Safe State Active” = TRUE and**
 - **“DIG Safe State Value” = TRUE:** the output is switched on.
2. **“DIG Safe State Active” = TRUE and**
 - **“DIG Safe State Value” = FALSE:** the output is switched off
3. **“DIG Safe State Active” = FALSE**
 - The state of the output is retained. Entries in “DIG Safe State Value” (index 0x80n1:01) have no effect.


Flow-chart illustration of the sequence in case of a bus error

Fig. 22: Change of state of the outputs in the case of a bus error

Tabular example:

| DIG Safe State Active Index 0x80n0:01 | DIG Safe State Value Index 0x80n1:01 | Output before bus error | Output during bus error | Output after bus error |
|---------------------------------------|--------------------------------------|-------------------------|-------------------------|------------------------|
| TRUE | TRUE | FALSE | TRUE | FALSE |
| | | TRUE | TRUE | TRUE |
| TRUE | FALSE | FALSE | FALSE | FALSE |
| | | TRUE | FALSE | TRUE |
| FALSE | FALSE / TRUE | FALSE | FALSE | FALSE |
| | | TRUE | TRUE | TRUE |

Graphical example:

- a) Safe State Active = TRUE, Safe State Value = TRUE
- b) Safe State Active = TRUE, Safe State Value = FALSE
- c) Safe State Active = FALSE, Safe State Value = TRUE




Fig. 23: Graphical illustration of the channel state during a bus error

2.2.6 Object description and parameterization

● EtherCAT XML Device Description

i The display matches that of the CoE objects from the EtherCAT XML Device Description. We recommend downloading the latest XML file from the [download area of the Beckhoff website](#) and installing it according to installation instructions.

● Parameterization

i The terminal is parameterized via the CoE Online tab (double-click on the respective object), or the PDOs are allocated via the Process Data tab.

Introduction

The CoE overview contains objects for different intended applications:

2.2.6.1 Restore object

Index 1011 Restore default parameters

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|--|---|-----------|-------|--------------------------------|
| 1011:0 | Restore default parameters [► 168] | Restore default parameters | UINT8 | RO | 0x01 (1 _{dec}) |
| 1011:01 | SubIndex 001 | If this object is set to " 0x64616F6C " in the set value dialog, all backup objects are reset to their delivery state. | UINT32 | RW | 0x00000000 (0 _{dec}) |

2.2.6.2 Configuration data

Index 80n0 DIG Safe State Active Ch.n

(n=0 for Ch.1 to n=3 for Ch.4)

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------------------------|---|-----------|-------|--------------------------|
| 80n0:0 | DIG Safe State Active Ch.n | Maximum subindex | UINT8 | RO | 0x01 (1 _{dec}) |
| 80n0:01 | Active [► 34] | Enabling of the output state defined in index 0x80n1:01 in case of a bus error 0: output retains its current state. 1: output is switched to the state defined in index 0x80n1. | BOOLEAN | RW | 0x01 (1 _{dec}) |

Index 80n1 DIG Safe State Value Ch.n

(n=0 for Ch.1 to n=3 for Ch.4)

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|------------------------------|--|-----------|-------|--------------------------|
| 80n1:0 | DIG Safe State Value Ch.n | Maximum subindex | UINT8 | RO | 0x01 (1 _{dec}) |
| 80n1:01 | Value [► 34] | Defines the state of the output in case of a bus error: 0: output off 1: output on | BOOLEAN | RW | 0x00 (0 _{dec}) |

2.2.6.3 Command object

Index FB00 DIG Command

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------|------------------|-------------------|-------|--------------------------|
| FB00:0 | DIG Command | Maximum subindex | UINT8 | RO | 0x03 (3 _{dec}) |
| FB00:01 | Request | reserved | OCTET - STRING[2] | RW | {0} |
| FB00:02 | Status | reserved | UINT8 | RO | 0x00 (0 _{dec}) |
| FB00:03 | Response | reserved | OCTET - STRING[4] | RO | {0} |

2.2.6.4 Input data

Index 60n1 DIG Diag Inputs

(n=0 for Ch.1 to n=3 for Ch.4)

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|---------------------------------------|---|-----------|-------|--------------------------|
| 60n1:0 | DIG Diag Inputs Ch.n | Maximum subindex | UINT8 | RO | 0x04 (4 _{dec}) |
| 60n1:01 | <u>Overtemperature</u> [► 32] | The overtemperature bit is set if the max. permissible temperature of the channel is exceeded. | BOOLEAN | RO | 0x00 (0 _{dec}) |
| 60n1:02 | <u>Open Load</u> [► 32] | Wire break detection The Open Load bit is set if the channel is switched on and the load current is ≤ typically 0.2 mA. | BOOLEAN | RO | 0x00 (0 _{dec}) |
| 60n1:03 | <u>Overcurrent</u> [► 32] | Overcurrent and short-circuit detection The overcurrent bit is set if an overload is detected when the channel is switched on. No overload can be detected if the channel is switched off (e.g. thermal switch-off). Short-circuit current detection: typ. 1 A | BOOLEAN | RO | 0x00 (0 _{dec}) |
| 60n1:04 | <u>Short Circuit to 24V</u> [► 32] | The Short Circuit to 24V bit is set if voltage is present when the channel is switched off. | BOOLEAN | RO | 0x00 (0 _{dec}) |

Index F600 DIG Inputs Device

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|--|--|-----------|-------|---------------------------|
| F600:0 | DIG Inputs Device | Maximum subindex | UINT8 | RO | 0x14 (20 _{dec}) |
| F600:11 | <u>Common Fault</u> [► 32] | The Common Fault bit is set if an error occurs on one or more channels of the terminal. | BOOLEAN | RO | 0x00 (0 _{dec}) |
| F600:12 | <u>Overtemperature De-</u> <u>vice</u> [► 32] | The Overtemperature Device bit is set if the max. permissible device temperature is exceeded. The overloaded channels are switched off until the device temperature cools down below the lower limit value again. | BOOLEAN | RO | 0x00 (0 _{dec}) |
| F600:13 | <u>Undervoltage</u> [► 32] | The Undervoltage bit is set if the terminal supply voltage falls below typically 17 V. | BOOLEAN | RO | 0x00 (0 _{dec}) |
| F600:14 | <u>Missing Voltage</u> [► 32] | The Missing Voltage bit is set if the supply voltage is lower than typically 14 V. | BOOLEAN | RO | 0x00 (0 _{dec}) |

2.2.6.5 Output data

Index 70n0 DIG Outputs

(n=0 for Ch.1 to n=3 for Ch.4)

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|------------------|--|-----------|-------|--------------------------|
| 70n0:0 | DIG Outputs Ch.n | Maximum subindex | UINT8 | RO | 0x01 (1 _{dec}) |
| 70n0:01 | Output | Status Output 0: Output off 1: Output on | BOOLEAN | RO | 0x00 (0 _{dec}) |

2.2.6.6 Standard objects

Standard objects (1000-1FFF)

Index 1000 Device type

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------|---|-----------|-------|--|
| 1000:0 | Device type | Device type of the EtherCAT slave: the Lo-Word contains the CoE profile used (5001). The Hi-Word contains the module profile according to the modular device profile. | UINT32 | RO | 0x01181389 (18355081 _{dec}) |

Index 1008 Device name

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------|-----------------------------------|-----------|-------|---------------|
| 1008:0 | Device name | Device name of the EtherCAT slave | STRING | RO | EL2014 |

Index 1009 Hardware version

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|------------------|--|-----------|-------|---------------|
| 1009:0 | Hardware version | Hardware version of the EtherCAT slave | STRING | RO | |

Index 100A Software version

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|------------------|--|-----------|-------|---------------|
| 100A:0 | Software version | Firmware version of the EtherCAT slave | STRING | RO | 01 |

Index 1018 Identity

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|---------------|---|-----------|-------|--|
| 1018:0 | Identity | Information for identifying the slave | UINT8 | RO | 0x04 (4 _{dec}) |
| 1018:01 | Vendor ID | Vendor ID of the EtherCAT slave | UINT32 | RO | 0x00000002 (2 _{dec}) |
| 1018:02 | Product code | Product code of the EtherCAT slave | UINT32 | RO | 0x07DE3052 (132001874 _{dec}) |
| 1018:03 | Revision | Revision number of the EtherCAT slave; the low word (bit 0-15) indicates the special terminal number, the high word (bit 16-31) refers to the device description | UINT32 | RO | 0x00000000 (0 _{dec}) |
| 1018:04 | Serial number | Serial number of the EtherCAT slave; the low byte (bit 0-7) of the low word contains the year of production, the high byte (bit 8-15) of the low word contains the week of production, the high word (bit 16-31) is 0 | UINT32 | RO | 0x00000000 (0 _{dec}) |

Index 10F0 Backup parameter handling

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|---------------------------|---|-----------|-------|--------------------------------|
| 10F0:0 | Backup parameter handling | Information for standardized loading and saving of backup entries | UINT8 | RO | 0x01 (1 _{dec}) |
| 10F0:01 | Checksum | Checksum across all backup entries of the EtherCAT slave | UINT32 | RO | 0x00000000 (0 _{dec}) |

Index 1600 DIG RxPDO-Map Outputs

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-----------------------|---|-----------|-------|--------------------------|
| 1600:0 | DIG RxPDO-Map Outputs | PDO Mapping RxPDO 1 | UINT8 | RO | 0x05 (5 _{dec}) |
| 1600:01 | SubIndex 001 | 1. PDO Mapping entry (object 0x7000 (DIG Outputs Ch.01), entry 0x01 (Output)) | UINT32 | RO | 0x7000:01, 1 |
| 1600:02 | SubIndex 002 | 2. PDO Mapping entry (object 0x7010 (DIG Outputs Ch.02), entry 0x01 (Output)) | UINT32 | RO | 0x7010:01, 1 |
| 1600:03 | SubIndex 003 | 3. PDO Mapping entry (object 0x7020 (DIG Outputs Ch.03), entry 0x01 (Output)) | UINT32 | RO | 0x7020:01, 1 |
| 1600:04 | SubIndex 004 | 4. PDO Mapping entry (object 0x7030 (DIG Outputs Ch.04), entry 0x01 (Output)) | UINT32 | RO | 0x7030:01, 1 |
| 1600:05 | SubIndex 005 | 5. PDO Mapping entry (4 bits align) | UINT32 | RO | 0x0000:00, 4 |

Index 1A00 DIG TxPDO-Map Diag Inputs

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|---------------------------|---|-----------|-------|---------------------------|
| 1A00:0 | DIG TxPDO-Map Diag Inputs | PDO Mapping TxPDO 1 | UINT8 | RO | 0x10 (16 _{dec}) |
| 1A00:01 | SubIndex 001 | 1. PDO Mapping entry (object 0x6001 (DIG Inputs Ch.01), entry 0x01 (Overtemperature)) | UINT32 | RO | 0x6001:01, 1 |
| 1A00:02 | SubIndex 002 | 2. PDO Mapping entry (object 0x6001 (DIG Inputs Ch.01), entry 0x02 (Wire Break)) | UINT32 | RO | 0x6001:02, 1 |
| 1A00:03 | SubIndex 003 | 3. PDO Mapping entry (object 0x6001 (DIG Inputs Ch.01), entry 0x03 (Overcurrent)) | UINT32 | RO | 0x6001:03, 1 |
| 1A00:04 | SubIndex 004 | 4. PDO Mapping entry (object 0x6001 (DIG Inputs Ch.01), entry 0x04 (Short Circuit)) | UINT32 | RO | 0x6001:04, 1 |
| 1A00:05 | SubIndex 005 | 5. PDO Mapping entry (object 0x6011 (DIG Inputs Ch.02), entry 0x01 (Overtemperature)) | UINT32 | RO | 0x6011:01, 1 |
| 1A00:06 | SubIndex 006 | 6. PDO Mapping entry (object 0x6011 (DIG Inputs Ch.02), entry 0x02 (Wire Break)) | UINT32 | RO | 0x6011:02, 1 |
| 1A00:07 | SubIndex 007 | 7. PDO Mapping entry (object 0x6011 (DIG Inputs Ch.02), entry 0x03 (Overcurrent)) | UINT32 | RO | 0x6011:03, 1 |
| 1A00:08 | SubIndex 008 | 8. PDO Mapping entry (object 0x6011 (DIG Inputs Ch.02), entry 0x04 (Short Circuit)) | UINT32 | RO | 0x6011:04, 1 |
| 1A00:09 | SubIndex 009 | 9. PDO Mapping entry (object 0x6021 (DIG Diag Inputs Ch.3), entry 0x01 (Overtemperature)) | UINT32 | RO | 0x6021:01, 1 |
| 1A00:0A | SubIndex 010 | 10. PDO Mapping entry (object 0x6021 (DIG Diag Inputs Ch.3), entry 0x02 (Open Load)) | UINT32 | RO | 0x6021:02, 1 |
| 1A00:0B | SubIndex 011 | 11. PDO Mapping entry (object 0x6021 (DIG Diag Inputs Ch.3), entry 0x03 (Overcurrent)) | UINT32 | RO | 0x6021:03, 1 |
| 1A00:0C | SubIndex 012 | 12. PDO Mapping entry (object 0x6021 (DIG Diag Inputs Ch.3), entry 0x04 (Short Circuit to 24V)) | UINT32 | RO | 0x6021:04, 1 |
| 1A00:0D | SubIndex 013 | 13. PDO Mapping entry (object 0x6031 (DIG Diag Inputs Ch.4), entry 0x01 (Overtemperature)) | UINT32 | RO | 0x6031:01, 1 |
| 1A00:0E | SubIndex 014 | 14. PDO Mapping entry (object 0x6031 (DIG Diag Inputs Ch.4), entry 0x02 (Open Load)) | UINT32 | RO | 0x6031:02, 1 |
| 1A00:0F | SubIndex 015 | 15. PDO Mapping entry (object 0x6031 (DIG Diag Inputs Ch.4), entry 0x03 (Overcurrent)) | UINT32 | RO | 0x6031:03, 1 |
| 1A00:10 | SubIndex 016 | 16. PDO Mapping entry (object 0x6031 (DIG Diag Inputs Ch.4), entry 0x04 (Short Circuit to 24V)) | UINT32 | RO | 0x6031:04, 1 |

Index 1A02 DIG TxPDO-Map Inputs Device

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-----------------------------|---|-----------|-------|--------------------------|
| 1A02:0 | DIG TxPDO-Map Inputs Device | PDO Mapping TxPDO | UINT8 | RO | 0x05 (5 _{dec}) |
| 1A02:01 | SubIndex 001 | 1. PDO Mapping entry (object 0xF600 (DIG Inputs Device), entry 0x11 (Common Fault)) | UINT32 | RO | 0xF600:11, 1 |
| 1A02:02 | SubIndex 002 | 2. PDO Mapping entry (object 0xF600 (DIG Inputs Device), entry 0x12 (Overtemperature Device)) | UINT32 | RO | 0xF600:12, 1 |
| 1A02:03 | SubIndex 003 | 3. PDO Mapping entry (object 0xF600 (DIG Inputs Device), entry 0x13 (Undervoltage)) | UINT32 | RO | 0xF600:13, 1 |
| 1A02:04 | SubIndex 004 | 4. PDO Mapping entry (object 0xF600 (DIG Inputs Device), entry 0x14 (Missing Voltage)) | UINT32 | RO | 0xF600:14, 1 |
| 1A02:05 | SubIndex 005 | 5. PDO Mapping entry (4 bits align) | UINT32 | RO | 0x0000:00, 4 |

Index 1C00 Sync manager type

| Index (hex) | Name | Meaning | Data type | Flags | Default |
|-------------|-------------------|---|-----------|-------|--------------------------|
| 1C00:0 | Sync manager type | Using the sync managers | UINT8 | RO | 0x04 (4 _{dec}) |
| 1C00:01 | SubIndex 001 | Sync-Manager Type Channel 1: Mailbox Write | UINT8 | RO | 0x01 (1 _{dec}) |
| 1C00:02 | SubIndex 002 | Sync-Manager Type Channel 2: Mailbox Read | UINT8 | RO | 0x02 (2 _{dec}) |
| 1C00:03 | SubIndex 003 | Sync-Manager Type Channel 3: Process Data Write (Outputs) | UINT8 | RO | 0x03 (3 _{dec}) |
| 1C00:04 | SubIndex 004 | Sync-Manager Type Channel 4: Process Data Read (Inputs) | UINT8 | RO | 0x04 (4 _{dec}) |

Index 1C12 RxPDO assign

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|--------------|--|-----------|-------|-------------------------------|
| 1C12:0 | RxPDO assign | PDO Assign Outputs | UINT8 | RW | 0x01 (1 _{dec}) |
| 1C32:01 | SubIndex 001 | 1. allocated RxPDO (contains the index of the associated RxPDO mapping object) | UINT16 | RW | 0x1600 (5632 _{dec}) |
| 1C12:02 | Subindex 002 | | UINT16 | RW | |
| 1C12:03 | Subindex 003 | | UINT16 | RW | |
| 1C12:04 | Subindex 004 | | UINT16 | RW | |

Index 1C13 TxPDO assign

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|--------------|--|-----------|-------|-------------------------------|
| 1C13:0 | TxPDO assign | PDO Assign Inputs | UINT8 | RW | 0x02 (2 _{dec}) |
| 1C13:01 | SubIndex 001 | 1. allocated TxPDO (contains the index of the associated TxPDO mapping object) | UINT16 | RW | 0x1A00 (6656 _{dec}) |
| 1C13:02 | Subindex 002 | 2. allocated TxPDO (contains the index of the associated TxPDO mapping object) | UINT16 | RW | 0x1A02 (6658 _{dec}) |
| 1C13:03 | Subindex 003 | | UINT16 | RW | |
| 1C13:04 | Subindex 004 | | UINT16 | RW | |
| 1C13:05 | Subindex 005 | | UINT16 | RW | |
| 1C32:06 | Subindex 006 | | UINT16 | RW | |
| 1C13:07 | Subindex 007 | | UINT16 | RW | |
| 1C13:08 | Subindex 008 | | UINT16 | RW | |
| 1C13:09 | Subindex 009 | | UINT16 | RW | |
| 1C13:0A | Subindex 010 | | UINT16 | RW | |

Index 1C32 SM output parameter

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------------------|--|-----------|-------|--------------------------------------|
| 1C32:0 | SM output parameter | Synchronization parameters for the outputs | UINT8 | RO | 0x20 (32 _{dec}) |
| 1C32:01 | Sync mode | Current synchronization mode: <ul style="list-style-type: none"> 0: Free Run 1: Synchronous with SM 2 event | UINT16 | RW | 0x0001 (1 _{dec}) |
| 1C32:02 | Cycle time | Cycle time (in ns): <ul style="list-style-type: none"> Free Run: Cycle time of the local timer Synchronous with SM 2 event: Master cycle time DC-Mode: SYNC0/SYNC1 Cycle Time | UINT32 | RW | 0x000F4240 (1000000 _{dec}) |
| 1C32:03 | Shift time | Time between SYNC0 event and output of the outputs (in ns, DC mode only) | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C32:04 | Sync modes supported | Supported synchronization modes: <ul style="list-style-type: none"> Bit 0 = 1: free run is supported Bit 1 = 1: Synchronous with SM 2 event is supported Bit 2-3 = 01: DC mode is supported Bit 4-5=10: Output shift with SYNC1 event (only DC mode) Bit 14 = 1: dynamic times (measurement by writing 0x1C32:08 [► 41]) (for revision no.: 17 – 25) | UINT16 | RO | 0x8002 (32770 _{dec}) |
| 1C32:05 | Minimum cycle time | Minimum cycle time (in ns) Default: 10 ms | UINT32 | RO | 0x00002710 (10000 _{dec}) |
| 1C32:06 | Calc and copy time | Minimum time between SYNC0 and SYNC1 event (in ns, DC mode only) | UINT32 | RO | 0x00000000 (0 _{dec}) |
| 1C32:07 | Minimum delay time | | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C32:08 | Command | <ul style="list-style-type: none"> 0: Measurement of the local cycle time is stopped 1: Measurement of the local cycle time is started <p>The entries 0x1C32:03 [► 41], 0x1C32:05 [► 41], 0x1C32:06 [► 41], 0x1C32:09 [► 41], 0x1C33:03 [► 42], 0x1C33:06 [► 41], 0x1C33:09 [► 42] are updated with the maximum measured values. For a subsequent measurement the measured values are reset.</p> | UINT16 | RW | 0x0000 (0 _{dec}) |
| 1C32:09 | Maximum Delay time | Time between SYNC1 event and output of the outputs (in ns, DC mode only) | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C32:0B | SM event missed counter | Number of missed SM events in OPERATIONAL (DC mode only) | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C32:0C | Cycle exceeded counter | Number of occasions the cycle time was exceeded in OPERATIONAL (cycle was not completed in time or the next cycle began too early) | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C32:0D | Shift too short counter | Number of occasions that the interval between SYNC0 and SYNC1 event was too short (DC mode only) | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C32:20 | Sync error | The synchronization was not correct in the last cycle (outputs were output too late; DC mode only) | BOOLEAN | RO | 0x00 (0 _{dec}) |

Index 1C33 SM input parameter

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-------------------------|---|-----------|-------|--------------------------------------|
| 1C33:0 | SM input parameter | Synchronization parameters for the inputs | UINT8 | RO | 0x20 (32 _{dec}) |
| 1C33:01 | Sync mode | Current synchronization mode: <ul style="list-style-type: none"> 0: Free Run 1: Synchronous with SM 3 event (no outputs available) 2: DC - Synchronous with SYNC0 Event 3: DC - Synchronous with SYNC1 Event 34: Synchronous with SM 2 event (outputs available) | UINT16 | RW | 0x0022 (34 _{dec}) |
| 1C33:02 | Cycle time | as 0x1C32:02 [► 41] | UINT32 | RW | 0x000F4240 (1000000 _{dec}) |
| 1C33:03 | Shift time | Time between SYNC0 event and reading of the inputs (in ns, only DC mode) | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C33:04 | Sync modes supported | Supported synchronization modes: <ul style="list-style-type: none"> Bit 0 = 1: free run is supported Bit 1 = 1: synchronous with SM 2 event is supported (outputs available) Bit 1 = 1: synchronous with SM 3 event is supported (no outputs available) Bit 2-3 = 01: DC mode is supported Bit 4-5 = 01: input shift through local event (outputs available) Bit 4-5 = 10: input shift with SYNC1 event (no outputs available) Bit 14 = 1: dynamic times (measurement by writing 0x1C32:08 [► 41]) (for revision no.: 17 – 25) | UINT16 | RO | 0x8002 (32770 _{dec}) |
| 1C33:05 | Minimum cycle time | as 0x1C32:05 [► 41] | UINT32 | RO | 0x00002710 (10000 _{dec}) |
| 1C33:06 | Calc and copy time | Time between reading of the inputs and availability of the inputs for the master (in ns, only DC mode) | UINT32 | RO | 0x00000000 (0 _{dec}) |
| 1C33:07 | Minimum delay time | | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C33:08 | Command | as 0x1C32:08 [► 41] | UINT16 | RW | 0x0000 (0 _{dec}) |
| 1C33:09 | Maximum Delay time | Time between SYNC1 event and reading of the inputs (in ns, only DC mode) | UINT32 | RO | 0x00000384 (900 _{dec}) |
| 1C33:0B | SM event missed counter | as 0x1C32:11 [► 41] | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C33:0C | Cycle exceeded counter | as 0x1C32:12 [► 41] | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C33:0D | Shift too short counter | as 0x1C32:13 [► 41] | UINT16 | RO | 0x0000 (0 _{dec}) |
| 1C33:20 | Sync error | as 0x1C32:32 [► 41] | BOOLEAN | RO | 0x00 (0 _{dec}) |

Index F000 Modular device profile

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|---------------------------|---|-----------|-------|-----------------------------|
| F000:0 | Modular device profile | General information for the modular device profile | UINT8 | RO | 0x02 (2 _{dec}) |
| F000:01 | Module index distance | Index spacing of the objects of the individual channels | UINT16 | RO | 0x0010 (16 _{dec}) |
| F000:02 | Maximum number of modules | Number of channels | UINT16 | RO | 0x0004 (4 _{dec}) |

Index F008 Code word

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|-----------|--|-----------|-------|--------------------------------|
| F008:0 | Code word | <p><u>NoCoeStorage</u> function:</p> <p>The input code of the code word 0x12345678 activates the <u>NoCoeStorage</u> function:</p> <p>Changes to the CoE directory are not saved if the function is active. The function is deactivated by:</p> <p>1.) changing the code word or</p> <p>2.) restarting the terminal.</p> | UINT32 | RW | 0x00000000 (0 _{dec}) |

Index F010 Module list

| Index (hex) | Name | Meaning | Data type | Flags | Default value |
|-------------|--------------|---|-----------|-------|----------------------------------|
| F010:0 | Module list | Maximum subindex | UINT8 | RW | 0x04 (4 _{dec}) |
| F010:01 | SubIndex 001 | Profil 280 (Extended Digital Input and Output with Diagnostics) | UINT32 | RW | 0x00000118 (280 _{dec}) |
| F010:02 | SubIndex 002 | Profil 280 (Extended Digital Input and Output with Diagnostics) | UINT32 | RW | 0x00000118 (280 _{dec}) |
| F010:03 | SubIndex 003 | Profil 280 (Extended Digital Input and Output with Diagnostics) | UINT32 | RW | 0x00000118 (280 _{dec}) |
| F010:04 | SubIndex 004 | Profil 280 (Extended Digital Input and Output with Diagnostics) | UINT32 | RW | 0x00000118 (280 _{dec}) |

2.3 EL2022, EL2024, EL2024-0010 - Introduction




Fig. 24: EL2022




Fig. 25: EL2024, EL2024-0010

Two- and four-channel digital output terminals, 24 V_{DC}, 2 A (EL2022, EL2024)

The EL2022 and EL2024 digital output terminals connect the binary control signals from the automation device on to the actuators at the process level with electrical isolation. These devices feature short-circuit protection of the outputs. Two channels (EL2022) or four channels (EL2024) are available, which indicate their signal state via LEDs. The EL2024 enables direct connection of four 2-wire actuators. It features four earth connecting points.

The EL2024-0010 is a version with 12 V_{DC} output.

⚠ CAUTION

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.3.1 EL2022, EL2024, EL2024-0010 - Technical data

| Technical data | EL2022 | EL2024 | EL2024-0010 |
|--|---|--|--|
| Number of outputs | 2 | 4 | |
| Non-reactive outputs | - | yes (see notice [p. 13]) | - |
| Reverse voltage protection | yes | | |
| Load type | ohmic, inductive, lamp load | | |
| Nominal output voltage | 24 V _{DC} (-15% / +20%) | | 12 V _{DC} (-15% / +20%) |
| Switching times | T _{ON} : 40 µs typ.; T _{OFF} : 200 µs typ. | | |
| Output current max. per channel | max. 2 A (short-circuit-proof) | | |
| Switch-off energy (inductive) | < 1,7 J/channel | | |
| Current consumption from load voltage | typ. 9 mA + load | typ. 13 mA + load | |
| Supply voltage for electronic | via the E-Bus | | |
| Current consumption via E-bus | typ. 100 mA | typ. 120 mA | |
| Electrical isolation | 500 V (E-bus/field voltage) | | |
| Bit width in the process image | 2 output bits | 4 output bits | |
| Configuration | no address setting, configuration via TwinCAT System Manager | | |
| Weight | approx. 55 g | | |
| Permissible ambient temperature range during operation | -25°C ... +60°C (extended temperature range)** | | 0°C ... + 55°C* |
| Permissible ambient temperature range during storage | -40°C ... +85°C | | -25°C ... + 85°C |
| Permissible relative humidity | 95%, no condensation | | |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) | | |
| Mounting [p. 76] | on 35 mm mounting rail conforms to EN 60715 | | |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for terminals with increased mechanical load capacity [p. 78] | | |
| EMC resistance burst/ESD | conforms to EN 61000-6-2 / EN 61000-6-4 | | |
| Protection class | IP20 | | |
| Installation position | variable | | |
| Approval | CE cULus [p. 155] ATEX [p. 86] IECEX | CE cULus [p. 155] ATEX [p. 86] | CE cULus [p. 155] ATEX [p. 85] |

2.3.2 EL2022 - LEDs and connection




Fig. 26: EL2022

EL2022 - LEDs

| LED | Color | Meaning | |
|----------------------|-------|---------|--|
| OUTPUT 1 OUTPUT 2 | green | off | No output signal is present. |
| | | on | A 24 V _{DC} output signal is present. |

EL2022 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| +24 V | 2 | +24 V (internally connected to terminal point 6 and positive power contact) |
| 0 V | 3 | Ground for output 1 (internally connected to terminal point 7 and negative power contact) |
| PE | 4 | PE contact (internally connected to terminal point 8 and PE power contact) |
| Output 2 | 5 | Output 2 |
| +24 V | 6 | +24 V (internally connected to terminal point 2 and positive power contact) |
| 0 V | 7 | Ground for output 2 (internally connected to terminal point 3 and negative power contact) |
| PE | 8 | PE contact (internally connected to terminal point 4 and PE power contact) |

2.3.3 EL2024, EL2024-0010 - LEDs and connection




Fig. 27: EL2024, EL2024-0010

EL2024, EL2024-0010 - LEDs

| LED | Color | Meaning |
|-------------|-------|---|
| OUTPUT 1- 4 | green | off No output signal is present. |
| | | on A 24 V _{DC} output signal (EL2024) or 12 V _{DC} output signal (EL2024-0010) is present |

EL2024, EL2024-0010 - Connection

NOTE

12 V DC at the power contacts of the EL2024-0010

During configuration of the Bus Terminal block, please note that the power contacts of the EL2024-0010 carry a voltage of 12 V_{DC} (provided e.g. by an EL9512 power supply terminal).
If 24 V terminals are to operate in the terminal block simultaneously, measures must be implemented for electrical isolation (e.g. through the EL9190 power feed terminal or the EL9080 separation terminal).

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| 0 V | 2 | Ground for output 1 (internally connected to terminal point 3, 6, 7 and negative power contact) |
| 0 V | 3 | Ground for output 3 (internally connected to terminal point 2, 6, 7 and negative power contact) |
| Output 3 | 4 | Output 3 |
| Output 2 | 5 | Output 2 |
| 0 V | 6 | Ground for output 2 (internally connected to terminal point 2, 3, 7 and negative power contact) |
| 0 V | 7 | Ground for output 4 (internally connected to terminal point 2, 3, 6 and negative power contact) |
| Output 4 | 8 | Output 4 |

2.3.4 EL2022, EL2024, EL2024-0010 - Switching off inductive loads

When switching off inductive loads, high induction voltages result from interrupting the current quickly. These induction voltages can cause energy to be fed back into the terminal. If the regenerated energy is larger than the switch-off energy (inductive) specified in the technical data, the terminal may be destroyed.



Protection against high induction voltages

To protect against voltage peaks such as can occur when switching inductive loads, we recommend to provide suitable protective circuits (e.g. with the free-wheeling diode, RC combination or varistor) directly at the actuator.

2.4 EL2032, EL2034 - Introduction




Fig. 28: EL2032, EL2034

Two- and four-channel digital output terminals with diagnostics, 24 V_{DC}, 2 A

The EL2032 and EL2034 digital output terminals connect the binary 24 V control signals electrically isolated with the actuators. Two channels or four channels are available, which indicate their signal state via LEDs. The direct connection of wire-wire actuators is possible. The EL2032 enables direct connection of two 3-wire actuators.

The EL2032 and EL2034 include additional diagnostic LEDs and input bits, which indicate short circuit and broken wire. Broken wire is reported, if the output current is less than the limit value when the output is connected. The limit value is typically between 2 and 900 mA. The application of the "broken wire detection" function therefore makes sense for regular output currents of approx. 1 A or higher.

⚠ CAUTION

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.4.1 EL2032, EL2034 - Technical data

| Technical data | EL2032 | EL2034 |
|--|--|--|
| Number of outputs | 2 | 4 |
| Reverse voltage protection | yes | |
| Load type | ohmic, inductive, lamp load | |
| Rated voltage of the outputs | 24 V _{DC} (-15% / +20%) | |
| Switching times | T _{ON} : 40 µs typ.; T _{OFF} : 200 µs typ. | |
| Output current max. per channel | max. 2 A (short-circuit-proof) | |
| Short circuit and open circuit detection | yes; open circuit detection [► 49] from approx. 1 A regular output current | |
| Switch-off energy (inductive) | < 1,7 J/channel | |
| Current consumption from load voltage | typ. 12 mA + load | typ. 14 mA + load |
| Supply voltage for electronic | via E-Bus | |
| Current consumption via E-bus | typ. 100 mA | typ. 120 mA |
| Electrical isolation | 500 V (E-bus/field voltage) | |
| Bit width in the process image | 2 output bits, 2 input bits (diagnostic) | 4 output bits, 4 input bits (diagnostic) |
| Configuration | no address setting, configuration via TwinCAT System Manager | |
| Weight | approx. 55 g | |
| Permissible ambient temperature range during operation | -25°C ... +60°C (extended temperature range) | |
| Permissible ambient temperature range during storage | -40°C ... +85°C | |
| Permissible relative humidity | 95%, no condensation | |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) | |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 | |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for terminals with increased mechanical load capacity [► 78] | |
| EMC resistance burst/ESD | conforms to EN 61000-6-2 / EN 61000-6-4 | |
| Protection class | IP20 | |
| Installation position | variable | |
| Approval | CE cULus [► 155] ATEX [► 86] | |

2.4.2 EL2032 - LEDs and connection




Fig. 29: EL2032

EL2032 - LEDs

| LED | Color | Meaning |
|----------|-------|---|
| OUTPUT 1 | green | off |
| OUTPUT 2 | | on |
| ERROR 1 | red | Fault indication in the event of interruption or overload of the output voltage |
| ERROR 2 | | |

EL2032 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| +24 V | 2 | +24 V (internally connected to terminal point 6 and positive power contact) |
| 0 V | 3 | Ground for output 1 (internally connected to terminal point 7 and negative power contact) |
| PE | 4 | PE contact (internally connected to terminal point 8 and PE power contact) |
| Output 2 | 5 | Output 2 |
| +24 V | 6 | +24 V (internally connected to terminal point 2 and positive power contact) |
| 0 V | 7 | Ground for output 2 (internally connected to terminal point 3 and negative power contact) |
| PE | 8 | PE contact (internally connected to terminal point 4 and PE power contact) |

2.4.3 EL2034 - LEDs and connection




Fig. 30: EL2034

LEDs

| LED | Color | Meaning | |
|-------------|-------|---|--|
| OUTPUT 1- 4 | green | off | No output signal is present. |
| | | on | A 24 V _{DC} output signal is present. |
| ERROR 1 - 4 | red | Fault indication in the event of interruption or overload of the output voltage | |

EL2034 pin assignment

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| 0 V | 2 | Ground for output 1 (internally connected to terminal point 3, 6, 7 and negative power contact) |
| 0 V | 3 | Ground for output 3 (internally connected to terminal point 2, 6, 7 and negative power contact) |
| Output 3 | 4 | Output 3 |
| Output 2 | 5 | Output 2 |
| 0 V | 6 | Ground for output 2 (internally connected to terminal point 2, 3, 7 and negative power contact) |
| 0 V | 7 | Ground for output 4 (internally connected to terminal point 2, 3, 6 and negative power contact) |
| Output 4 | 8 | Output 4 |

2.4.4 EL2032, EL2034 - Switching off inductive loads

When switching off inductive loads, high induction voltages result from interrupting the current quickly. These induction voltages can cause energy to be fed back into the terminal. If the regenerated energy is larger than the switch-off energy (inductive) specified in the technical data, the terminal may be destroyed.



Protection against high induction voltages

To protect against voltage peaks such as can occur when switching inductive loads, we recommend to provide suitable protective circuits (e.g. with the free-wheeling diode, RC combination or varistor) directly at the actuator.

2.5 EL2042 - Introduction




Fig. 31: EL2042

Two-channel digital output terminals, 24 V_{DC}, 2 x 4 A/1 x 8 A

The EL2042 digital output terminals connect the binary 24 V control signals electrically isolated with the actuators. Two channels are available in each case, which indicate their signal state via LEDs. The EL2042 enables connection of loads with current consumption up to 8 A if the outputs are connected in parallel.

⚠ CAUTION

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.5.1 EL2042 - Technical data

| Technical data | EL2042 |
|--|--|
| Number of outputs | 2 |
| Reverse voltage protection | yes |
| Load type | ohmic, inductive, lamp load |
| Nominal output voltage | 24 V _{DC} (-15% / +20%) |
| Switching times | T _{ON} : 40 µs typ.; T _{OFF} : 200 µs typ. |
| Switch-off energy (inductive) | < 1.7 J / channel |
| Output current max. per channel | max. 4 A (short-circuit-proof) per channel, 8 A with parallel connection |
| Supply voltage for electronic | via the E-Bus |
| Current consumption of power contacts | typ. 13 mA + load |
| Current consumption via E-bus | typ. 120 mA |
| Electrical isolation | 500 V (E-bus/field voltage) |
| Bit width in the process image | 2 output bits |
| Configuration | no address setting, configuration via TwinCAT System Manager |
| Weight | approx. 55 g |
| Permissible ambient temperature range during operation | 0°C ... + 55°C |
| Permissible ambient temperature range during storage | -25°C ... + 85°C |
| Permissible relative humidity | 95%, no condensation |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for terminals with increased mechanical load capacity [► 78] |
| EMC resistance burst/ESD | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP20 |
| Installation position | variable |
| Approval | CE |

2.5.2 EL2042 - LEDs and connection




Fig. 32: EL2042

EL2042 - LEDs

| LED | Color | Meaning | |
|----------|-------|---------|--|
| OUTPUT 1 | green | off | No output signal is present. |
| OUTPUT 2 | | on | A 24 V _{DC} output signal is present. |

EL2042 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| +24 V | 2 | +24 V (internally connected to terminal point 6 and positive power contact) |
| 0 V | 3 | Ground for output 1 (internally connected to terminal point 7 and negative power contact) |
| - | 4 | - |
| Output 2 | 5 | Output 2 |
| +24 V | 6 | +24 V (internally connected to terminal point 2 and positive power contact) |
| 0 V | 7 | Ground for output 2 (internally connected to terminal point 3 and negative power contact) |
| - | 8 | - |

2.5.3 EL2042 - Switching off inductive loads

When switching off inductive loads, high induction voltages result from interrupting the current quickly. These induction voltages can cause energy to be fed back into the terminal. If the regenerated energy is larger than the switch-off energy (inductive) specified in the technical data, the terminal may be destroyed.



Protection against high induction voltages

To protect against voltage peaks such as can occur when switching inductive loads, we recommend to provide suitable protective circuits (e.g. with the free-wheeling diode, RC combination or varistor) directly at the actuator.

2.6 EL2084, EL2088 - Introduction




Fig. 33: EL2084, EL2088

Four- and eight-channel digital output terminals, 24 V_{DC}, 0.5 A (EL2084, EL2088)

The EL2084 and EL2088 digital output terminals connect the binary control signals from the automation unit on to the actuators at the process level with electrical isolation.

The EtherCAT Terminals have 0 V (ground) switching outputs and generate load currents with outputs that are resistant to overload and short-circuit. They include four or eight channels, whose signal state is indicated by LEDs.

⚠ CAUTION

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.6.1 EL2084, EL2088 - Technical data

| Technical data | EL2084 | EL2088 |
|--|--|---|
| Number of outputs | 4 | 8 |
| Load type | ohmic, inductive, lamp load | |
| Nominal voltage of the outputs | 24 V _{DC} (-15% / +20%) | |
| Output current max. per channel | max. 0.5 A (short-circuit-proof) | max. 0.5 A (total current 3 A) |
| Current consumption from load voltage | typ. 30 mA + load | |
| Supply voltage for electronic | via the E-Bus | |
| Current consumption via E-bus | typ. 100 mA | typ. 110 mA |
| Electrical isolation | 500 V (E-bus/field voltage) | |
| Bit width in the process image | 4 output bits | 8 output bits |
| Configuration | no address setting, configuration via TwinCAT System Manager | |
| Weight | approx. 70 g | |
| Permissible ambient temperature range during operation | 0°C ... + 55°C | 0°C ... + 55°C (aligned in horizontal installation position) 0°C ... + 45°C (all other installation positions, see Note [► 80]) |
| Permissible ambient temperature range during storage | -25°C ... + 85°C | |
| Permissible relative humidity | 95%, no condensation | |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) | |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 | |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for terminals with increased mechanical load capacity [► 78] | |
| EMC resistance burst/ESD | conforms to EN 61000-6-2 / EN 61000-6-4 | |
| Protection class | IP20 | |
| Installation position | variable | see note [► 80] |
| Approval | CE cULus [► 155] ATEX [► 85] | |

2.6.2 EL2084 - LEDs and connection




Fig. 34: EL2084

EL2084 - LEDs

| LED | Color | Meaning | |
|-------------|-------|---------|---|
| OUTPUT 1- 4 | green | off | No output signal is present at the respective output |
| | | on | A 0 V output signal is present at the respective output |

EL2084 - Connection

| Terminal point | | Description |
|----------------|-----|---|
| Name | No. | |
| Output 1 | 1 | Output 1 (0 V) |
| 24 V | 2 | +24 V for output 1 (internally connected to terminal points 3, 6, 7 and positive power contact) |
| 24 V | 3 | +24 V for output 3 (internally connected to terminal points 2, 6, 7 and positive power contact) |
| Output 3 | 4 | Output 3 (0 V) |
| Output 2 | 5 | Output 2 (0 V) |
| 24 V | 6 | +24 V for output 2 (internally connected to terminal points 2, 3, 7 and positive power contact) |
| 24 V | 7 | +24 V for output 4 (internally connected to terminal points 2, 3, 6 and positive power contact) |
| Output 4 | 8 | Output 4 (0 V) |

2.6.3 EL2088 - LEDs and connection




Fig. 35: EL2088

EL2088 - LEDs

| LED | Color | Meaning | |
|-------------|-------|---------|---|
| OUTPUT 1- 8 | green | off | No output signal is present at the respective output |
| | | on | A 0 V output signal is present at the respective output |

EL2088 - Connection

| Terminal point | | Description |
|----------------|-----|----------------|
| Name | No. | |
| Output 1 | 1 | Output 1 (0 V) |
| Output 3 | 2 | Output 3 (0 V) |
| Output 5 | 3 | Output 5 (0 V) |
| Output 7 | 4 | Output 7 (0 V) |
| Output 2 | 5 | Output 2 (0 V) |
| Output 4 | 6 | Output 4 (0 V) |
| Output 6 | 7 | Output 6 (0 V) |
| Output 8 | 8 | Output 8 (0 V) |

2.7 EL2124 - Introduction




Fig. 36: EL2124

Four-channel digital output terminal 5 V_{DC}, CMOS output

The digital output terminal EL2124 connects the binary control signals of the automation device in an electrically isolated manner to the actuators at the process level and generates load currents with outputs that are protected against overload and short-circuit. The EtherCAT Terminal contains four channels whose signal state is indicated by LEDs.

⚠ CAUTION

Watchdog settings

Please refer to section "Notes for setting the watchdog [► 66]".

2.7.1 EL2124 - Technical data

| Technical data | EL2124 |
|--|--|
| Number of outputs | 4 |
| Load type | ohmic, lamp load |
| Nominal output voltage | 5 V _{DC} (CMOS output) |
| Switching times | T _{ON} : < 1 µs typ.; T _{OFF} : < 1 µs typ. |
| Output current max. per channel | ±20 mA (short-circuit-proof) per channel, 8 mA signal current, type CMOS output |
| Supply voltage for electronic | via the E-Bus |
| Current consumption via E-bus | typ. 130 mA |
| Current consumption from load voltage (power contacts) | typ. 12 mA + load |
| Electrical isolation | 500 V (E-bus/field voltage) |
| Bit width in the process image | 4 output bits |
| Configuration | no address setting, configuration via TwinCAT System Manager |
| Weight | approx. 70 g |
| Permissible ambient temperature range during operation | 0°C ... + 55°C |
| Permissible ambient temperature range during storage | -25°C ... + 85°C |
| Permissible relative humidity | 95%, no condensation |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) |
| Mounting [► 76] | on 35 mm mounting rail conforms to EN 60715 |
| Vibration/shock resistance | according to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for terminals with increased mechanical load capacity [► 78] |
| EMC immunity/emission | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP 20 |
| Installation position | variable |
| Approval | CE cULus [► 155] ATEX [► 85] |

2.7.2 EL2124 - LEDs and connection




Fig. 37: EL2124

LEDs

| LED | Color | Meaning | |
|-------------|-------|---------|--|
| OUTPUT 1- 4 | green | off | No output signal |
| | | on | 5 V _{DC} output signal at the respective output |

EL2124 - Connection

NOTE

5 V DC at the power contacts

During configuration of the Bus Terminal block, please note that the power contacts of the EL2124 carry a voltage of 5 V_{DC} (provided e.g. by an EL9505 power supply terminal).

If 24 V terminals are to operate in the terminal block simultaneously, measures must be implemented for electrical isolation (e.g. through the EL9190 power feed terminal or the EL9080 separation terminal).

| Terminal point | | Description |
|----------------|-----|--|
| Name | No. | |
| Output 1 | 1 | Output 1 |
| +5 V | 2 | +5 V (internally connected to terminal point 6 and positive power contact) |
| 0 V | 3 | 0 V (internally connected to terminal point 7 and negative power contact) |
| Output 3 | 4 | Output 3 |
| Output 2 | 5 | Output 2 |
| +5 V | 6 | +5 V (internally connected to terminal point 2 and positive power contact) |
| 0 V | 7 | 0 V (internally connected to terminal point 3 and negative power contact) |
| Output 4 | 8 | Output 4 |

3 Basics communication

3.1 EtherCAT basics

Please refer to the [EtherCAT System Documentation](#) for the EtherCAT fieldbus basics.

3.2 EtherCAT cabling – wire-bound

The cable length between two EtherCAT devices must not exceed 100 m. This results from the FastEthernet technology, which, above all for reasons of signal attenuation over the length of the cable, allows a maximum link length of 5 + 90 + 5 m if cables with appropriate properties are used. See also the [Design recommendations for the infrastructure for EtherCAT/Ethernet](#).

Cables and connectors

For connecting EtherCAT devices only Ethernet connections (cables + plugs) that meet the requirements of at least category 5 (Cat5) according to EN 50173 or ISO/IEC 11801 should be used. EtherCAT uses 4 wires for signal transfer.

EtherCAT uses RJ45 plug connectors, for example. The pin assignment is compatible with the Ethernet standard (ISO/IEC 8802-3).

| Pin | Color of conductor | Signal | Description |
|-----|--------------------|--------|---------------------|
| 1 | yellow | TD + | Transmission Data + |
| 2 | orange | TD - | Transmission Data - |
| 3 | white | RD + | Receiver Data + |
| 6 | blue | RD - | Receiver Data - |

Due to automatic cable detection (auto-crossing) symmetric (1:1) or cross-over cables can be used between EtherCAT devices from Beckhoff.




Recommended cables

Suitable cables for the connection of EtherCAT devices can be found on the [Beckhoff website!](#)

E-Bus supply

A bus coupler can supply the EL terminals added to it with the E-bus system voltage of 5 V; a coupler is thereby loadable up to 2 A as a rule (see details in respective device documentation). Information on how much current each EL terminal requires from the E-bus supply is available online and in the catalogue. If the added terminals require more current than the coupler can supply, then power feed terminals (e.g. [EL9410](#)) must be inserted at appropriate places in the terminal strand.

The pre-calculated theoretical maximum E-Bus current is displayed in the TwinCAT System Manager. A shortfall is marked by a negative total amount and an exclamation mark; a power feed terminal is to be placed before such a position.



| Number | Box Name | Add... | Type | In Si... | Out ... | E-Bus (mA) |
|--------|----------------------|--------|-------------|----------|---------|------------|
| 1 | Term 1 (EK1100) | 1001 | EK1100 | | | |
| 2 | Term 2 (EL2008) | 1002 | EL2008 | | 1.0 | 1890 |
| 3 | Term 3 (EL2008) | 1003 | EL2008 | | 1.0 | 1780 |
| 4 | Term 4 (EL2008) | 1004 | EL2008 | | 1.0 | 1670 |
| 5 | Term 5 (EL6740-0010) | 1005 | EL6740-0010 | 2.0 | 2.0 | 1220 |
| 6 | Term 6 (EL6740-0010) | 1006 | EL6740-0010 | 2.0 | 2.0 | 770 |
| 7 | Term 7 (EL6740-0010) | 1007 | EL6740-0010 | 2.0 | 2.0 | 320 |
| 8 | Term 8 (EL6740-0010) | 1008 | EL6740-0010 | 2.0 | 2.0 | -130 I |
| 9 | Term 9 (EL6740-0010) | 1009 | EL6740-0010 | 2.0 | 2.0 | -580 I |

Fig. 38: System manager current calculation

NOTE**Malfunction possible!**

The same ground potential must be used for the E-Bus supply of all EtherCAT terminals in a terminal block!

3.3 General notes for setting the watchdog

ELxxxx terminals are equipped with a safety feature (watchdog) that switches off the outputs after a specifiable time e.g. in the event of an interruption of the process data traffic, depending on the device and settings, e.g. in OFF state.

The EtherCAT slave controller (ESC) in the EL2xxx terminals features 2 watchdogs:

- SM watchdog (default: 100 ms)
- PDI watchdog (default: 100 ms)

SM watchdog (SyncManager Watchdog)

The SyncManager watchdog is reset after each successful EtherCAT process data communication with the terminal. If no EtherCAT process data communication takes place with the terminal for longer than the set and activated SM watchdog time, e.g. in the event of a line interruption, the watchdog is triggered and the outputs are set to FALSE. The OP state of the terminal is unaffected. The watchdog is only reset after a successful EtherCAT process data access. Set the monitoring time as described below.

The SyncManager watchdog monitors correct and timely process data communication with the ESC from the EtherCAT side.

PDI watchdog (Process Data Watchdog)

If no PDI communication with the EtherCAT slave controller (ESC) takes place for longer than the set and activated PDI watchdog time, this watchdog is triggered.

PDI (Process Data Interface) is the internal interface between the ESC and local processors in the EtherCAT slave, for example. The PDI watchdog can be used to monitor this communication for failure.

The PDI watchdog monitors correct and timely process data communication with the ESC from the application side.

The settings of the SM- and PDI-watchdog must be done for each slave separately in the TwinCAT System Manager.




Fig. 39: EtherCAT tab -> Advanced Settings -> Behavior -> Watchdog

Notes:

- the multiplier is valid for both watchdogs.
- each watchdog has its own timer setting, the outcome of this in summary with the multiplier is a resulting time.
- Important: the multiplier/timer setting is only loaded into the slave at the start up, if the checkbox is activated.
If the checkbox is not activated, nothing is downloaded and the ESC settings remain unchanged.

Multiplier

Multiplier

Both watchdogs receive their pulses from the local terminal cycle, divided by the watchdog multiplier:

$$1/25 \text{ MHz} * (\text{watchdog multiplier} + 2) = 100 \text{ } \mu\text{s} \text{ (for default setting of 2498 for the multiplier)}$$

The standard setting of 1000 for the SM watchdog corresponds to a release time of 100 ms.

The value in multiplier + 2 corresponds to the number of basic 40 ns ticks representing a watchdog tick. The multiplier can be modified in order to adjust the watchdog time over a larger range.

Example "Set SM watchdog"

This checkbox enables manual setting of the watchdog times. If the outputs are set and the EtherCAT communication is interrupted, the SM watchdog is triggered after the set time and the outputs are erased. This setting can be used for adapting a terminal to a slower EtherCAT master or long cycle times. The default SM watchdog setting is 100 ms. The setting range is 0...65535. Together with a multiplier with a range of 1...65535 this covers a watchdog period between 0...~170 seconds.

Calculation

Multiplier = 2498 → watchdog base time = $1 / 25 \text{ MHz} * (2498 + 2) = 0.0001 \text{ seconds} = 100 \mu\text{s}$
SM watchdog = 10000 → $10000 * 100 \mu\text{s} = 1 \text{ second watchdog monitoring time}$

CAUTION

Undefined state possible!

The function for switching off of the SM watchdog via SM watchdog = 0 is only implemented in terminals from version -0016. In previous versions this operating mode should not be used.

CAUTION

Damage of devices and undefined state possible!

If the SM watchdog is activated and a value of 0 is entered the watchdog switches off completely. This is the deactivation of the watchdog! Set outputs are NOT set in a safe state, if the communication is interrupted.

3.4 EtherCAT State Machine

The state of the EtherCAT slave is controlled via the EtherCAT State Machine (ESM). Depending upon the state, different functions are accessible or executable in the EtherCAT slave. Specific commands must be sent by the EtherCAT master to the device in each state, particularly during the bootup of the slave.

A distinction is made between the following states:

- Init
- Pre-Operational
- Safe-Operational and
- Operational
- Boot

The regular state of each EtherCAT slave after bootup is the OP state.




Fig. 40: States of the EtherCAT State Machine

Init

After switch-on the EtherCAT slave in the *Init* state. No mailbox or process data communication is possible. The EtherCAT master initializes sync manager channels 0 and 1 for mailbox communication.

Pre-Operational (Pre-Op)

During the transition between *Init* and *Pre-Op* the EtherCAT slave checks whether the mailbox was initialized correctly.

In *Pre-Op* state mailbox communication is possible, but not process data communication. The EtherCAT master initializes the sync manager channels for process data (from sync manager channel 2), the FMMU channels and, if the slave supports configurable mapping, PDO mapping or the sync manager PDO assignment. In this state the settings for the process data transfer and perhaps terminal-specific parameters that may differ from the default settings are also transferred.

Safe-Operational (Safe-Op)

During transition between *Pre-Op* and *Safe-Op* the EtherCAT slave checks whether the sync manager channels for process data communication and, if required, the distributed clocks settings are correct. Before it acknowledges the change of state, the EtherCAT slave copies current input data into the associated DP-RAM areas of the EtherCAT slave controller (ECSC).

In *Safe-Op* state mailbox and process data communication is possible, although the slave keeps its outputs in a safe state, while the input data are updated cyclically.

● Outputs in SAFEOP state

i The default set `watchdog` [► 66] monitoring sets the outputs of the module in a safe state - depending on the settings in `SAFEOP` and `OP` - e.g. in OFF state. If this is prevented by deactivation of the watchdog monitoring in the module, the outputs can be switched or set also in the `SAFEOP` state.

Operational (Op)

Before the EtherCAT master switches the EtherCAT slave from *Safe-Op* to *Op* it must transfer valid output data.

In the *Op* state the slave copies the output data of the masters to its outputs. Process data and mailbox communication is possible.

Boot

In the *Boot* state the slave firmware can be updated. The *Boot* state can only be reached via the *Init* state.

In the *Boot* state mailbox communication via the *file access over EtherCAT* (FoE) protocol is possible, but no other mailbox communication and no process data communication.

3.5 CoE Interface

General description

The CoE interface (CAN application protocol over EtherCAT)) is used for parameter management of EtherCAT devices. EtherCAT slaves or the EtherCAT master manage fixed (read only) or variable parameters which they require for operation, diagnostics or commissioning.

CoE parameters are arranged in a table hierarchy. In principle, the user has read access via the fieldbus. The EtherCAT master (TwinCAT System Manager) can access the local CoE lists of the slaves via EtherCAT in read or write mode, depending on the attributes.

Different CoE parameter types are possible, including string (text), integer numbers, Boolean values or larger byte fields. They can be used to describe a wide range of features. Examples of such parameters include manufacturer ID, serial number, process data settings, device name, calibration values for analog measurement or passwords.

The order is specified in 2 levels via hexadecimal numbering: (main)index, followed by subindex. The value ranges are

- Index: 0x0000 ...0xFFFF (0...65535_{dez})
- SubIndex: 0x00...0xFF (0...255_{dez})

A parameter localized in this way is normally written as 0x8010:07, with preceding "x" to identify the hexadecimal numerical range and a colon between index and subindex.

The relevant ranges for EtherCAT fieldbus users are:

- 0x1000: This is where fixed identity information for the device is stored, including name, manufacturer, serial number etc., plus information about the current and available process data configurations.
- 0x8000: This is where the operational and functional parameters for all channels are stored, such as filter settings or output frequency.

Other important ranges are:

- 0x4000: here are the channel parameters for some EtherCAT devices. Historically, this was the first parameter area before the 0x8000 area was introduced. EtherCAT devices that were previously equipped with parameters in 0x4000 and changed to 0x8000 support both ranges for compatibility reasons and mirror internally.
- 0x6000: Input PDOs ("input" from the perspective of the EtherCAT master)
- 0x7000: Output PDOs ("output" from the perspective of the EtherCAT master)



Availability

Not every EtherCAT device must have a CoE list. Simple I/O modules without dedicated processor usually have no variable parameters and therefore no CoE list.

If a device has a CoE list, it is shown in the TwinCAT System Manager as a separate tab with a listing of the elements:

| General EtherCAT Process Data Startup CoE - Online Online | | | |
|---|----------------------------|--------------------------------------|---|
| Update List | | <input type="checkbox"/> Auto Update | <input checked="" type="checkbox"/> Single Update <input checked="" type="checkbox"/> Show Offline Data |
| Advanced... | | | |
| Add to Startup... | | Offline Data | Module OD (AoE Port): 0 |
| Index | Name | Flags | Value |
| 1000 | Device type | RO | 0x00FA1389 (16389001) |
| 1008 | Device name | RO | EL2502-0000 |
| 1009 | Hardware version | RO | |
| 100A | Software version | RO | |
| + 1011:0 | Restore default parameters | RO | > 1 < |
| - 1018:0 | Identity | RO | > 4 < |
| 1018:01 | Vendor ID | RO | 0x00000002 (2) |
| 1018:02 | Product code | RO | 0x09C63052 (163983442) |
| 1018:03 | Revision | RO | 0x00130000 (1245184) |
| 1018:04 | Serial number | RO | 0x00000000 (0) |
| + 10F0:0 | Backup parameter handling | RO | > 1 < |
| + 1400:0 | PWM RxPDO-Par Ch.1 | RO | > 6 < |
| + 1401:0 | PWM RxPDO-Par Ch.2 | RO | > 6 < |
| + 1402:0 | PWM RxPDO-Par h.1 Ch.1 | RO | > 6 < |
| + 1403:0 | PWM RxPDO-Par h.1 Ch.2 | RO | > 6 < |
| + 1600:0 | PWM RxPDO-Map Ch.1 | RO | > 1 < |

Fig. 41: "CoE Online" tab

The figure above shows the CoE objects available in device "EL2502", ranging from 0x1000 to 0x1600. The subindices for 0x1018 are expanded.

Data management and function "NoCoeStorage"

Some parameters, particularly the setting parameters of the slave, are configurable and writeable. This can be done in write or read mode

- via the System Manager (Fig. "CoE Online" tab) by clicking
This is useful for commissioning of the system/slaves. Click on the row of the index to be parameterised and enter a value in the "SetValue" dialog.
- from the control system/PLC via ADS, e.g. through blocks from the TcEtherCAT.lib library
This is recommended for modifications while the system is running or if no System Manager or operating staff are available.

● Data management

i If slave CoE parameters are modified online, Beckhoff devices store any changes in a fail-safe manner in the EEPROM, i.e. the modified CoE parameters are still available after a restart. The situation may be different with other manufacturers.

An EEPROM is subject to a limited lifetime with respect to write operations. From typically 100,000 write operations onwards it can no longer be guaranteed that new (changed) data are reliably saved or are still readable. This is irrelevant for normal commissioning. However, if CoE parameters are continuously changed via ADS at machine runtime, it is quite possible for the lifetime limit to be reached. Support for the NoCoeStorage function, which suppresses the saving of changed CoE values, depends on the firmware version.

Please refer to the technical data in this documentation as to whether this applies to the respective device.

- If the function is supported: the function is activated by entering the code word 0x12345678 once in CoE 0xF008 and remains active as long as the code word is not changed. After switching the device on it is then inactive. Changed CoE values are not saved in the EEPROM and can thus be changed any number of times.
- Function is not supported: continuous changing of CoE values is not permissible in view of the lifetime limit.

i Startup list

Changes in the local CoE list of the terminal are lost if the terminal is replaced. If a terminal is replaced with a new Beckhoff terminal, it will have the default settings. It is therefore advisable to link all changes in the CoE list of an EtherCAT slave with the Startup list of the slave, which is processed whenever the EtherCAT fieldbus is started. In this way a replacement EtherCAT slave can automatically be parameterized with the specifications of the user.

If EtherCAT slaves are used which are unable to store local CoE values permanently, the Startup list must be used.

Recommended approach for manual modification of CoE parameters

- Make the required change in the System Manager
The values are stored locally in the EtherCAT slave
- If the value is to be stored permanently, enter it in the Startup list.
The order of the Startup entries is usually irrelevant.




Fig. 42: Startup list in the TwinCAT System Manager

The Startup list may already contain values that were configured by the System Manager based on the ESI specifications. Additional application-specific entries can be created.

Online/offline list

While working with the TwinCAT System Manager, a distinction has to be made whether the EtherCAT device is "available", i.e. switched on and linked via EtherCAT and therefore **online**, or whether a configuration is created **offline** without connected slaves.

In both cases a CoE list as shown in Fig. "CoE online tab" is displayed. The connectivity is shown as offline/online.

- If the slave is offline
 - The offline list from the ESI file is displayed. In this case modifications are not meaningful or possible.
 - The configured status is shown under Identity.
 - No firmware or hardware version is displayed, since these are features of the physical device.
 - **Offline** is shown in red.




Fig. 43: Offline list

- If the slave is online
 - The actual current slave list is read. This may take several seconds, depending on the size and cycle time.
 - The actual identity is displayed
 - The firmware and hardware version of the equipment according to the electronic information is displayed
 - **Online** is shown in green.




Fig. 44: Online list

Channel-based order

The CoE list is available in EtherCAT devices that usually feature several functionally equivalent channels. For example, a 4-channel analog 0...10 V input terminal also has 4 logical channels and therefore 4 identical sets of parameter data for the channels. In order to avoid having to list each channel in the documentation, the placeholder "n" tends to be used for the individual channel numbers.

In the CoE system 16 indices, each with 255 subindices, are generally sufficient for representing all channel parameters. The channel-based order is therefore arranged in $16_{\text{dec}}/10_{\text{hex}}$ steps. The parameter range 0x8000 exemplifies this:

- Channel 0: parameter range 0x8000:00 ... 0x800F:255
- Channel 1: parameter range 0x8010:00 ... 0x801F:255
- Channel 2: parameter range 0x8020:00 ... 0x802F:255
- ...

This is generally written as 0x80n0.

Detailed information on the CoE interface can be found in the [EtherCAT system documentation](#) on the Beckhoff website.

3.6 Distributed Clock

The distributed clock represents a local clock in the EtherCAT slave controller (ESC) with the following characteristics:

- Unit *1 ns*
- Zero point *1.1.2000 00:00*
- Size *64 bit* (sufficient for the next 584 years; however, some EtherCAT slaves only offer 32-bit support, i.e. the variable overflows after approx. 4.2 seconds)
- The EtherCAT master automatically synchronizes the local clock with the master clock in the EtherCAT bus with a precision of < 100 ns.

For detailed information please refer to the [EtherCAT system description](#).

4 Mounting and wiring

4.1 Installation on mounting rails

⚠ WARNING

Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the bus terminals!

Assembly




Fig. 45: Attaching on mounting rail

The bus coupler and bus terminals are attached to commercially available 35 mm mounting rails (DIN rails according to EN 60715) by applying slight pressure:

1. First attach the fieldbus coupler to the mounting rail.
2. The bus terminals are now attached on the right-hand side of the fieldbus coupler. Join the components with tongue and groove and push the terminals against the mounting rail, until the lock clicks onto the mounting rail.

If the terminals are clipped onto the mounting rail first and then pushed together without tongue and groove, the connection will not be operational! When correctly assembled, no significant gap should be visible between the housings.

i Fixing of mounting rails

The locking mechanism of the terminals and couplers extends to the profile of the mounting rail. At the installation, the locking mechanism of the components must not come into conflict with the fixing bolts of the mounting rail. To mount the mounting rails with a height of 7.5 mm under the terminals and couplers, you should use flat mounting connections (e.g. countersunk screws or blind rivets).

Disassembly




Fig. 46: Disassembling of terminal

Each terminal is secured by a lock on the mounting rail, which must be released for disassembly:

1. Pull the terminal by its orange-colored lugs approximately 1 cm away from the mounting rail. In doing so for this terminal the mounting rail lock is released automatically and you can pull the terminal out of the bus terminal block easily without excessive force.
2. Grasp the released terminal with thumb and index finger simultaneous at the upper and lower grooved housing surfaces and pull the terminal out of the bus terminal block.

Connections within a bus terminal block

The electric connections between the Bus Coupler and the Bus Terminals are automatically realized by joining the components:

- The six spring contacts of the K-Bus/E-Bus deal with the transfer of the data and the supply of the Bus Terminal electronics.
- The power contacts deal with the supply for the field electronics and thus represent a supply rail within the bus terminal block. The power contacts are supplied via terminals on the Bus Coupler (up to 24 V) or for higher voltages via power feed terminals.

i Power Contacts

During the design of a bus terminal block, the pin assignment of the individual Bus Terminals must be taken account of, since some types (e.g. analog Bus Terminals or digital 4-channel Bus Terminals) do not or not fully loop through the power contacts. Power Feed Terminals (KL91xx, KL92xx or EL91xx, EL92xx) interrupt the power contacts and thus represent the start of a new supply rail.

PE power contact

The power contact labeled PE can be used as a protective earth. For safety reasons this contact mates first when plugging together, and can ground short-circuit currents of up to 125 A.




Fig. 47: Power contact on left side

NOTE**Possible damage of the device**

Note that, for reasons of electromagnetic compatibility, the PE contacts are capacitatively coupled to the mounting rail. This may lead to incorrect results during insulation testing or to damage on the terminal (e.g. disruptive discharge to the PE line during insulation testing of a consumer with a nominal voltage of 230 V). For insulation testing, disconnect the PE supply line at the Bus Coupler or the Power Feed Terminal! In order to decouple further feed points for testing, these Power Feed Terminals can be released and pulled at least 10 mm from the group of terminals.

⚠ WARNING**Risk of electric shock!**

The PE power contact must not be used for other potentials!

4.2 Installation instructions for enhanced mechanical load capacity

⚠ WARNING**Risk of injury through electric shock and damage to the device!**

Bring the Bus Terminal system into a safe, de-energized state before starting mounting, disassembly or wiring of the Bus Terminals!

Additional checks

The terminals have undergone the following additional tests:

| Verification | Explanation |
|--------------|---|
| Vibration | 10 frequency runs in 3 axes |
| | 6 Hz < f < 60 Hz displacement 0.35 mm, constant amplitude |
| | 60.1 Hz < f < 500 Hz acceleration 5 g, constant amplitude |
| Shocks | 1000 shocks in each direction, in 3 axes |
| | 25 g, 6 ms |

Additional installation instructions

For terminals with enhanced mechanical load capacity, the following additional installation instructions apply:

- The enhanced mechanical load capacity is valid for all permissible installation positions
- Use a mounting rail according to EN 60715 TH35-15
- Fix the terminal segment on both sides of the mounting rail with a mechanical fixture, e.g. an earth terminal or reinforced end clamp
- The maximum total extension of the terminal segment (without coupler) is:
64 terminals (12 mm mounting with) or 32 terminals (24 mm mounting with)
- Avoid deformation, twisting, crushing and bending of the mounting rail during edging and installation of the rail
- The mounting points of the mounting rail must be set at 5 cm intervals
- Use countersunk head screws to fasten the mounting rail
- The free length between the strain relief and the wire connection should be kept as short as possible. A distance of approx. 10 cm should be maintained to the cable duct.

4.3 Positioning of passive Terminals

i Hint for positioning of passive terminals in the bus terminal block

EtherCAT Terminals (ELxxxx / ESxxxx), which do not take an active part in data transfer within the bus terminal block are so called passive terminals. The passive terminals have no current consumption out of the E-Bus.

To ensure an optimal data transfer, you must not directly string together more than 2 passive terminals!

Examples for positioning of passive terminals (highlighted)




Fig. 48: Correct positioning




Fig. 49: Incorrect positioning

4.4 Installation positions

NOTE

Constraints regarding installation position and operating temperature range

Please refer to the technical data for a terminal to ascertain whether any restrictions regarding the installation position and/or the operating temperature range have been specified. When installing high power dissipation terminals ensure that an adequate spacing is maintained between other components above and below the terminal in order to guarantee adequate ventilation!

Optimum installation position (standard)

The optimum installation position requires the mounting rail to be installed horizontally and the connection surfaces of the EL/KL terminals to face forward (see Fig. "Recommended distances for standard installation position"). The terminals are ventilated from below, which enables optimum cooling of the electronics through convection. "From below" is relative to the acceleration of gravity.





Fig. 50: Recommended distances for standard installation position

Compliance with the distances shown in Fig. “Recommended distances for standard installation position” is recommended.

Other installation positions

All other installation positions are characterized by different spatial arrangement of the mounting rail - see Fig “Other installation positions”.

The minimum distances to ambient specified above also apply to these installation positions.






Fig. 51: Other installation positions

4.5 Connection

4.5.1 Connection system

⚠ WARNING

Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the bus terminals!

Overview

The Bus Terminal system offers different connection options for optimum adaptation to the respective application:

- The terminals of ELxxxx and KLxxxx series with standard wiring include electronics and connection level in a single enclosure.
- The terminals of ESxxxx and KSxxxx series feature a pluggable connection level and enable steady wiring while replacing.
- The High Density Terminals (HD Terminals) include electronics and connection level in a single enclosure and have advanced packaging density.

Standard wiring (ELxxxx / KLxxxx)



Fig. 52: Standard wiring

The terminals of ELxxxx and KLxxxx series have been tried and tested for years. They feature integrated screwless spring force technology for fast and simple assembly.

Pluggable wiring (ESxxxx / KSxxxx)




Fig. 53: Pluggable wiring

The terminals of ESxxxx and KSxxxx series feature a pluggable connection level. The assembly and wiring procedure is the same as for the ELxxxx and KLxxxx series. The pluggable connection level enables the complete wiring to be removed as a plug connector from the top of the housing for servicing. The lower section can be removed from the terminal block by pulling the unlocking tab. Insert the new component and plug in the connector with the wiring. This reduces the installation time and eliminates the risk of wires being mixed up.

The familiar dimensions of the terminal only had to be changed slightly. The new connector adds about 3 mm. The maximum height of the terminal remains unchanged.

A tab for strain relief of the cable simplifies assembly in many applications and prevents tangling of individual connection wires when the connector is removed.

Conductor cross sections between 0.08 mm² and 2.5 mm² can continue to be used with the proven spring force technology.

The overview and nomenclature of the product names for ESxxxx and KSxxxx series has been retained as known from ELxxxx and KLxxxx series.

High Density Terminals (HD Terminals)



Fig. 54: High Density Terminals

The Bus Terminals from these series with 16 terminal points are distinguished by a particularly compact design, as the packaging density is twice as large as that of the standard 12 mm Bus Terminals. Massive conductors and conductors with a wire end sleeve can be inserted directly into the spring loaded terminal point without tools.



Wiring HD Terminals

The High Density Terminals of the ELx8xx and KLx8xx series doesn't support pluggable wiring.

Ultrasonically "bonded" (ultrasonically welded) conductors



Ultrasonically "bonded" conductors

It is also possible to connect the Standard and High Density Terminals with ultrasonically "bonded" (ultrasonically welded) conductors. In this case, please note the tables concerning the wire-size width below!

4.5.2 Wiring

⚠ WARNING

Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!

Terminals for standard wiring ELxxxx/KLxxxx and for pluggable wiring ESxxxx/KSxxxx




Fig. 55: Connecting a cable on a terminal point

Up to eight terminal points enable the connection of solid or finely stranded cables to the Bus Terminal. The terminal points are implemented in spring force technology. Connect the cables as follows:

1. Open a terminal point by pushing a screwdriver straight against the stop into the square opening above the terminal point. Do not turn the screwdriver or move it alternately (don't toggle).
2. The wire can now be inserted into the round terminal opening without any force.
3. The terminal point closes automatically when the pressure is released, holding the wire securely and permanently.

See the following table for the suitable wire size width.

| Terminal housing | ELxxxx, KLxxxx | ESxxxx, KSxxxx |
|---|------------------------------|------------------------------|
| Wire size width (single core wires) | 0.08 ... 2.5 mm ² | 0.08 ... 2.5 mm ² |
| Wire size width (fine-wire conductors) | 0.08 ... 2.5 mm ² | 0.08 ... 2.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 1.5 mm ² | 0.14 ... 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm | 9 ... 10 mm |

High Density Terminals (HD Terminals [► 83]) with 16 terminal points

The conductors of the HD Terminals are connected without tools for single-wire conductors using the direct plug-in technique, i.e. after stripping the wire is simply plugged into the terminal point. The cables are released, as usual, using the contact release with the aid of a screwdriver. See the following table for the suitable wire size width.

| Terminal housing | High Density Housing |
|--|-------------------------------|
| Wire size width (single core wires) | 0.08 ... 1.5 mm ² |
| Wire size width (fine-wire conductors) | 0.25 ... 1.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 0.75 mm ² |
| Wire size width (ultrasonically "bonded" conductors) | only 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm |

4.5.3 Shielding



Shielding

Encoder, analog sensors and actors should always be connected with shielded, twisted paired wires.

4.6 ATEX - Special conditions (standard temperature range)

WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components with standard temperature range in potentially explosive areas (directive 2014/34/EU)!

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60079-15! The environmental conditions during use are thereby to be taken into account!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of 0 to 55°C for the use of Beckhoff fieldbus components standard temperature range in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010

Marking

The Beckhoff fieldbus components with standard temperature range certified according to the ATEX directive for potentially explosive areas bear one of the following markings:



II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: 0 ... +55°C

or



II 3G KEMA 10ATEX0075 X Ex nC IIC T4 Gc Ta: 0 ... +55°C

4.7 ATEX - Special conditions (extended temperature range)

⚠ WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components with extended temperature range (ET) in potentially explosive areas (directive 2014/34/EU)!

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60079-15! The environmental conditions during use are thereby to be taken into account!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of -25 to 60°C for the use of Beckhoff fieldbus components with extended temperature range (ET) in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010

Marking

The Beckhoff fieldbus components with extended temperature range (ET) certified according to the ATEX directive for potentially explosive areas bear the following marking:



II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: -25 ... +60°C

or



II 3G KEMA 10ATEX0075 X Ex nC IIC T4 Gc Ta: -25 ... +60°C

4.8 ATEX Documentation



Notes about operation of the Beckhoff terminal systems in potentially explosive areas (ATEX)

Pay also attention to the continuative documentation

Notes about operation of the Beckhoff terminal systems in potentially explosive areas (ATEX)

that is available in the download area of the Beckhoff homepage <http://www.beckhoff.com!>

5 Commissioning

5.1 TwinCAT Quick Start

TwinCAT is a development environment for real-time control including multi-PLC system, NC axis control, programming and operation. The whole system is mapped through this environment and enables access to a programming environment (including compilation) for the controller. Individual digital or analog inputs or outputs can also be read or written directly, in order to verify their functionality, for example.

For further information please refer to <http://infosys.beckhoff.com>:

- **EtherCAT Systemmanual:**
Fieldbus Components → EtherCAT Terminals → EtherCAT System Documentation → Setup in the TwinCAT System Manager
- **TwinCAT 2** → TwinCAT System Manager → I/O - Configuration
- In particular, TwinCAT driver installation:
Fieldbus components → Fieldbus Cards and Switches → FC900x – PCI Cards for Ethernet → Installation

Devices contain the terminals for the actual configuration. All configuration data can be entered directly via editor functions (offline) or via the "Scan" function (online):

- **"offline"**: The configuration can be customized by adding and positioning individual components. These can be selected from a directory and configured.
 - The procedure for offline mode can be found under <http://infosys.beckhoff.com>:
TwinCAT 2 → TwinCAT System Manager → IO - Configuration → Adding an I/O Device
- **"online"**: The existing hardware configuration is read
 - See also <http://infosys.beckhoff.com>:
Fieldbus components → Fieldbus cards and switches → FC900x – PCI Cards for Ethernet → Installation → Searching for devices

The following relationship is envisaged from user PC to the individual control elements:




Fig. 56: Relationship between user side (commissioning) and installation

The user inserting of certain components (I/O device, terminal, box...) is the same in TwinCAT 2 and TwinCAT 3. The descriptions below relate to the online procedure.

Sample configuration (actual configuration)

Based on the following sample configuration, the subsequent subsections describe the procedure for TwinCAT 2 and TwinCAT 3:

- Control system (PLC) **CX2040** including **CX2100-0004** power supply unit
- Connected to the CX2040 on the right (E-bus):
EL1004 (4-channel digital input terminal 24 V DC)
- Linked via the X001 port (RJ-45): **EK1100** EtherCAT Coupler
- Connected to the EK1100 EtherCAT coupler on the right (E-bus):
EL2008 (8-channel digital output terminal 24 V DC; 0.5 A)
- (Optional via X000: a link to an external PC for the user interface)




Fig. 57: Control configuration with Embedded PC, input (EL1004) and output (EL2008)

Note that all combinations of a configuration are possible; for example, the EL1004 terminal could also be connected after the coupler, or the EL2008 terminal could additionally be connected to the CX2040 on the right, in which case the EK1100 coupler wouldn't be necessary.

5.1.1 TwinCAT 2

Startup

TwinCAT basically uses two user interfaces: the TwinCAT System Manager for communication with the electromechanical components and TwinCAT PLC Control for the development and compilation of a controller. The starting point is the TwinCAT System Manager.

After successful installation of the TwinCAT system on the PC to be used for development, the TwinCAT 2 System Manager displays the following user interface after startup:





Fig. 58: Initial TwinCAT 2 user interface

Generally, TwinCAT can be used in local or remote mode. Once the TwinCAT system including the user interface (standard) is installed on the respective PLC, TwinCAT can be used in local mode and thereby the next step is "Insert Device [► 93]".

If the intention is to address the TwinCAT runtime environment installed on a PLC as development environment remotely from another system, the target system must be made known first. In the menu under

"Actions" → "Choose Target System...", via the symbol "  " or the "F8" key, open the following window:




Fig. 59: Selection of the target system

Use "Search (Ethernet)..." to enter the target system. Thus a next dialog opens to either:

- enter the known computer name after "Enter Host Name / IP:" (as shown in red)
- perform a "Broadcast Search" (if the exact computer name is not known)
- enter the known computer IP or AmsNetID.





Fig. 60: Specify the PLC for access by the TwinCAT System Manager: selection of the target system



Once the target system has been entered, it is available for selection as follows (a password may have to be entered):



After confirmation with "OK" the target system can be accessed via the System Manager.

Adding devices

In the configuration tree of the TwinCAT 2 System Manager user interface on the left, select "I/O Devices" and then right-click to open a context menu and select "Scan Devices...", or start the action in the menu bar

via . The TwinCAT System Manager may first have to be set to "Config mode" via  or via menu "Actions" → "Set/Reset TwinCAT to Config Mode..." (Shift + F4).




Fig. 61: Select "Scan Devices..."

Confirm the warning message, which follows, and select "EtherCAT" in the dialog:




Fig. 62: Automatic detection of I/O devices: selection the devices to be integrated

Confirm the message "Find new boxes", in order to determine the terminals connected to the devices. "Free Run" enables manipulation of input and output values in "Config mode" and should also be acknowledged.

Based on the [sample configuration](#) [► 89] described at the beginning of this section, the result is as follows:




Fig. 63: Mapping of the configuration in the TwinCAT 2 System Manager

The whole process consists of two stages, which may be performed separately (first determine the devices, then determine the connected elements such as boxes, terminals, etc.). A scan can also be initiated by selecting "Device ..." from the context menu, which then reads the elements present in the configuration below:




Fig. 64: Reading of individual terminals connected to a device

This functionality is useful if the actual configuration is modified at short notice.

Programming and integrating the PLC

TwinCAT PLC Control is the development environment for the creation of the controller in different program environments: TwinCAT PLC Control supports all languages described in IEC 61131-3. There are two text-based languages and three graphical languages.

- **Text-based languages**
 - Instruction List (IL)

- Structured Text (ST)
- **Graphical languages**
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - The Continuous Function Chart Editor (CFC)
 - Sequential Function Chart (SFC)

The following section refers to Structured Text (ST).

After starting TwinCAT PLC Control, the following user interface is shown for an initial project:




Fig. 65: TwinCAT PLC Control after startup

Sample variables and a sample program have been created and stored under the name "PLC_example.pro":




Fig. 66: Sample program with variables after a compile process (without variable integration)

Warning 1990 (missing "VAR_CONFIG") after a compile process indicates that the variables defined as external (with the ID "AT%I*" or "AT%Q*") have not been assigned. After successful compilation, TwinCAT PLC Control creates a "*.tpy" file in the directory in which the project was stored. This file (*.tpy) contains variable assignments and is not known to the System Manager, hence the warning. Once the System Manager has been notified, the warning no longer appears.

First, integrate the TwinCAT PLC Control project in the **System Manager** via the context menu of the PLC configuration; right-click and select "Append PLC Project...":




Fig. 67: Appending the TwinCAT PLC Control project

Select the PLC configuration "PLC_example.tpy" in the browser window that opens. The project including the two variables identified with "AT" are then integrated in the configuration tree of the System Manager:




Fig. 68: PLC project integrated in the PLC configuration of the System Manager

The two variables "bEL1004_Ch4" and "nEL2008_value" can now be assigned to certain process objects of the I/O configuration.

Assigning variables

Open a window for selecting a suitable process object (PDO) via the context menu of a variable of the integrated project "PLC_example" and via "Modify Link..." "Standard":




Fig. 69: Creating the links between PLC variables and process objects

In the window that opens, the process object for the variable "bEL1004_Ch4" of type BOOL can be selected from the PLC configuration tree:




Fig. 70: Selecting PDO of type BOOL

According to the default setting, certain PDO objects are now available for selection. In this sample the input of channel 4 of the EL1004 terminal is selected for linking. In contrast, the checkbox "All types" must be ticked for creating the link for the output variables, in order to allocate a set of eight separate output bits to a byte variable. The following diagram shows the whole process:





Fig. 71: Selecting several PDOs simultaneously: activate "Continuous" and "All types"

Note that the "Continuous" checkbox was also activated. This is designed to allocate the bits contained in the byte of the variable "nEL2008_value" sequentially to all eight selected output bits of the EL2008 terminal. In this way it is possible to subsequently address all eight outputs of the terminal in the program with a byte corresponding to bit 0 for channel 1 to bit 7 for channel 8 of the PLC. A special symbol () at the yellow or red object of the variable indicates that a link exists. The links can also be checked by selecting a "Goto Link Variable" from the context menu of a variable. The object opposite, in this case the PDO, is automatically selected:





Fig. 72: Application of a "Goto Link" variable, using "MAIN.bEL1004_Ch4" as a sample

The process of assigning variables to the PDO is completed via the menu selection "Actions" → "Generate

Mappings", key Ctrl+M or by clicking on the symbol  in the menu.


This can be visualized in the configuration:




The process of creating links can also take place in the opposite direction, i.e. starting with individual PDOs to variable. However, in this example it would then not be possible to select all output bits for the EL2008, since the terminal only makes individual digital outputs available. If a terminal has a byte, word, integer or similar PDO, it is possible to allocate this a set of bit-standardised variables (type "BOOL"). Here, too, a "Goto Link Variable" from the context menu of a PDO can be executed in the other direction, so that the respective PLC instance can then be selected.

Activation of the configuration

The allocation of PDO to PLC variables has now established the connection from the controller to the inputs and outputs of the terminals. The configuration can now be activated. First, the configuration can be verified

via  (or via "Actions" → "Check Configuration"). If no error is present, the configuration can be

activated via  (or via "Actions" → "Activate Configuration...") to transfer the System Manager settings to the runtime system. Confirm the messages "Old configurations are overwritten!" and "Restart TwinCAT system in Run mode" with "OK".

A few seconds later the real-time status **RTime 0%** is displayed at the bottom right in the System Manager. The PLC system can then be started as described below.

Starting the controller

Starting from a remote system, the PLC control has to be linked with the Embedded PC over Ethernet via "Online" → "Choose Run-Time System...":





Fig. 73: Choose target system (remote)

In this sample "Runtime system 1 (port 801)" is selected and confirmed. Link the PLC with the real-time

system via menu option "Online" → "Login", the F11 key or by clicking on the symbol . The control program can then be loaded for execution. This results in the message "No program on the controller! Should the new program be loaded?", which should be acknowledged with "Yes". The runtime environment is ready for the program start:




Fig. 74: PLC Control logged in, ready for program startup

The PLC can now be started via "Online" → "Run", F5 key or .

5.1.2 TwinCAT 3

Startup

TwinCAT makes the development environment areas available together with Microsoft Visual Studio: after startup, the project folder explorer appears on the left in the general window area (cf. "TwinCAT System Manager" of TwinCAT 2) for communication with the electromechanical components.

After successful installation of the TwinCAT system on the PC to be used for development, TwinCAT 3 (shell) displays the following user interface after startup:





Fig. 75: Initial TwinCAT 3 user interface

First create a new project via  **New TwinCAT Project...** (or under "File"→"New"→"Project..."). In the following dialog make the corresponding entries as required (as shown in the diagram):




Fig. 76: Create new TwinCAT project

The new project is then available in the project folder explorer:






Fig. 77: New TwinCAT3 project in the project folder explorer

Generally, TwinCAT can be used in local or remote mode. Once the TwinCAT system including the user interface (standard) is installed on the respective PLC, TwinCAT can be used in local mode and thereby the next step is "Insert Device [► 104]".

If the intention is to address the TwinCAT runtime environment installed on a PLC as development environment remotely from another system, the target system must be made known first. Via the symbol in the menu bar:



expand the pull-down menu:



and open the following window:




Fig. 78: Selection dialog: Choose the target system

Use "Search (Ethernet)..." to enter the target system. Thus a next dialog opens to either:

- enter the known computer name after "Enter Host Name / IP:" (as shown in red)
- perform a "Broadcast Search" (if the exact computer name is not known)
- enter the known computer IP or AmsNetID.





Fig. 79: Specify the PLC for access by the TwinCAT System Manager: selection of the target system


Once the target system has been entered, it is available for selection as follows (a password may have to be entered):




After confirmation with "OK" the target system can be accessed via the Visual Studio shell.

Adding devices

In the project folder explorer of the Visual Studio shell user interface on the left, select "Devices" within

element "I/O", then right-click to open a context menu and select "Scan" or start the action via  in the

menu bar. The TwinCAT System Manager may first have to be set to "Config mode" via  or via the menu "TwinCAT" → "Restart TwinCAT (Config mode)".




Fig. 80: Select "Scan"

Confirm the warning message, which follows, and select "EtherCAT" in the dialog:




Fig. 81: Automatic detection of I/O devices: selection the devices to be integrated

Confirm the message "Find new boxes", in order to determine the terminals connected to the devices. "Free Run" enables manipulation of input and output values in "Config mode" and should also be acknowledged.

Based on the [sample configuration](#) [► 89] described at the beginning of this section, the result is as follows:




Fig. 82: Mapping of the configuration in VS shell of the TwinCAT3 environment

The whole process consists of two stages, which may be performed separately (first determine the devices, then determine the connected elements such as boxes, terminals, etc.). A scan can also be initiated by selecting "Device ..." from the context menu, which then reads the elements present in the configuration below:




Fig. 83: Reading of individual terminals connected to a device

This functionality is useful if the actual configuration is modified at short notice.

Programming the PLC

TwinCAT PLC Control is the development environment for the creation of the controller in different program environments: TwinCAT PLC Control supports all languages described in IEC 61131-3. There are two text-based languages and three graphical languages.

- **Text-based languages**
 - Instruction List (IL)
 - Structured Text (ST)
- **Graphical languages**
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - The Continuous Function Chart Editor (CFC)
 - Sequential Function Chart (SFC)

The following section refers to Structured Text (ST).

In order to create a programming environment, a PLC subproject is added to the project sample via the context menu of "PLC" in the project folder explorer by selecting "Add New Item....":




Fig. 84: Adding the programming environment in "PLC"

In the dialog that opens select "Standard PLC project" and enter "PLC_example" as project name, for example, and select a corresponding directory:




Fig. 85: Specifying the name and directory for the PLC programming environment

The "Main" program, which already exists by selecting "Standard PLC project", can be opened by double-clicking on "PLC_example_project" in "POUs". The following user interface is shown for an initial project:




Fig. 86: Initial "Main" program of the standard PLC project

To continue, sample variables and a sample program have now been created:




Fig. 87: Sample program with variables after a compile process (without variable integration)

The control program is now created as a project folder, followed by the compile process:





Fig. 88: Start program compilation

The following variables, identified in the ST/ PLC program with "AT%", are then available in under "Assignments" in the project folder explorer:



Assigning variables

Via the menu of an instance - variables in the "PLC" context, use the "Modify Link..." option to open a window for selecting a suitable process object (PDO) for linking:




Fig. 89: Creating the links between PLC variables and process objects

In the window that opens, the process object for the variable "bEL1004_Ch4" of type BOOL can be selected from the PLC configuration tree:




Fig. 90: Selecting PDO of type BOOL

According to the default setting, certain PDO objects are now available for selection. In this sample the input of channel 4 of the EL1004 terminal is selected for linking. In contrast, the checkbox "All types" must be ticked for creating the link for the output variables, in order to allocate a set of eight separate output bits to a byte variable. The following diagram shows the whole process:





Fig. 91: Selecting several PDOs simultaneously: activate "Continuous" and "All types"

Note that the "Continuous" checkbox was also activated. This is designed to allocate the bits contained in the byte of the variable "nEL2008_value" sequentially to all eight selected output bits of the EL2008 terminal. In this way it is possible to subsequently address all eight outputs of the terminal in the program with a byte corresponding to bit 0 for channel 1 to bit 7 for channel 8 of the PLC. A special symbol () at the yellow or red object of the variable indicates that a link exists. The links can also be checked by selecting a "Goto Link Variable" from the context menu of a variable. The object opposite, in this case the PDO, is automatically selected:




Fig. 92: Application of a "Goto Link" variable, using "MAIN.bEL1004_Ch4" as a sample


The process of creating links can also take place in the opposite direction, i.e. starting with individual PDOs to variable. However, in this example it would then not be possible to select all output bits for the EL2008, since the terminal only makes individual digital outputs available. If a terminal has a byte, word, integer or

similar PDO, it is possible to allocate this a set of bit-standardised variables (type "BOOL"). Here, too, a "Goto Link Variable" from the context menu of a PDO can be executed in the other direction, so that the respective PLC instance can then be selected.

Activation of the configuration

The allocation of PDO to PLC variables has now established the connection from the controller to the inputs

and outputs of the terminals. The configuration can now be activated with  or via the menu under "TwinCAT" in order to transfer settings of the development environment to the runtime system. Confirm the messages "Old configurations are overwritten!" and "Restart TwinCAT system in Run mode" with "OK". The corresponding assignments can be seen in the project folder explorer:





A few seconds later the corresponding status of the Run mode is displayed in the form of a rotating symbol



at the bottom right of the VS shell development environment. The PLC system can then be started as described below.

Starting the controller

Select the menu option "PLC" → "Login" or click on  to link the PLC with the real-time system and load the control program for execution. This results in the message "No program on the controller! Should the new program be loaded?", which should be acknowledged with "Yes". The runtime environment is ready for

program start by click on symbol , the "F5" key or via "PLC" in the menu selecting "Start". The started programming environment shows the runtime values of individual variables:




Fig. 93: TwinCAT development environment (VS shell): logged-in, after program startup

The two operator control elements for stopping  and logout  result in the required action (accordingly also for stop "Shift + F5", or both actions can be selected via the PLC menu).

5.2 TwinCAT Development Environment

The Software for automation TwinCAT (The Windows Control and Automation Technology) will be distinguished into:

- TwinCAT 2: System Manager (Configuration) & PLC Control (Programming)
- TwinCAT 3: Enhancement of TwinCAT 2 (Programming and Configuration takes place via a common Development Environment)

Details:

- **TwinCAT 2:**
 - Connects I/O devices to tasks in a variable-oriented manner
 - Connects tasks to tasks in a variable-oriented manner
 - Supports units at the bit level
 - Supports synchronous or asynchronous relationships
 - Exchange of consistent data areas and process images
 - Datalink on NT - Programs by open Microsoft Standards (OLE, OCX, ActiveX, DCOM+, etc.)
 - Integration of IEC 61131-3-Software-SPS, Software- NC and Software-CNC within Windows NT/2000/XP/Vista, Windows 7, NT/XP Embedded, CE
 - Interconnection to all common fieldbusses
 - More...

Additional features:

- **TwinCAT 3 (eXtended Automation):**
 - Visual-Studio®-Integration
 - Choice of the programming language
 - Supports object orientated extension of IEC 61131-3
 - Usage of C/C++ as programming language for real time applications
 - Connection to MATLAB®/Simulink®
 - Open interface for expandability
 - Flexible run-time environment
 - Active support of Multi-Core- und 64-Bit-Operatingsystem
 - Automatic code generation and project creation with the TwinCAT Automation Interface
 - More...

Within the following sections commissioning of the TwinCAT Development Environment on a PC System for the control and also the basically functions of unique control elements will be explained.

Please see further information to TwinCAT 2 and TwinCAT 3 at <http://infosys.beckhoff.com>.

5.2.1 Installation of the TwinCAT real-time driver

In order to assign real-time capability to a standard Ethernet port of an IPC controller, the Beckhoff real-time driver has to be installed on this port under Windows.

This can be done in several ways. One option is described here.

In the System Manager call up the TwinCAT overview of the local network interfaces via Options → Show Real Time Ethernet Compatible Devices.




Fig. 94: System Manager “Options” (TwinCAT 2)

This have to be called up by the Menü “TwinCAT” within the TwinCAT 3 environment:




Fig. 95: Call up under VS Shell (TwinCAT 3)

The following dialog appears:




Fig. 96: Overview of network interfaces

Interfaces listed under “Compatible devices” can be assigned a driver via the “Install” button. A driver should only be installed on compatible devices.


A Windows warning regarding the unsigned driver can be ignored.

Alternatively an EtherCAT-device can be inserted first of all as described in chapter [Offline configuration creation, section “Creating the EtherCAT device”](#) [► 124] in order to view the compatible ethernet ports via its EtherCAT properties (tab „Adapter“, button „Compatible Devices...“):



Fig. 97: EtherCAT device properties(TwinCAT 2): click on „Compatible Devices...“ of tab “Adapter”

TwinCAT 3: the properties of the EtherCAT device can be opened by double click on “Device .. (EtherCAT)” within the Solution Explorer under “I/O”:



After the installation the driver appears activated in the Windows overview for the network interface (Windows Start → System Properties → Network)




Fig. 98: Windows properties of the network interface

A correct setting of the driver could be:




Fig. 99: Exemplary correct driver setting for the Ethernet port

Other possible settings have to be avoided:




Fig. 100: Incorrect driver settings for the Ethernet port

IP address of the port used



IP address/DHCP

In most cases an Ethernet port that is configured as an EtherCAT device will not transport general IP packets. For this reason and in cases where an EL6601 or similar devices are used it is useful to specify a fixed IP address for this port via the “Internet Protocol TCP/IP” driver setting and to disable DHCP. In this way the delay associated with the DHCP client for the Ethernet port assigning itself a default IP address in the absence of a DHCP server is avoided. A suitable address space is 192.168.x.x, for example.




Fig. 101: TCP/IP setting for the Ethernet port

5.2.2 Notes regarding ESI device description

Installation of the latest ESI device description

The TwinCAT EtherCAT master/System Manager needs the device description files for the devices to be used in order to generate the configuration in online or offline mode. The device descriptions are contained in the so-called ESI files (EtherCAT Slave Information) in XML format. These files can be requested from the respective manufacturer and are made available for download. An *.xml file may contain several device descriptions.

The ESI files for Beckhoff EtherCAT devices are available on the [Beckhoff website](#).

The ESI files should be stored in the TwinCAT installation directory.

Default settings:

- **TwinCAT 2:** C:\TwinCAT\IO\EtherCAT
- **TwinCAT 3:** C:\TwinCAT\3.1\Config\Io\EtherCAT

The files are read (once) when a new System Manager window is opened, if they have changed since the last time the System Manager window was opened.

A TwinCAT installation includes the set of Beckhoff ESI files that was current at the time when the TwinCAT build was created.

For TwinCAT 2.11/TwinCAT 3 and higher, the ESI directory can be updated from the System Manager, if the programming PC is connected to the Internet; by

- **TwinCAT 2:** Option → “Update EtherCAT Device Descriptions”
- **TwinCAT 3:** TwinCAT → EtherCAT Devices → “Update Device Descriptions (via ETG Website)...”

The [TwinCAT ESI Updater](#) [► 123] is available for this purpose.



ESI

The *.xml files are associated with *.xsd files, which describe the structure of the ESI XML files. To update the ESI device descriptions, both file types should therefore be updated.

Device differentiation

EtherCAT devices/slaves are distinguished by four properties, which determine the full device identifier. For example, the device identifier EL2521-0025-1018 consists of:

- family key “EL”
- name “2521”
- type “0025”
- and revision “1018”




Fig. 102: Identifier structure

The order identifier consisting of name + type (here: EL2521-0010) describes the device function. The revision indicates the technical progress and is managed by Beckhoff. In principle, a device with a higher revision can replace a device with a lower revision, unless specified otherwise, e.g. in the documentation. Each revision has its own ESI description. See further notes.

Online description

If the EtherCAT configuration is created online through scanning of real devices (see section Online setup) and no ESI descriptions are available for a slave (specified by name and revision) that was found, the System Manager asks whether the description stored in the device should be used. In any case, the System Manager needs this information for setting up the cyclic and acyclic communication with the slave correctly.




Fig. 103: OnlineDescription information window (TwinCAT 2)

In TwinCAT 3 a similar window appears, which also offers the Web update:




Fig. 104: Information window OnlineDescription (TwinCAT 3)

If possible, the Yes is to be rejected and the required ESI is to be requested from the device manufacturer. After installation of the XML/XSD file the configuration process should be repeated.

NOTE

Changing the 'usual' configuration through a scan

- ✓ If a scan discovers a device that is not yet known to TwinCAT, distinction has to be made between two cases. Taking the example here of the EL2521-0000 in the revision 1019
 - a) no ESI is present for the EL2521-0000 device at all, either for the revision 1019 or for an older revision. The ESI must then be requested from the manufacturer (in this case Beckhoff).
 - b) an ESI is present for the EL2521-0000 device, but only in an older revision, e.g. 1018 or 1017. In this case an in-house check should first be performed to determine whether the spare parts stock allows the integration of the increased revision into the configuration at all. A new/higher revision usually also brings along new features. If these are not to be used, work can continue without reservations with the previous revision 1018 in the configuration. This is also stated by the Beckhoff compatibility rule.

Refer in particular to the chapter '[General notes on the use of Beckhoff EtherCAT IO components](#)' and for manual configuration to the chapter '[Offline configuration creation](#)' [[▶ 124](#)].

If the OnlineDescription is used regardless, the System Manager reads a copy of the device description from the EEPROM in the EtherCAT slave. In complex slaves the size of the EEPROM may not be sufficient for the complete ESI, in which case the ESI would be *incomplete* in the configurator. Therefore it's recommended using an offline ESI file with priority in such a case.

The System Manager creates for online recorded device descriptions a new file "OnlineDescription0000...xml" in its ESI directory, which contains all ESI descriptions that were read online.

OnlineDescriptionCache000000002.xml

Fig. 105: File OnlineDescription.xml created by the System Manager

If a slave desired to be added manually to the configuration at a later stage, online created slaves are indicated by a prepended symbol ">" in the selection list (see Figure "Indication of an online recorded ESI of EL2521 as an example").




Fig. 106: Indication of an online recorded ESI of EL2521 as an example

If such ESI files are used and the manufacturer's files become available later, the file OnlineDescription.xml should be deleted as follows:

- close all System Manager windows
- restart TwinCAT in Config mode
- delete "OnlineDescription0000...xml"
- restart TwinCAT System Manager

This file should not be visible after this procedure, if necessary press <F5> to update

OnlineDescription for TwinCAT 3.x

In addition to the file described above "OnlineDescription0000...xml", a so called EtherCAT cache with new discovered devices is created by TwinCAT 3.x, e.g. under Windows 7:

C:\User\[USERNAME]\AppData\Roaming\Beckhoff\TwinCAT3\Components\Base\EtherCATCache.xml

(Please note the language settings of the OS!)

You have to delete this file, too.

Faulty ESI file

If an ESI file is faulty and the System Manager is unable to read it, the System Manager brings up an information window.




Fig. 107: Information window for faulty ESI file (left: TwinCAT 2; right: TwinCAT 3)

Reasons may include:

- Structure of the *.xml does not correspond to the associated *.xsd file → check your schematics
- Contents cannot be translated into a device description → contact the file manufacturer

5.2.3 TwinCAT ESI Updater

For TwinCAT 2.11 and higher, the System Manager can search for current Beckhoff ESI files automatically, if an online connection is available:




Fig. 108: Using the ESI Updater (\geq TwinCAT 2.11)

The call up takes place under:

“Options” → “Update EtherCAT Device Descriptions”

Selection under TwinCAT 3:




Fig. 109: Using the ESI Updater (TwinCAT 3)

The ESI Updater (TwinCAT 3) is a convenient option for automatic downloading of ESI data provided by EtherCAT manufacturers via the Internet into the TwinCAT directory (ESI = EtherCAT slave information). TwinCAT accesses the central ESI ULR directory list stored at ETG; the entries can then be viewed in the Updater dialog, although they cannot be changed there.

The call up takes place under:

“TwinCAT” → „EtherCAT Devices“ → “Update Device Description (via ETG Website)...”.

5.2.4 Distinction between Online and Offline

The distinction between online and offline refers to the presence of the actual I/O environment (drives, terminals, EJ-modules). If the configuration is to be prepared in advance of the system configuration as a programming system, e.g. on a laptop, this is only possible in “Offline configuration” mode. In this case all components have to be entered manually in the configuration, e.g. based on the electrical design.

If the designed control system is already connected to the EtherCAT system and all components are energised and the infrastructure is ready for operation, the TwinCAT configuration can simply be generated through “scanning” from the runtime system. This is referred to as online configuration.

In any case, during each startup the EtherCAT master checks whether the slaves it finds match the configuration. This test can be parameterised in the extended slave settings. Refer to note “Installation of the latest ESI-XML device description” [► 119].

For preparation of a configuration:

- the real EtherCAT hardware (devices, couplers, drives) must be present and installed
- the devices/modules must be connected via EtherCAT cables or in the terminal/ module strand in the same way as they are intended to be used later

- the devices/modules be connected to the power supply and ready for communication
- TwinCAT must be in CONFIG mode on the target system.

The online scan process consists of:

- detecting the EtherCAT device [► 129] (Ethernet port at the IPC)
- detecting the connected EtherCAT devices [► 130]. This step can be carried out independent of the preceding step
- troubleshooting [► 133]

The scan with existing configuration [► 134] can also be carried out for comparison.

5.2.5 OFFLINE configuration creation

Creating the EtherCAT device

Create an EtherCAT device in an empty System Manager window.




Fig. 110: Append EtherCAT device (left: TwinCAT 2; right: TwinCAT 3)

Select type 'EtherCAT' for an EtherCAT I/O application with EtherCAT slaves. For the present publisher/subscriber service in combination with an EL6601/EL614 terminal select "EtherCAT Automation Protocol via EL6601".




Fig. 111: Selecting the EtherCAT connection (TwinCAT 2.11, TwinCAT 3)

Then assign a real Ethernet port to this virtual device in the runtime system.




Fig. 112: Selecting the Ethernet port

This query may appear automatically when the EtherCAT device is created, or the assignment can be set/modified later in the properties dialog; see Fig. “EtherCAT device properties (TwinCAT 2)”.





Fig. 113: EtherCAT device properties (TwinCAT 2)

TwinCAT 3: the properties of the EtherCAT device can be opened by double click on “Device .. (EtherCAT)” within the Solution Explorer under “I/O”:



● Selecting the Ethernet port

i Ethernet ports can only be selected for EtherCAT devices for which the TwinCAT real-time driver is installed. This has to be done separately for each port. Please refer to the respective [installation page \[► 113\]](#).

Defining EtherCAT slaves

Further devices can be appended by right-clicking on a device in the configuration tree.




Fig. 114: Appending EtherCAT devices (left: TwinCAT 2; right: TwinCAT 3)

The dialog for selecting a new device opens. Only devices for which ESI files are available are displayed.

Only devices are offered for selection that can be appended to the previously selected device. Therefore the physical layer available for this port is also displayed (Fig. “Selection dialog for new EtherCAT device”, A). In the case of cable-based Fast-Ethernet physical layer with PHY transfer, then also only cable-based devices are available, as shown in Fig. “Selection dialog for new EtherCAT device”. If the preceding device has several free ports (e.g. EK1122 or EK1100), the required port can be selected on the right-hand side (A).

Overview of physical layer

- “Ethernet”: cable-based 100BASE-TX: EK couplers, EP boxes, devices with RJ45/M8/M12 connector

- “E-Bus”: LVDS “terminal bus”, “EJ-module”: EL/ES terminals, various modular modules

The search field facilitates finding specific devices (since TwinCAT 2.11 or TwinCAT 3).




Fig. 115: Selection dialog for new EtherCAT device

By default only the name/device type is used as selection criterion. For selecting a specific revision of the device the revision can be displayed as “Extended Information”.




Fig. 116: Display of device revision

In many cases several device revisions were created for historic or functional reasons, e.g. through technological advancement. For simplification purposes (see Fig. “Selection dialog for new EtherCAT device”) only the last (i.e. highest) revision and therefore the latest state of production is displayed in the selection dialog for Beckhoff devices. To show all device revisions available in the system as ESI descriptions tick the “Show Hidden Devices” check box, see Fig. “Display of previous revisions”.




Fig. 117: Display of previous revisions

● Device selection based on revision, compatibility

The ESI description also defines the process image, the communication type between master and slave/device and the device functions, if applicable. The physical device (firmware, if available) has to support the communication queries/settings of the master. This is backward compatible, i.e. newer devices (higher revision) should be supported if the EtherCAT master addresses them as an older revision. The following compatibility rule of thumb is to be assumed for Beckhoff EtherCAT Terminals/ Boxes/ EJ-modules:

device revision in the system \geq device revision in the configuration

This also enables subsequent replacement of devices without changing the configuration (different specifications are possible for drives).

Example

If an EL2521-0025-**1018** is specified in the configuration, an EL2521-0025-**1018** or higher (**-1019**, **-1020**) can be used in practice.

Name
(EL2521-0025-1018)
Revision

Fig. 118: Name/revision of the terminal

If current ESI descriptions are available in the TwinCAT system, the last revision offered in the selection dialog matches the Beckhoff state of production. It is recommended to use the last device revision when creating a new configuration, if current Beckhoff devices are used in the real application. Older revisions should only be used if older devices from stock are to be used in the application.

In this case the process image of the device is shown in the configuration tree and can be parameterised as follows: linking with the task, CoE/DC settings, plug-in definition, startup settings, ...






Fig. 119: EtherCAT terminal in the TwinCAT tree (left: TwinCAT 2; right: TwinCAT 3)



5.2.6 ONLINE configuration creation

Detecting/scanning of the EtherCAT device

The online device search can be used if the TwinCAT system is in CONFIG mode. This can be indicated by a symbol right below in the information bar:



- on TwinCAT 2 by a blue display “Config Mode” within the System Manager window:  .
- on TwinCAT 3 within the user interface of the development environment by a symbol  .

TwinCAT can be set into this mode:

- TwinCAT 2: by selection of  in the Menubar or by “Actions” → “Set/Reset TwinCAT to Config Mode...”
- TwinCAT 3: by selection of  in the Menubar or by „TwinCAT“ → “Restart TwinCAT (Config Mode)”

Online scanning in Config mode

i The online search is not available in RUN mode (production operation). Note the differentiation between TwinCAT programming system and TwinCAT target system.

The TwinCAT 2 icon () or TwinCAT 3 icon () within the Windows-Taskbar always shows the TwinCAT mode of the local IPC. Compared to that, the System Manager window of TwinCAT 2 or the user interface of TwinCAT 3 indicates the state of the target system.




Fig. 120: Differentiation local/target system (left: TwinCAT 2; right: TwinCAT 3)

Right-clicking on “I/O Devices” in the configuration tree opens the search dialog.




Fig. 121: Scan Devices (left: TwinCAT 2; right: TwinCAT 3)

This scan mode attempts to find not only EtherCAT devices (or Ethernet ports that are usable as such), but also NOVRA, fieldbus cards, SMB etc. However, not all devices can be found automatically.




Fig. 122: Note for automatic device scan (left: TwinCAT 2; right: TwinCAT 3)

Ethernet ports with installed TwinCAT real-time driver are shown as “RT Ethernet” devices. An EtherCAT frame is sent to these ports for testing purposes. If the scan agent detects from the response that an EtherCAT slave is connected, the port is immediately shown as an “EtherCAT Device”.




Fig. 123: Detected Ethernet devices

Via respective checkboxes devices can be selected (as illustrated in Fig. “Detected Ethernet devices” e.g. Device 3 and Device 4 were chosen). After confirmation with “OK” a device scan is suggested for all selected devices, see Fig.: “Scan query after automatic creation of an EtherCAT device”.

● Selecting the Ethernet port

i

Ethernet ports can only be selected for EtherCAT devices for which the TwinCAT real-time driver is installed. This has to be done separately for each port. Please refer to the respective [installation page \[► 113\]](#).

Detecting/Scanning the EtherCAT devices

● Online scan functionality

i

During a scan the master queries the identity information of the EtherCAT slaves from the slave EEPROM. The name and revision are used for determining the type. The respective devices are located in the stored ESI data and integrated in the configuration tree in the default state defined there.

Name
(EL2521-0025-1018)
Revision

Fig. 124: Example default state

NOTE

Slave scanning in practice in series machine production

The scanning function should be used with care. It is a practical and fast tool for creating an initial configuration as a basis for commissioning. In series machine production or reproduction of the plant, however, the function should no longer be used for the creation of the configuration, but if necessary for [comparison \[► 134\]](#) with the defined initial configuration. Background: since Beckhoff occasionally increases the revision version of the delivered products for product maintenance reasons, a configuration can be created by such a scan which (with an identical machine construction) is identical according to the device list; however, the respective device revision may differ from the initial configuration.

Example:

Company A builds the prototype of a machine B, which is to be produced in series later on. To do this the prototype is built, a scan of the IO devices is performed in TwinCAT and the initial configuration ‘B.tsm’ is created. The EL2521-0025 EtherCAT terminal with the revision 1018 is located somewhere. It is thus built into the TwinCAT configuration in this way:




Fig. 125: Installing EtherCAT terminal with revision -1018

Likewise, during the prototype test phase, the functions and properties of this terminal are tested by the programmers/commissioning engineers and used if necessary, i.e. addressed from the PLC 'B.pro' or the NC. (the same applies correspondingly to the TwinCAT 3 solution files).

The prototype development is now completed and series production of machine B starts, for which Beckhoff continues to supply the EL2521-0025-0018. If the commissioning engineers of the series machine production department always carry out a scan, a B configuration with the identical contents results again for each machine. Likewise, A might create spare parts stores worldwide for the coming series-produced machines with EL2521-0025-1018 terminals.

After some time Beckhoff extends the EL2521-0025 by a new feature C. Therefore the FW is changed, outwardly recognizable by a higher FW version and a **new revision -1019**. Nevertheless the new device naturally supports functions and interfaces of the predecessor version(s); an adaptation of 'B.tsm' or even 'B.pro' is therefore unnecessary. The series-produced machines can continue to be built with 'B.tsm' and 'B.pro'; it makes sense to perform a comparative scan [▶ 134](#) against the initial configuration 'B.tsm' in order to check the built machine.

However, if the series machine production department now doesn't use 'B.tsm', but instead carries out a scan to create the productive configuration, the revision **-1019** is automatically detected and built into the configuration:




Fig. 126: Detection of EtherCAT terminal with revision -1019

This is usually not noticed by the commissioning engineers. TwinCAT cannot signal anything either, since virtually a new configuration is created. According to the compatibility rule, however, this means that no EL2521-0025-**1018** should be built into this machine as a spare part (even if this nevertheless works in the vast majority of cases).

In addition, it could be the case that, due to the development accompanying production in company A, the new feature C of the EL2521-0025-1019 (for example, an improved analog filter or an additional process data for the diagnosis) is discovered and used without in-house consultation. The previous stock of spare part devices are then no longer to be used for the new configuration 'B2.tsm' created in this way. If series machine production is established, the scan should only be performed for informative purposes for comparison with a defined initial configuration. Changes are to be made with care!

If an EtherCAT device was created in the configuration (manually or through a scan), the I/O field can be scanned for devices/slaves.



Fig. 127: Scan query after automatic creation of an EtherCAT device (left: TwinCAT 2; right: TwinCAT 3)




Fig. 128: Manual triggering of a device scan on a specified EtherCAT device (left: TwinCAT 2; right: TwinCAT 3)

In the System Manager (TwinCAT 2) or the User Interface (TwinCAT 3) the scan process can be monitored via the progress bar at the bottom in the status bar.



Fig. 129: Scan progress example by TwinCAT 2

The configuration is established and can then be switched to online state (OPERATIONAL).



Fig. 130: Config/FreeRun query (left: TwinCAT 2; right: TwinCAT 3)

In Config/FreeRun mode the System Manager display alternates between blue and red, and the EtherCAT device continues to operate with the idling cycle time of 4 ms (default setting), even without active task (NC, PLC).



Fig. 131: Displaying of "Free Run" and "Config Mode" toggling right below in the status bar



Fig. 132: TwinCAT can also be switched to this state by using a button (left: TwinCAT 2; right: TwinCAT 3)

The EtherCAT system should then be in a functional cyclic state, as shown in Fig. "Online display example".




Fig. 133: Online display example

Please note:

- all slaves should be in OP state
- the EtherCAT master should be in "Actual State" OP
- "frames/sec" should match the cycle time taking into account the sent number of frames
- no excessive "LostFrames" or CRC errors should occur

The configuration is now complete. It can be modified as described under [manual procedure \[► 124\]](#).

Troubleshooting

Various effects may occur during scanning.

- An **unknown device** is detected, i.e. an EtherCAT slave for which no ESI XML description is available. In this case the System Manager offers to read any ESI that may be stored in the device. This case is described in the chapter "Notes regarding ESI device description".
- **Device are not detected properly**
Possible reasons include:
 - faulty data links, resulting in data loss during the scan
 - slave has invalid device description
 The connections and devices should be checked in a targeted manner, e.g. via the emergency scan. Then re-run the scan.




Fig. 134: Faulty identification

In the System Manager such devices may be set up as EK0000 or unknown devices. Operation is not possible or meaningful.

Scan over existing Configuration

NOTE

Change of the configuration after comparison

With this scan (TwinCAT 2.11 or 3.1) only the device properties vendor (manufacturer), device name and revision are compared at present! A 'ChangeTo' or 'Copy' should only be carried out with care, taking into consideration the Beckhoff IO compatibility rule (see above). The device configuration is then replaced by the revision found; this can affect the supported process data and functions.

If a scan is initiated for an existing configuration, the actual I/O environment may match the configuration exactly or it may differ. This enables the configuration to be compared.



Fig. 135: Identical configuration (left: TwinCAT 2; right: TwinCAT 3)

If differences are detected, they are shown in the correction dialog, so that the user can modify the configuration as required.




Fig. 136: Correction dialog

It is advisable to tick the "Extended Information" check box to reveal differences in the revision.

| Color | Explanation |
|------------|--|
| green | This EtherCAT slave matches the entry on the other side. Both type and revision match. |
| blue | <p>This EtherCAT slave is present on the other side, but in a different revision. This other revision can have other default values for the process data as well as other/additional functions.</p> <p>If the found revision is higher than the configured revision, the slave may be used provided compatibility issues are taken into account.</p> <p>If the found revision is lower than the configured revision, it is likely that the slave cannot be used. The found device may not support all functions that the master expects based on the higher revision number.</p> |
| light blue | This EtherCAT slave is ignored ("Ignore" button) |
| red | <ul style="list-style-type: none"> This EtherCAT slave is not present on the other side. It is present, but in a different revision, which also differs in its properties from the one specified. The compatibility principle then also applies here: if the found revision is higher than the configured revision, use is possible provided compatibility issues are taken into account, since the successor devices should support the functions of the predecessor devices. If the found revision is lower than the configured revision, it is likely that the slave cannot be used. The found device may not support all functions that the master expects based on the higher revision number. |

● **Device selection based on revision, compatibility**

i The ESI description also defines the process image, the communication type between master and slave/device and the device functions, if applicable. The physical device (firmware, if available) has to support the communication queries/settings of the master. This is backward compatible, i.e. newer devices (higher revision) should be supported if the EtherCAT master addresses them as an older revision. The following compatibility rule of thumb is to be assumed for Beckhoff EtherCAT Terminals/ Boxes/ EJ-modules:

device revision in the system \geq device revision in the configuration

This also enables subsequent replacement of devices without changing the configuration (different specifications are possible for drives).

Example

If an EL2521-0025-**1018** is specified in the configuration, an EL2521-0025-**1018** or higher (**-1019**, **-1020**) can be used in practice.

Name
 (EL2521-0025-1018)
Revision

Fig. 137: Name/revision of the terminal

If current ESI descriptions are available in the TwinCAT system, the last revision offered in the selection dialog matches the Beckhoff state of production. It is recommended to use the last device revision when creating a new configuration, if current Beckhoff devices are used in the real application. Older revisions should only be used if older devices from stock are to be used in the application.

In this case the process image of the device is shown in the configuration tree and can be parameterised as follows: linking with the task, CoE/DC settings, plug-in definition, startup settings, ...




Fig. 138: Correction dialog with modifications

Once all modifications have been saved or accepted, click “OK” to transfer them to the real *.tsm configuration.

Change to Compatible Type

TwinCAT offers a function “*Change to Compatible Type...*” for the exchange of a device whilst retaining the links in the task.




Fig. 139: Dialog “Change to Compatible Type...” (left: TwinCAT 2; right: TwinCAT 3)

This function is preferably to be used on AX5000 devices.

Change to Alternative Type

The TwinCAT System Manager offers a function for the exchange of a device: Change to Alternative Type




Fig. 140: TwinCAT 2 Dialog Change to Alternative Type

If called, the System Manager searches in the procured device ESI (in this example: EL1202-0000) for details of compatible devices contained there. The configuration is changed and the ESI-EEPROM is overwritten at the same time – therefore this process is possible only in the online state (ConfigMode).

5.2.7 EtherCAT subscriber configuration

In the left-hand window of the TwinCAT 2 System Manager or the Solution Explorer of the TwinCAT 3 Development Environment respectively, click on the element of the terminal within the tree you wish to configure (in the example: EL3751 Terminal 3).




Fig. 141: Branch element as terminal EL3751

In the right-hand window of the TwinCAT System manager (TwinCAT 2) or the Development Environment (TwinCAT 3), various tabs are now available for configuring the terminal. And yet the dimension of complexity of a subscriber determines which tabs are provided. Thus as illustrated in the example above the terminal EL3751 provides many setup options and also a respective number of tabs are available. On the contrary by the terminal EL1004 for example the tabs "General", "EtherCAT" and "Online" are available only. Several terminals, as for instance the EL6695 provide special functions by a tab with its own terminal name, so "EL6695" in this case. A specific tab "Settings" by terminals with a wide range of setup options will be provided also (e.g. EL3751).

„General“ tab




Fig. 142: "General" tab

| | |
|-----------------------|---|
| Name | Name of the EtherCAT device |
| Id | Number of the EtherCAT device |
| Type | EtherCAT device type |
| Comment | Here you can add a comment (e.g. regarding the system). |
| Disabled | Here you can deactivate the EtherCAT device. |
| Create symbols | Access to this EtherCAT slave via ADS is only available if this control box is activated. |

„EtherCAT“ tab

Allgemein | **EtherCAT** | Prozessdaten | Startup | CoE - Online | Online

Typ: EL5001 1K. SSI Encoder
 Produkt / Revision: EL5001-0000-0000
 Auto-Inc-Adresse: FFFB
 EtherCAT-Adresse: ☐ 1006 Weitere Einstellungen...
 Vorgänger-Port: Klemme 5 (EL5001) - B

<http://www.beckhoff.de/german/default.htm?EtherCAT/EL5001.htm>

Fig. 143: „EtherCAT“ tab

Type

EtherCAT device type

Product/Revision

Product and revision number of the EtherCAT device

Auto Inc Addr.

Auto increment address of the EtherCAT device. The auto increment address can be used for addressing each EtherCAT device in the communication ring through its physical position. Auto increment addressing is used during the start-up phase when the EtherCAT master allocates addresses to the EtherCAT devices. With auto increment addressing the first EtherCAT slave in the ring has the address 0000_{hex}. For each further slave the address is decremented by 1 (FFFF_{hex}, FFFE_{hex} etc.).

EtherCAT Addr.

Fixed address of an EtherCAT slave. This address is allocated by the EtherCAT master during the start-up phase. Tick the control box to the left of the input field in order to modify the default value.

Previous Port

Name and port of the EtherCAT device to which this device is connected. If it is possible to connect this device with another one without changing the order of the EtherCAT devices in the communication ring, then this combination field is activated and the EtherCAT device to which this device is to be connected can be selected.

Advanced Settings

This button opens the dialogs for advanced settings.

The link at the bottom of the tab points to the product page for this EtherCAT device on the web.

“Process Data” tab

Indicates the configuration of the process data. The input and output data of the EtherCAT slave are represented as CANopen process data objects (Process Data Objects, PDOs). The user can select a PDO via PDO assignment and modify the content of the individual PDO via this dialog, if the EtherCAT slave supports this function.




Fig. 144: "Process Data" tab

The process data (PDOs) transferred by an EtherCAT slave during each cycle are user data which the application expects to be updated cyclically or which are sent to the slave. To this end the EtherCAT master (Beckhoff TwinCAT) parameterizes each EtherCAT slave during the start-up phase to define which process data (size in bits/bytes, source location, transmission type) it wants to transfer to or from this slave. Incorrect configuration can prevent successful start-up of the slave.

For Beckhoff EtherCAT EL, ES, EM, EJ and EP slaves the following applies in general:

- The input/output process data supported by the device are defined by the manufacturer in the ESI/XML description. The TwinCAT EtherCAT Master uses the ESI description to configure the slave correctly.
- The process data can be modified in the system manager. See the device documentation. Examples of modifications include: mask out a channel, displaying additional cyclic information, 16-bit display instead of 8-bit data size, etc.
- In so-called "intelligent" EtherCAT devices the process data information is also stored in the CoE directory. Any changes in the CoE directory that lead to different PDO settings prevent successful startup of the slave. It is not advisable to deviate from the designated process data, because the device firmware (if available) is adapted to these PDO combinations.

If the device documentation allows modification of process data, proceed as follows (see Figure "Configuring the process data").

- A: select the device to configure
- B: in the "Process Data" tab select Input or Output under SyncManager (C)
- D: the PDOs can be selected or deselected
- H: the new process data are visible as linkable variables in the system manager
The new process data are active once the configuration has been activated and TwinCAT has been restarted (or the EtherCAT master has been restarted)
- E: if a slave supports this, Input and Output PDO can be modified simultaneously by selecting a so-called PDO record ("predefined PDO settings").




Fig. 145: Configuring the process data

Manual modification of the process data

According to the ESI description, a PDO can be identified as “fixed” with the flag “F” in the PDO overview (Fig. “Configuring the process data”, J). The configuration of such PDOs cannot be changed, even if TwinCAT offers the associated dialog (“Edit”). In particular, CoE content cannot be displayed as cyclic process data. This generally also applies in cases where a device supports download of the PDO configuration, “G”. In case of incorrect configuration the EtherCAT slave usually refuses to start and change to OP state. The System Manager displays an “invalid SM cfg” log-ger message: This error message (“invalid SM IN cfg” or “invalid SM OUT cfg”) also indicates the reason for the failed start.

A detailed description [► 145] can be found at the end of this section.

„Startup“ tab

The *Startup* tab is displayed if the EtherCAT slave has a mailbox and supports the *CANopen over EtherCAT* (CoE) or *Servo drive over EtherCAT* protocol. This tab indicates which download requests are sent to the mailbox during startup. It is also possible to add new mailbox requests to the list display. The download requests are sent to the slave in the same order as they are shown in the list.




Fig. 146: „Startup“ tab

| Column | Description |
|------------|--|
| Transition | Transition to which the request is sent. This can either be <ul style="list-style-type: none"> the transition from pre-operational to safe-operational (PS), or the transition from safe-operational to operational (SO). If the transition is enclosed in "<>" (e.g. <PS>), the mailbox request is fixed and cannot be modified or deleted by the user. |
| Protocol | Type of mailbox protocol |
| Index | Index of the object |
| Data | Date on which this object is to be downloaded. |
| Comment | Description of the request to be sent to the mailbox |

Move Up

This button moves the selected request up by one position in the list.

Move Down

This button moves the selected request down by one position in the list.

New

This button adds a new mailbox download request to be sent during startup.

Delete

This button deletes the selected entry.

Edit

This button edits an existing request.

“CoE – Online” tab

The additional *CoE - Online* tab is displayed if the EtherCAT slave supports the *CANopen over EtherCAT* (CoE) protocol. This dialog lists the content of the object list of the slave (SDO upload) and enables the user to modify the content of an object from this list. Details for the objects of the individual EtherCAT devices can be found in the device-specific object descriptions.




Fig. 147: "CoE – Online" tab

Object list display

| Column | Description | |
|--------|-----------------------------------|--|
| Index | Index and sub-index of the object | |
| Name | Name of the object | |
| Flags | RW | The object can be read, and data can be written to the object (read/write) |
| | RO | The object can be read, but no data can be written to the object (read only) |
| | P | An additional P identifies the object as a process data object. |
| Value | Value of the object | |

Update List The *Update list* button updates all objects in the displayed list

Auto Update If this check box is selected, the content of the objects is updated automatically.

Advanced The *Advanced* button opens the *Advanced Settings* dialog. Here you can specify which objects are displayed in the list.




Fig. 148: Dialog "Advanced settings"

Online - via SDO Information If this option button is selected, the list of the objects included in the object list of the slave is uploaded from the slave via SDO information. The list below can be used to specify which object types are to be uploaded.

Offline - via EDS File If this option button is selected, the list of the objects included in the object list is read from an EDS file provided by the user.

„Online“ tab




Fig. 149: „Online“ tab

State Machine

| | |
|------------------------|---|
| Init | This button attempts to set the EtherCAT device to the <i>Init</i> state. |
| Pre-Op | This button attempts to set the EtherCAT device to the <i>pre-operational</i> state. |
| Op | This button attempts to set the EtherCAT device to the <i>operational</i> state. |
| Bootstrap | This button attempts to set the EtherCAT device to the <i>Bootstrap</i> state. |
| Safe-Op | This button attempts to set the EtherCAT device to the <i>safe-operational</i> state. |
| Clear Error | This button attempts to delete the fault display. If an EtherCAT slave fails during change of state it sets an error flag. Example: An EtherCAT slave is in PREOP state (pre-operational). The master now requests the SAFEOP state (safe-operational). If the slave fails during change of state it sets the error flag. The current state is now displayed as ERR PREOP. When the <i>Clear Error</i> button is pressed the error flag is cleared, and the current state is displayed as PREOP again. |
| Current State | Indicates the current state of the EtherCAT device. |
| Requested State | Indicates the state requested for the EtherCAT device. |

DLL Status

Indicates the DLL status (data link layer status) of the individual ports of the EtherCAT slave. The DLL status can have four different states:

| Status | Description |
|---------------------|---|
| No Carrier / Open | No carrier signal is available at the port, but the port is open. |
| No Carrier / Closed | No carrier signal is available at the port, and the port is closed. |
| Carrier / Open | A carrier signal is available at the port, and the port is open. |
| Carrier / Closed | A carrier signal is available at the port, but the port is closed. |

File Access over EtherCAT

| | |
|-----------------|--|
| Download | With this button a file can be written to the EtherCAT device. |
| Upload | With this button a file can be read from the EtherCAT device. |

"DC" tab (Distributed Clocks)




Fig. 150: "DC" tab (Distributed Clocks)

| | |
|-----------------------------|--|
| Operation Mode | Options (optional): <ul style="list-style-type: none"> • FreeRun • SM-Synchron • DC-Synchron (Input based) • DC-Synchron |
| Advanced Settings... | Advanced settings for readjustment of the real time determinant TwinCAT-clock |

Detailed information to Distributed Clocks are specified on <http://infosys.beckhoff.com>:

Fieldbus Components → EtherCAT Terminals → EtherCAT System documentation → EtherCAT basics → Distributed Clocks

5.2.7.1 Detailed description of Process Data tab

Sync Manager

Lists the configuration of the Sync Manager (SM).

If the EtherCAT device has a mailbox, SM0 is used for the mailbox output (MbxOut) and SM1 for the mailbox input (MbxIn).

SM2 is used for the output process data (outputs) and SM3 (inputs) for the input process data.

If an input is selected, the corresponding PDO assignment is displayed in the *PDO Assignment* list below.

PDO Assignment

PDO assignment of the selected Sync Manager. All PDOs defined for this Sync Manager type are listed here:

- If the output Sync Manager (outputs) is selected in the Sync Manager list, all RxPDOs are displayed.
- If the input Sync Manager (inputs) is selected in the Sync Manager list, all TxPDOs are displayed.

The selected entries are the PDOs involved in the process data transfer. In the tree diagram of the System Manager these PDOs are displayed as variables of the EtherCAT device. The name of the variable is identical to the *Name* parameter of the PDO, as displayed in the PDO list. If an entry in the PDO assignment list is deactivated (not selected and greyed out), this indicates that the input is excluded from the PDO assignment. In order to be able to select a greyed out PDO, the currently selected PDO has to be deselected first.

● i Activation of PDO assignment

✓ If you have changed the PDO assignment, in order to activate the new PDO assignment,

a) the EtherCAT slave has to run through the PS status transition cycle (from pre-operational to safe-operational) once (see [Online tab \[▶ 143\]](#)),

b) and the System Manager has to reload the EtherCAT slaves



(button for TwinCAT 2 or



button for TwinCAT 3)

PDO list

List of all PDOs supported by this EtherCAT device. The content of the selected PDOs is displayed in the *PDO Content* list. The PDO configuration can be modified by double-clicking on an entry.

| Column | Description | |
|--------|---|---|
| Index | PDO index. | |
| Size | Size of the PDO in bytes. | |
| Name | Name of the PDO. If this PDO is assigned to a Sync Manager, it appears as a variable of the slave with this parameter as the name. | |
| Flags | F | Fixed content: The content of this PDO is fixed and cannot be changed by the System Manager. |
| | M | Mandatory PDO. This PDO is mandatory and must therefore be assigned to a Sync Manager! Consequently, this PDO cannot be deleted from the <i>PDO Assignment</i> list |
| SM | Sync Manager to which this PDO is assigned. If this entry is empty, this PDO does not take part in the process data traffic. | |
| SU | Sync unit to which this PDO is assigned. | |

PDO Content

Indicates the content of the PDO. If flag F (fixed content) of the PDO is not set the content can be modified.

Download

If the device is intelligent and has a mailbox, the configuration of the PDO and the PDO assignments can be downloaded to the device. This is an optional feature that is not supported by all EtherCAT slaves.

PDO Assignment

If this check box is selected, the PDO assignment that is configured in the PDO Assignment list is downloaded to the device on startup. The required commands to be sent to the device can be viewed in the [Startup \[► 140\]](#) tab.

PDO Configuration

If this check box is selected, the configuration of the respective PDOs (as shown in the PDO list and the PDO Content display) is downloaded to the EtherCAT slave.

5.3 General Notes - EtherCAT Slave Application

This summary briefly deals with a number of aspects of EtherCAT Slave operation under TwinCAT. More detailed information on this may be found in the corresponding sections of, for instance, the [EtherCAT System Documentation](#).

Diagnosis in real time: WorkingCounter, EtherCAT State and Status

Generally speaking an EtherCAT Slave provides a variety of diagnostic information that can be used by the controlling task.

This diagnostic information relates to differing levels of communication. It therefore has a variety of sources, and is also updated at various times.

Any application that relies on I/O data from a fieldbus being correct and up to date must make diagnostic access to the corresponding underlying layers. EtherCAT and the TwinCAT System Manager offer comprehensive diagnostic elements of this kind. Those diagnostic elements that are helpful to the controlling task for diagnosis that is accurate for the current cycle when in operation (not during commissioning) are discussed below.




Fig. 151: Selection of the diagnostic information of an EtherCAT Slave

In general, an EtherCAT Slave offers

- communication diagnosis typical for a slave (diagnosis of successful participation in the exchange of process data, and correct operating mode)
This diagnosis is the same for all slaves.

as well as

- function diagnosis typical for a channel (device-dependent)
See the corresponding device documentation

The colors in Fig. “Selection of the diagnostic information of an EtherCAT Slave” also correspond to the variable colors in the System Manager, see Fig. “Basic EtherCAT Slave Diagnosis in the PLC”.

| Colour | Meaning |
|--------|--|
| yellow | Input variables from the Slave to the EtherCAT Master, updated in every cycle |
| red | Output variables from the Slave to the EtherCAT Master, updated in every cycle |
| green | Information variables for the EtherCAT Master that are updated acyclically. This means that it is possible that in any particular cycle they do not represent the latest possible status. It is therefore useful to read such variables through ADS. |

Fig. “Basic EtherCAT Slave Diagnosis in the PLC” shows an example of an implementation of basic EtherCAT Slave Diagnosis. A Beckhoff EL3102 (2-channel analogue input terminal) is used here, as it offers both the communication diagnosis typical of a slave and the functional diagnosis that is specific to a channel. Structures are created as input variables in the PLC, each corresponding to the process image.




Fig. 152: Basic EtherCAT Slave Diagnosis in the PLC

The following aspects are covered here:

| Code | Function | Implementation | Application/evaluation |
|------|--|---|--|
| A | The EtherCAT Master's diagnostic information updated acyclically (yellow) or provided acyclically (green). | | At least the DevState is to be evaluated for the most recent cycle in the PLC. The EtherCAT Master's diagnostic information offers many more possibilities than are treated in the EtherCAT System Documentation. A few keywords: <ul style="list-style-type: none"> • CoE in the Master for communication with/through the Slaves • Functions from <i>TcEtherCAT.lib</i> • Perform an OnlineScan |
| B | In the example chosen (EL3102) the EL3102 comprises two analogue input channels that transmit a single function status for the most recent cycle. | Status <ul style="list-style-type: none"> • the bit significations may be found in the device documentation • other devices may supply more information, or none that is typical of a slave | In order for the higher-level PLC task (or corresponding control applications) to be able to rely on correct data, the function status must be evaluated there. Such information is therefore provided with the process data for the most recent cycle. |
| C | For every EtherCAT Slave that has cyclic process data, the Master displays, using what is known as a WorkingCounter, whether the slave is participating successfully and without error in the cyclic exchange of process data. This important, elementary information is therefore provided for the most recent cycle in the System Manager <ol style="list-style-type: none"> 1. at the EtherCAT Slave, and, with identical contents 2. as a collective variable at the EtherCAT Master (see Point A) for linking. | WcState (Working Counter) 0: valid real-time communication in the last cycle 1: invalid real-time communication This may possibly have effects on the process data of other Slaves that are located in the same SyncUnit | In order for the higher-level PLC task (or corresponding control applications) to be able to rely on correct data, the communication status of the EtherCAT Slave must be evaluated there. Such information is therefore provided with the process data for the most recent cycle. |
| D | Diagnostic information of the EtherCAT Master which, while it is represented at the slave for linking, is actually determined by the Master for the Slave concerned and represented there. This information cannot be characterized as real-time, because it <ul style="list-style-type: none"> • is only rarely/never changed, except when the system starts up • is itself determined acyclically (e.g. EtherCAT Status) | State current Status (INIT..OP) of the Slave. The Slave must be in OP (=8) when operating normally. <i>AdsAddr</i> The ADS address is useful for communicating from the PLC/task via ADS with the EtherCAT Slave, e.g. for reading/writing to the CoE. The AMS-NetID of a slave corresponds to the AMS-NetID of the EtherCAT Master; communication with the individual Slave is possible via the <i>port</i> (= EtherCAT address). | Information variables for the EtherCAT Master that are updated acyclically. This means that it is possible that in any particular cycle they do not represent the latest possible status. It is therefore possible to read such variables through ADS. |

NOTE

Diagnostic information

It is strongly recommended that the diagnostic information made available is evaluated so that the application can react accordingly.

CoE Parameter Directory

The CoE parameter directory (CanOpen-over-EtherCAT) is used to manage the set values for the slave concerned. Changes may, in some circumstances, have to be made here when commissioning a relatively complex EtherCAT Slave. It can be accessed through the TwinCAT System Manager, see Fig. "EL3102, CoE directory".




Fig. 153: EL3102, CoE directory

● EtherCAT System Documentation



The comprehensive description in the [EtherCAT System Documentation](#) (EtherCAT Basics --> CoE Interface) must be observed!

A few brief extracts:

- Whether changes in the online directory are saved locally in the slave depends on the device. EL terminals (except the EL66xx) are able to save in this way.
- The user must manage the changes to the StartUp list.

Commissioning aid in the TwinCAT System Manager

Commissioning interfaces are being introduced as part of an ongoing process for EL/EP EtherCAT devices. These are available in TwinCAT System Managers from TwinCAT 2.11R2 and above. They are integrated into the System Manager through appropriately extended ESI configuration files.




Fig. 154: Example of commissioning aid for a EL3204

This commissioning process simultaneously manages

- CoE Parameter Directory
- DC/FreeRun mode
- the available process data records (PDO)

Although the "Process Data", "DC", "Startup" and "CoE-Online" that used to be necessary for this are still displayed, it is recommended that, if the commissioning aid is used, the automatically generated settings are not changed by it.

The commissioning tool does not cover every possible application of an EL/EP device. If the available setting options are not adequate, the user can make the DC, PDO and CoE settings manually, as in the past.

EtherCAT State: automatic default behaviour of the TwinCAT System Manager and manual operation

After the operating power is switched on, an EtherCAT Slave must go through the following statuses

- INIT
- PREOP
- SAFEOP
- OP

to ensure sound operation. The EtherCAT Master directs these statuses in accordance with the initialization routines that are defined for commissioning the device by the ES/XML and user settings (Distributed Clocks (DC), PDO, CoE). See also the section on "Principles of [Communication, EtherCAT State Machine \[► 68\]](#)" in this connection. Depending how much configuration has to be done, and on the overall communication, booting can take up to a few seconds.

The EtherCAT Master itself must go through these routines when starting, until it has reached at least the OP target state.

The target state wanted by the user, and which is brought about automatically at start-up by TwinCAT, can be set in the System Manager. As soon as TwinCAT reaches the status RUN, the TwinCAT EtherCAT Master will approach the target states.

Standard setting

The advanced settings of the EtherCAT Master are set as standard:

- EtherCAT Master: OP
- Slaves: OP
This setting applies equally to all Slaves.




Fig. 155: Default behaviour of the System Manager

In addition, the target state of any particular Slave can be set in the "Advanced Settings" dialogue; the standard setting is again OP.




Fig. 156: Default target state in the Slave

Manual Control

There are particular reasons why it may be appropriate to control the states from the application/task/PLC. For instance:

- for diagnostic reasons
- to induce a controlled restart of axes
- because a change in the times involved in starting is desirable

In that case it is appropriate in the PLC application to use the PLC function blocks from the *TcEtherCAT.lib*, which is available as standard, and to work through the states in a controlled manner using, for instance, *FB_EcSetMasterState*.

It is then useful to put the settings in the EtherCAT Master to INIT for master and slave.




Fig. 157: PLC function blocks

Note regarding E-Bus current

EL/ES terminals are placed on the DIN rail at a coupler on the terminal strand. A Bus Coupler can supply the EL terminals added to it with the E-bus system voltage of 5 V; a coupler is thereby loadable up to 2 A as a rule. Information on how much current each EL terminal requires from the E-bus supply is available online and in the catalogue. If the added terminals require more current than the coupler can supply, then power feed terminals (e.g. EL9410) must be inserted at appropriate places in the terminal strand.

The pre-calculated theoretical maximum E-Bus current is displayed in the TwinCAT System Manager as a column value. A shortfall is marked by a negative total amount and an exclamation mark; a power feed terminal is to be placed before such a position.

| General Adapter EtherCAT Online CoE - Online | | | | | | |
|--|------------------|-----------------|--------|----------------------|----------|-----------|
| NetId: | | 10.43.2.149.2.1 | | Advanced Settings... | | |
| Number | Box Name | Address | Type | In Size | Out S... | E-Bus (.. |
| 1 | Term 1 (EK1100) | 1001 | EK1100 | | | |
| 2 | Term 2 (EL3102) | 1002 | EL3102 | 8.0 | | 1830 |
| 3 | Term 4 (EL2004) | 1003 | EL2004 | | 0.4 | 1730 |
| 4 | Term 5 (EL2004) | 1004 | EL2004 | | 0.4 | 1630 |
| 5 | Term 6 (EL7031) | 1005 | EL7031 | 8.0 | 8.0 | 1510 |
| 6 | Term 7 (EL2808) | 1006 | EL2808 | | 1.0 | 1400 |
| 7 | Term 8 (EL3602) | 1007 | EL3602 | 12.0 | | 1210 |
| 8 | Term 9 (EL3602) | 1008 | EL3602 | 12.0 | | 1020 |
| 9 | Term 10 (EL3602) | 1009 | EL3602 | 12.0 | | 830 |
| 10 | Term 11 (EL3602) | 1010 | EL3602 | 12.0 | | 640 |
| 11 | Term 12 (EL3602) | 1011 | EL3602 | 12.0 | | 450 |
| 12 | Term 13 (EL3602) | 1012 | EL3602 | 12.0 | | 260 |
| 13 | Term 14 (EL3602) | 1013 | EL3602 | 12.0 | | 70 |
| 14 | Term 3 (EL6688) | 1014 | EL6688 | 22.0 | | -240 ! |

Fig. 158: Illegally exceeding the E-Bus current

From TwinCAT 2.11 and above, a warning message "E-Bus Power of Terminal..." is output in the logger window when such a configuration is activated:

| Message |
|--|
| E-Bus Power of Terminal 'Term 3 (EL6688)' may to low (-240 mA) - please check! |

Fig. 159: Warning message for exceeding E-Bus current




| NOTE |
|---|
| Caution! Malfunction possible! The same ground potential must be used for the E-Bus supply of all EtherCAT terminals in a terminal block! |

6 Appendix

6.1 EtherCAT AL Status Codes

For detailed information please refer to the [EtherCAT system description](#).

6.2 UL notice

| | |
|---|---|
|  | Application Beckhoff EtherCAT modules are intended for use with Beckhoff's UL Listed EtherCAT System only. |
|  | Examination For cULus examination, the Beckhoff I/O System has only been investigated for risk of fire and electrical shock (in accordance with UL508 and CSA C22.2 No. 142). |
|  | For devices with Ethernet connectors Not for connection to telecommunication circuits. |

Basic principles

UL certification according to UL508. Devices with this kind of certification are marked by this sign:



6.3 Firmware compatibility

Beckhoff EtherCAT devices are delivered with the latest available firmware version. Compatibility of firmware and hardware is mandatory; not every combination ensures compatibility. The overview below shows the hardware versions on which a firmware can be operated.

Note

- It is recommended to use the newest possible firmware for the respective hardware.
- Beckhoff is not under any obligation to provide customers with free firmware updates for delivered products.

NOTE

Risk of damage to the device!

Pay attention to the instructions for firmware updates on the [separate page \[► 156\]](#). If a device is placed in BOOTSTRAP mode for a firmware update, it does not check when downloading whether the new firmware is suitable. This can result in damage to the device! Therefore, always make sure that the firmware is suitable for the hardware version!

| EL2014 | | | |
|---------------|---------------|------------------|-----------------|
| Hardware (HW) | Firmware (FW) | Revision no. | Date of release |
| 00 - 02* | 01 | EL2014-0000-0016 | 2015/05 |
| | 02 | | 2015/07 |
| | 03 | EL2014-0000-0017 | 2016/03 |
| | 04* | | 2019/12 |

There are no further terminals from the EL20xx and EL2124 series that have firmware.

*) This is the current compatible firmware/hardware version at the time of the preparing this documentation. Check on the Beckhoff web page whether more up-to-date [documentation](#) is available.

6.4 Firmware Update EL/ES/EM/ELM/EPxxxx

This section describes the device update for Beckhoff EtherCAT slaves from the EL/ES, ELM, EM, EK and EP series. A firmware update should only be carried out after consultation with Beckhoff support.

Storage locations

An EtherCAT slave stores operating data in up to 3 locations:

- Depending on functionality and performance EtherCAT slaves have one or several local controllers for processing I/O data. The corresponding program is the so-called **firmware** in *.efw format.
- In some EtherCAT slaves the EtherCAT communication may also be integrated in these controllers. In this case the controller is usually a so-called **FPGA** chip with *.rbf firmware.
- In addition, each EtherCAT slave has a memory chip, a so-called **ESI-EEPROM**, for storing its own device description (ESI: EtherCAT Slave Information). On power-up this description is loaded and the EtherCAT communication is set up accordingly. The device description is available from the download area of the Beckhoff website at (<https://www.beckhoff.de>). All ESI files are accessible there as zip files.

Customers can access the data via the EtherCAT fieldbus and its communication mechanisms. Acyclic mailbox communication or register access to the ESC is used for updating or reading of these data.

The TwinCAT System Manager offers mechanisms for programming all 3 parts with new data, if the slave is set up for this purpose. Generally the slave does not check whether the new data are suitable, i.e. it may no longer be able to operate if the data are unsuitable.

Simplified update by bundle firmware

The update using so-called **bundle firmware** is more convenient: in this case the controller firmware and the ESI description are combined in a *.efw file; during the update both the firmware and the ESI are changed in the terminal. For this to happen it is necessary

- for the firmware to be in a packed format: recognizable by the file name, which also contains the revision number, e.g. ELxxx-xxx_REV0016_SW01.efw
- for password=1 to be entered in the download dialog. If password=0 (default setting) only the firmware update is carried out, without an ESI update.
- for the device to support this function. The function usually cannot be retrofitted; it is a component of many new developments from year of manufacture 2016.

Following the update, its success should be verified

- ESI/Revision: e.g. by means of an online scan in TwinCAT ConfigMode/FreeRun – this is a convenient way to determine the revision
- Firmware: e.g. by looking in the online CoE of the device

NOTE

Risk of damage to the device!

Note the following when downloading new device files

- Firmware downloads to an EtherCAT device must not be interrupted
- Flawless EtherCAT communication must be ensured. CRC errors or LostFrames must be avoided.
- The power supply must adequately dimensioned. The signal level must meet the specification.

In the event of malfunctions during the update process the EtherCAT device may become unusable and require re-commissioning by the manufacturer.

6.4.1 Device description ESI file/XML

NOTE

Attention regarding update of the ESI description/EEPROM

Some slaves have stored calibration and configuration data from the production in the EEPROM. These are irretrievably overwritten during an update.

The ESI device description is stored locally on the slave and loaded on start-up. Each device description has a unique identifier consisting of slave name (9 characters/digits) and a revision number (4 digits). Each slave configured in the System Manager shows its identifier in the EtherCAT tab:




Fig. 160: Device identifier consisting of name EL3204-0000 and revision -0016

The configured identifier must be compatible with the actual device description used as hardware, i.e. the description which the slave has loaded on start-up (in this case EL3204). Normally the configured revision must be the same or lower than that actually present in the terminal network.

For further information on this, please refer to the [EtherCAT system documentation](#).

i Update of XML/ESI description

The device revision is closely linked to the firmware and hardware used. Incompatible combinations lead to malfunctions or even final shutdown of the device. Corresponding updates should only be carried out in consultation with Beckhoff support.

Display of ESI slave identifier

The simplest way to ascertain compliance of configured and actual device description is to scan the EtherCAT boxes in TwinCAT mode Config/FreeRun:




Fig. 161: Scan the subordinate field by right-clicking on the EtherCAT device

If the found field matches the configured field, the display shows



Fig. 162: Configuration is identical

otherwise a change dialog appears for entering the actual data in the configuration.




Fig. 163: Change dialog

In this example in Fig. *Change dialog*, an EL3201-0000-**0017** was found, while an EL3201-0000-**0016** was configured. In this case the configuration can be adapted with the *Copy Before* button. The *Extended Information* checkbox must be set in order to display the revision.

Changing the ESI slave identifier

The ESI/EEPROM identifier can be updated as follows under TwinCAT:

- Trouble-free EtherCAT communication must be established with the slave.
- The state of the slave is irrelevant.
- Right-clicking on the slave in the online display opens the *EEPROM Update* dialog, Fig. *EEPROM Update*




Fig. 164: EEPROM Update

The new ESI description is selected in the following dialog, see Fig. *Selecting the new ESI*. The checkbox *Show Hidden Devices* also displays older, normally hidden versions of a slave.




Fig. 165: Selecting the new ESI

A progress bar in the System Manager shows the progress. Data are first written, then verified.

● The change only takes effect after a restart.

i Most EtherCAT devices read a modified ESI description immediately or after startup from the INIT. Some communication settings such as distributed clocks are only read during power-on. The EtherCAT slave therefore has to be switched off briefly in order for the change to take effect.

6.4.2 Firmware explanation

Determining the firmware version

Determining the version on laser inscription

Beckhoff EtherCAT slaves feature serial numbers applied by laser. The serial number has the following structure: **KK YY FF HH**

KK - week of production (CW, calendar week)
 YY - year of production
 FF - firmware version
 HH - hardware version

Example with ser. no.: 12 10 03 02:

12 - week of production 12
 10 - year of production 2010
 03 - firmware version 03
 02 - hardware version 02

Determining the version via the System Manager

The TwinCAT System Manager shows the version of the controller firmware if the master can access the slave online. Click on the E-Bus Terminal whose controller firmware you want to check (in the example terminal 2 (EL3204)) and select the tab *CoE Online* (CAN over EtherCAT).

● CoE Online and Offline CoE

i Two CoE directories are available:

- **online:** This is offered in the EtherCAT slave by the controller, if the EtherCAT slave supports this. This CoE directory can only be displayed if a slave is connected and operational.
- **offline:** The EtherCAT Slave Information ESI/XML may contain the default content of the CoE. This CoE directory can only be displayed if it is included in the ESI (e.g. "Beckhoff EL5xxx.xml").

The Advanced button must be used for switching between the two views.

In Fig. *Display of EL3204 firmware version* the firmware version of the selected EL3204 is shown as 03 in CoE entry 0x100A.




Fig. 166: Display of EL3204 firmware version

In (A) TwinCAT 2.11 shows that the Online CoE directory is currently displayed. If this is not the case, the Online directory can be loaded via the *Online* option in Advanced Settings (B) and double-clicking on *All Objects*.

6.4.3 Updating controller firmware *.efw



CoE directory

The Online CoE directory is managed by the controller and stored in a dedicated EEPROM, which is generally not changed during a firmware update.

Switch to the *Online* tab to update the controller firmware of a slave, see Fig. *Firmware Update*.






Fig. 167: Firmware Update

Proceed as follows, unless instructed otherwise by Beckhoff support. Valid for TwinCAT 2 and 3 as EtherCAT master.

- Switch TwinCAT system to ConfigMode/FreeRun with cycle time ≥ 1 ms (default in ConfigMode is 4 ms). A FW-Update during real time operation is not recommended.




- Switch EtherCAT Master to PreOP



- Switch slave to INIT (A)
- Switch slave to BOOTSTRAP

- Check the current status (B, C)
- Download the new *efw file (wait until it ends). A pass word will not be necessary usually.



- After the download switch to INIT, then PreOP
- Switch off the slave briefly (don't pull under voltage!)
- Check within CoE 0x100A, if the FW status was correctly overtaken.

6.4.4 FPGA firmware *.rbf

If an FPGA chip deals with the EtherCAT communication an update may be accomplished via an *.rbf file.

- Controller firmware for processing I/O signals
- FPGA firmware for EtherCAT communication (only for terminals with FPGA)

The firmware version number included in the terminal serial number contains both firmware components. If one of these firmware components is modified this version number is updated.

Determining the version via the System Manager

The TwinCAT System Manager indicates the FPGA firmware version. Click on the Ethernet card of your EtherCAT strand (Device 2 in the example) and select the *Online* tab.

The *Reg:0002* column indicates the firmware version of the individual EtherCAT devices in hexadecimal and decimal representation.





Fig. 168: FPGA firmware version definition

If the column *Reg:0002* is not displayed, right-click the table header and select *Properties* in the context menu.

Fig. 169: Context menu *Properties*

The *Advanced Settings* dialog appears where the columns to be displayed can be selected. Under *Diagnosis/Online View* select the '*0002 ETxxx Build*' check box in order to activate the FPGA firmware version display.




Fig. 170: Dialog *Advanced Settings*

Update

For updating the FPGA firmware

- of an EtherCAT coupler the coupler must have FPGA firmware version 11 or higher;
- of an E-Bus Terminal the terminal must have FPGA firmware version 10 or higher.


Older firmware versions can only be updated by the manufacturer!

Updating an EtherCAT device


The following sequence order have to be met if no other specifications are given (e.g. by the Beckhoff support):

- Switch TwinCAT system to ConfigMode/FreeRun with cycle time ≥ 1 ms (default in ConfigMode is 4 ms). A FW-Update during real time operation is not recommended.


- In the TwinCAT System Manager select the terminal for which the FPGA firmware is to be updated (in the example: Terminal 5: EL5001) and click the *Advanced Settings* button in the *EtherCAT* tab:



- The *Advanced Settings* dialog appears. Under *ESC Access/E²PROM/FPGA* click on *Write FPGA* button:



- Select the file (*.rbf) with the new FPGA firmware, and transfer it to the EtherCAT device:



- Wait until download ends
- Switch slave current less for a short time (don't pull under voltage!). In order to activate the new FPGA firmware a restart (switching the power supply off and on again) of the EtherCAT device is required.
- Check the new FPGA status

NOTE

Risk of damage to the device!

A download of firmware to an EtherCAT device must not be interrupted in any case! If you interrupt this process by switching off power supply or disconnecting the Ethernet link, the EtherCAT device can only be recommissioned by the manufacturer!

6.4.5 Simultaneous updating of several EtherCAT devices

The firmware and ESI descriptions of several devices can be updated simultaneously, provided the devices have the same firmware file/ESI.




Fig. 171: Multiple selection and firmware update

Select the required slaves and carry out the firmware update in BOOTSTRAP mode as described above.

6.5 Restoring the delivery state

To restore the delivery state for backup objects in ELxxxx terminals, the CoE object Restore default parameters, *SubIndex 001* can be selected in the TwinCAT System Manager (Config mode) (see Fig. *Selecting the Restore default parameters PDO*)




Fig. 172: Selecting the "Restore default parameters" PDO

Double-click on SubIndex 001 to enter the Set Value dialog. Enter the value **1684107116** in field *Dec* or the value **0x64616F6C** in field *Hex* and confirm with *OK* (Fig. *Entering a restore value in the Set Value dialog*). All backup objects are reset to the delivery state.




Fig. 173: Entering a restore value in the Set Value dialog

Alternative restore value

In some older terminals the backup objects can be switched with an alternative restore value: Decimal value: 1819238756, Hexadecimal value: 0x6C6F6164An incorrect entry for the restore value has no effect.

6.6 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages:

<http://www.beckhoff.com>

You will also find further documentation for Beckhoff components there.

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

| | |
|---------|--|
| Phone: | +49 5246 963 0 |
| Fax: | +49 5246 963 198 |
| e-mail: | info@beckhoff.com |

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

| | |
|----------|--|
| Hotline: | +49 5246 963 157 |
| Fax: | +49 5246 963 9157 |
| e-mail: | support@beckhoff.com |

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

| | |
|----------|--|
| Hotline: | +49 5246 963 460 |
| Fax: | +49 5246 963 479 |
| e-mail: | service@beckhoff.com |

List of illustrations

| | | |
|---------|--|----|
| Fig. 1 | EL5021 EL terminal, standard IP20 IO device with serial/ batch number and revision ID (since 2014/01)..... | 11 |
| Fig. 2 | EK1100 EtherCAT coupler, standard IP20 IO device with serial/ batch number..... | 11 |
| Fig. 3 | EL3202-0020 with serial/ batch number 26131006 and unique ID-number 204418 | 11 |
| Fig. 4 | BIC as data matrix code (DMC, code scheme ECC200)..... | 12 |
| Fig. 5 | Negative example – active load | 15 |
| Fig. 6 | Ground connection of the load: correct (K1) and incorrect (K2) | 16 |
| Fig. 7 | Short circuit fault exclusion through protected cable laying..... | 17 |
| Fig. 8 | EL2002, EL2004 | 18 |
| Fig. 9 | EL2008 | 18 |
| Fig. 10 | EL2002 | 21 |
| Fig. 11 | EL2004 | 22 |
| Fig. 12 | EL2008 | 23 |
| Fig. 13 | EL2014 | 24 |
| Fig. 14 | EL2014 | 26 |
| Fig. 15 | Overload current limitation | 27 |
| Fig. 16 | Schematic illustration of the thermal switch-off in case of overload | 27 |
| Fig. 17 | Switch-off of inductive loads | 28 |
| Fig. 18 | EL2014 "Process Data" tab | 29 |
| Fig. 19 | EL2014 Online illustration of the process data and structural contents in the System Manager | 30 |
| Fig. 20 | EL2014 "Process Data" tab | 31 |
| Fig. 21 | EL2014 CoE directory..... | 33 |
| Fig. 22 | Change of state of the outputs in the case of a bus error..... | 34 |
| Fig. 23 | Graphical illustration of the channel state during a bus error | 35 |
| Fig. 24 | EL2022 | 44 |
| Fig. 25 | EL2024, EL2024-0010..... | 44 |
| Fig. 26 | EL2022 | 46 |
| Fig. 27 | EL2024, EL2024-0010..... | 47 |
| Fig. 28 | EL2032, EL2034 | 49 |
| Fig. 29 | EL2032 | 51 |
| Fig. 30 | EL2034 | 52 |
| Fig. 31 | EL2042 | 54 |
| Fig. 32 | EL2042 | 56 |
| Fig. 33 | EL2084, EL2088 | 58 |
| Fig. 34 | EL2084 | 60 |
| Fig. 35 | EL2088 | 61 |
| Fig. 36 | EL2124 | 62 |
| Fig. 37 | EL2124 | 64 |
| Fig. 38 | System manager current calculation | 66 |
| Fig. 39 | EtherCAT tab -> Advanced Settings -> Behavior -> Watchdog | 67 |
| Fig. 40 | States of the EtherCAT State Machine..... | 69 |
| Fig. 41 | "CoE Online " tab..... | 72 |
| Fig. 42 | Startup list in the TwinCAT System Manager | 73 |
| Fig. 43 | Offline list..... | 74 |

| | | |
|---------|---|-----|
| Fig. 44 | Online list | 74 |
| Fig. 45 | Attaching on mounting rail | 76 |
| Fig. 46 | Disassembling of terminal..... | 77 |
| Fig. 47 | Power contact on left side..... | 78 |
| Fig. 48 | Correct positioning..... | 79 |
| Fig. 49 | Incorrect positioning..... | 80 |
| Fig. 50 | Recommended distances for standard installation position | 81 |
| Fig. 51 | Other installation positions | 82 |
| Fig. 52 | Standard wiring..... | 82 |
| Fig. 53 | Pluggable wiring | 83 |
| Fig. 54 | High Density Terminals..... | 83 |
| Fig. 55 | Connecting a cable on a terminal point | 84 |
| Fig. 56 | Relationship between user side (commissioning) and installation..... | 89 |
| Fig. 57 | Control configuration with Embedded PC, input (EL1004) and output (EL2008) | 90 |
| Fig. 58 | Initial TwinCAT 2 user interface | 91 |
| Fig. 59 | Selection of the target system | 92 |
| Fig. 60 | Specify the PLC for access by the TwinCAT System Manager: selection of the target system .. | 92 |
| Fig. 61 | Select "Scan Devices..." | 93 |
| Fig. 62 | Automatic detection of I/O devices: selection the devices to be integrated..... | 93 |
| Fig. 63 | Mapping of the configuration in the TwinCAT 2 System Manager..... | 94 |
| Fig. 64 | Reading of individual terminals connected to a device..... | 94 |
| Fig. 65 | TwinCAT PLC Control after startup | 95 |
| Fig. 66 | Sample program with variables after a compile process (without variable integration) | 96 |
| Fig. 67 | Appending the TwinCAT PLC Control project | 96 |
| Fig. 68 | PLC project integrated in the PLC configuration of the System Manager | 97 |
| Fig. 69 | Creating the links between PLC variables and process objects | 97 |
| Fig. 70 | Selecting PDO of type BOOL | 98 |
| Fig. 71 | Selecting several PDOs simultaneously: activate "Continuous" and "All types"..... | 98 |
| Fig. 72 | Application of a "Goto Link" variable, using "MAIN.bEL1004_Ch4" as a sample | 99 |
| Fig. 73 | Choose target system (remote) | 100 |
| Fig. 74 | PLC Control logged in, ready for program startup | 101 |
| Fig. 75 | Initial TwinCAT 3 user interface..... | 102 |
| Fig. 76 | Create new TwinCAT project..... | 102 |
| Fig. 77 | New TwinCAT3 project in the project folder explorer | 103 |
| Fig. 78 | Selection dialog: Choose the target system | 103 |
| Fig. 79 | Specify the PLC for access by the TwinCAT System Manager: selection of the target system .. | 104 |
| Fig. 80 | Select "Scan" | 104 |
| Fig. 81 | Automatic detection of I/O devices: selection the devices to be integrated..... | 105 |
| Fig. 82 | Mapping of the configuration in VS shell of the TwinCAT3 environment..... | 105 |
| Fig. 83 | Reading of individual terminals connected to a device..... | 106 |
| Fig. 84 | Adding the programming environment in "PLC" | 107 |
| Fig. 85 | Specifying the name and directory for the PLC programming environment | 107 |
| Fig. 86 | Initial "Main" program of the standard PLC project..... | 108 |
| Fig. 87 | Sample program with variables after a compile process (without variable integration) | 109 |
| Fig. 88 | Start program compilation..... | 109 |
| Fig. 89 | Creating the links between PLC variables and process objects | 110 |

| | | |
|----------|--|-----|
| Fig. 90 | Selecting PDO of type BOOL | 110 |
| Fig. 91 | Selecting several PDOs simultaneously: activate "Continuous" and "All types" | 111 |
| Fig. 92 | Application of a "Goto Link" variable, using "MAIN.bEL1004_Ch4" as a sample | 111 |
| Fig. 93 | TwinCAT development environment (VS shell): logged-in, after program startup..... | 112 |
| Fig. 94 | System Manager "Options" (TwinCAT 2)..... | 114 |
| Fig. 95 | Call up under VS Shell (TwinCAT 3) | 114 |
| Fig. 96 | Overview of network interfaces | 114 |
| Fig. 97 | EtherCAT device properties(TwinCAT 2): click on „Compatible Devices...“ of tab "Adapter" | 115 |
| Fig. 98 | Windows properties of the network interface..... | 115 |
| Fig. 99 | Exemplary correct driver setting for the Ethernet port | 116 |
| Fig. 100 | Incorrect driver settings for the Ethernet port | 117 |
| Fig. 101 | TCP/IP setting for the Ethernet port | 118 |
| Fig. 102 | Identifier structure | 119 |
| Fig. 103 | OnlineDescription information window (TwinCAT 2) | 120 |
| Fig. 104 | Information window OnlineDescription (TwinCAT 3) | 120 |
| Fig. 105 | File OnlineDescription.xml created by the System Manager | 121 |
| Fig. 106 | Indication of an online recorded ESI of EL2521 as an example | 121 |
| Fig. 107 | Information window for faulty ESI file (left: TwinCAT 2; right: TwinCAT 3)..... | 121 |
| Fig. 108 | Using the ESI Updater (>= TwinCAT 2.11)..... | 123 |
| Fig. 109 | Using the ESI Updater (TwinCAT 3)..... | 123 |
| Fig. 110 | Append EtherCAT device (left: TwinCAT 2; right: TwinCAT 3) | 124 |
| Fig. 111 | Selecting the EtherCAT connection (TwinCAT 2.11, TwinCAT 3)..... | 124 |
| Fig. 112 | Selecting the Ethernet port | 124 |
| Fig. 113 | EtherCAT device properties (TwinCAT 2) | 125 |
| Fig. 114 | Appending EtherCAT devices (left: TwinCAT 2; right: TwinCAT 3)..... | 125 |
| Fig. 115 | Selection dialog for new EtherCAT device | 126 |
| Fig. 116 | Display of device revision | 126 |
| Fig. 117 | Display of previous revisions | 127 |
| Fig. 118 | Name/revision of the terminal | 127 |
| Fig. 119 | EtherCAT terminal in the TwinCAT tree (left: TwinCAT 2; right: TwinCAT 3)..... | 128 |
| Fig. 120 | Differentiation local/target system (left: TwinCAT 2; right: TwinCAT 3)..... | 129 |
| Fig. 121 | Scan Devices (left: TwinCAT 2; right: TwinCAT 3)..... | 129 |
| Fig. 122 | Note for automatic device scan (left: TwinCAT 2; right: TwinCAT 3)..... | 129 |
| Fig. 123 | Detected Ethernet devices | 130 |
| Fig. 124 | Example default state | 130 |
| Fig. 125 | Installing EthetCAT terminal with revision -1018 | 131 |
| Fig. 126 | Detection of EtherCAT terminal with revision -1019..... | 131 |
| Fig. 127 | Scan query after automatic creation of an EtherCAT device (left: TwinCAT 2; right: TwinCAT 3) | 131 |
| Fig. 128 | Manual triggering of a device scan on a specified EtherCAT device (left: TwinCAT 2; right: TwinCAT 3)..... | 132 |
| Fig. 129 | Scan progressexemplary by TwinCAT 2 | 132 |
| Fig. 130 | Config/FreeRun query (left: TwinCAT 2; right: TwinCAT 3)..... | 132 |
| Fig. 131 | Displaying of "Free Run" and "Config Mode" toggling right below in the status bar | 132 |
| Fig. 132 | TwinCAT can also be switched to this state by using a button (left: TwinCAT 2; right: TwinCAT 3) | 132 |
| Fig. 133 | Online display example | 133 |

| | | |
|----------|---|-----|
| Fig. 134 | Faulty identification | 133 |
| Fig. 135 | Identical configuration (left: TwinCAT 2; right: TwinCAT 3) | 134 |
| Fig. 136 | Correction dialog | 134 |
| Fig. 137 | Name/revision of the terminal | 135 |
| Fig. 138 | Correction dialog with modifications | 136 |
| Fig. 139 | Dialog "Change to Compatible Type..." (left: TwinCAT 2; right: TwinCAT 3) | 136 |
| Fig. 140 | TwinCAT 2 Dialog Change to Alternative Type | 136 |
| Fig. 141 | Branch element as terminal EL3751 | 137 |
| Fig. 142 | "General" tab | 137 |
| Fig. 143 | „EtherCAT“ tab | 138 |
| Fig. 144 | "Process Data" tab | 139 |
| Fig. 145 | Configuring the process data | 140 |
| Fig. 146 | „Startup“ tab | 141 |
| Fig. 147 | "CoE – Online" tab | 142 |
| Fig. 148 | Dialog "Advanced settings" | 143 |
| Fig. 149 | „Online“ tab | 143 |
| Fig. 150 | "DC" tab (Distributed Clocks) | 144 |
| Fig. 151 | Selection of the diagnostic information of an EtherCAT Slave | 147 |
| Fig. 152 | Basic EtherCAT Slave Diagnosis in the PLC | 148 |
| Fig. 153 | EL3102, CoE directory | 150 |
| Fig. 154 | Example of commissioning aid for a EL3204 | 151 |
| Fig. 155 | Default behaviour of the System Manager | 152 |
| Fig. 156 | Default target state in the Slave | 152 |
| Fig. 157 | PLC function blocks | 153 |
| Fig. 158 | Illegally exceeding the E-Bus current | 154 |
| Fig. 159 | Warning message for exceeding E-Bus current | 154 |
| Fig. 160 | Device identifier consisting of name EL3204-0000 and revision -0016 | 157 |
| Fig. 161 | Scan the subordinate field by right-clicking on the EtherCAT device | 158 |
| Fig. 162 | Configuration is identical | 158 |
| Fig. 163 | Change dialog | 159 |
| Fig. 164 | EEPROM Update | 159 |
| Fig. 165 | Selecting the new ESI | 160 |
| Fig. 166 | Display of EL3204 firmware version | 161 |
| Fig. 167 | Firmware Update | 162 |
| Fig. 168 | FPGA firmware version definition | 164 |
| Fig. 169 | Context menu Properties | 164 |
| Fig. 170 | Dialog Advanced Settings | 165 |
| Fig. 171 | Multiple selection and firmware update | 167 |
| Fig. 172 | Selecting the "Restore default parameters" PDO | 168 |
| Fig. 173 | Entering a restore value in the Set Value dialog | 168 |