

		Not logged in	Operation	Programming (restricted)		Programming	Maintenance	Risk Management
				Check				
				Checked	Not checked			
Robot System/Cell Operation	Executing a program from the TP Panel (*1)	-	-	-	-	-	-	-
Robot System/Cell Operation	Checking the status of the robot controller	-	●	●	●	●	●	●
Robot System/Cell Operation	Changing a password for the logged in account	-	●	●	●	●	●	●
Robot Operation	Switching the modes (Auto/Manual/Program Check)	-	-	●	●	●	●	●
Robot Operation	Clearing an error	-	-	●	●	●	●	●
Robot Operation	STO reset	-	-	●	●	●	●	-
Robot Operation	Motor ON/OFF	-	-	●	●	●	●	-
Robot Operation	External speed	-	-	●	●	●	●	-
Robot Operation	Switching the move modes (Joint/X-Y/TOOL)	-	-	●	●	●	●	-
Robot Operation	Selecting a coordinate system (Work Number/Tool Number)	-	-	●	●	●	●	-
Robot Operation	Manual operation	-	-	●	-	●	●	-
Robot Operation	Variable move	-	-	●	-	●	●	-
Robot Operation	Program operation (Start/Stop/Reset)	-	-	●	-	●	-	-
Robot Operation	I/O operation (ON/OFF)	-	-	●	-	●	-	-
Robot Operation	Recovery	-	-	●	-	●	-	-
Robot Operation	Home Position Guidance	-	-	●	-	●	-	-
Programming	Editing variables	-	-	-	-	●	-	-
Programming	Machine Lock (ON/OFF)	-	-	-	-	●	-	-
Programming	Editing a program	-	-	-	-	●	-	-
Programming	Editing parameters	-	-	-	-	●	-	-
Maintenance	Deleting an extension function	-	-	-	-	-	●	-
Maintenance	Editing/Resetting an encoder reference position	-	-	-	-	-	●	-
Maintenance	Executing CALSET	-	-	-	-	-	●	-
Maintenance	Releasing the brakes	-	-	-	-	-	●	-
Maintenance	Changing the axis settings	-	-	-	-	-	●	-

Maintenance	Setting the maximum acceleration	-	-	-	-	-	●	-
Maintenance	FPGA setting	-	-	-	-	-	●	-
Maintenance	Deleting XAE data	-	-	-	-	-	●	-
Maintenance	Changing the robot type in the MC9 controller	-	-	-	-	-	●	-
Maintenance	Permitting the version upgrade	-	-	-	-	-	●	-
Programming	Editing parameters	-	-	-	-	-	●	-
Risk Assessment	Motion-related settings	-	-	-	-	-	-	●
Risk Assessment	User account management	-	-	-	-	-	-	●
Risk Assessment	Setting the auto logout time	-	-	-	-	-	-	●
Risk Assessment	STO reset message display setting	-	-	-	-	-	-	●
Risk Assessment	Sending the safety parameters	-	-	-	-	-	-	●

● : Available

- : Not available

*1:	Some of the processing directly written in events of the TP Panel buttons can be executed.
-----	--